

HOMCOM 837-415CF

HOMCOM Slim Shoe Cabinet 837-415CF Instruction Manual

Model: 837-415CF | Brand: HOMCOM

1. PRODUCT OVERVIEW

The HOMCOM Slim Shoe Cabinet (Model 837-415CF) is designed for efficient shoe storage in compact spaces. It features three fold-out drawers and a spacious top surface for additional items. Constructed from P2 grade particleboard, this cabinet offers durability and ease of maintenance.



Image 1.1: Front view of the HOMCOM Slim Shoe Cabinet with drawers closed.

Key Features:

- **Sufficient Storage:** Three fold-out drawers provide ample space for shoes while maintaining a small footprint.
- **Anti-Toppling Device:** Includes a safety device to secure the cabinet to a wall, preventing accidental tipping.
- **Upper Storage:** The top shelf offers extra space for small items like keys, wallets, or decorative objects.
- **Easy-To-Clean:** Made from P2 grade particleboard for simple maintenance.

2. SETUP AND ASSEMBLY

This shoe cabinet requires assembly. Please follow the included assembly instructions carefully. It is recommended to lay out all components and hardware before beginning assembly to ensure all parts are present.

Small-print Design

• Suitable for limited space



Image 2.1: Illustration of the cabinet's slim profile and the anti-tilt design for wall mounting.

Important Assembly Notes:

- **Check All Parts:** Verify that all components and hardware listed in the assembly manual are present and undamaged before starting.
- **Follow Instructions:** Adhere strictly to the step-by-step instructions provided in the separate assembly guide.
- **Anti-Toppling Device:** For safety, always install the anti-toppling device to secure the cabinet to a wall, especially in households with children or pets.
- **Tools:** Ensure you have the necessary tools as specified in the assembly manual.

3. OPERATING INSTRUCTIONS

The HOMCOM Slim Shoe Cabinet is designed for easy access and organization of your footwear.



Image 3.1: The shoe cabinet with its three fold-out drawers open, displaying stored shoes.

Using the Shoe Drawers:

1. **Open Drawers:** Gently pull the handle on each drawer to tilt it open. The drawers are designed to fold out, providing access to the shoe compartments.
2. **Store Shoes:** Place shoes into the designated compartments within each drawer. The storage capacity depends on shoe size and type.
3. **Adjustable Compartments:** The internal dividers within each drawer can be adjusted to two positions to accommodate different shoe sizes. Refer to the diagram below for adjustment.
4. **Close Drawers:** Push the drawer back into the cabinet until it is fully closed and flush with the cabinet front.

Two-position adjusted

- Fit for shoes of different sizes



Image 3.2: Detail of the two-position adjustable mechanism for shoe compartments.

Using the Top Surface:

The top surface of the cabinet provides a convenient area for placing small items. Avoid placing excessively heavy objects on the top surface to prevent damage or instability.

Top shelf provide extra space



Image 3.3: The top shelf provides additional space for small items or decorations.

4. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your HOMCOM Slim Shoe Cabinet.

Cleaning:

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Dry immediately with a clean, dry cloth to prevent water marks.

General Care:

- Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Ensure the anti-toppling device remains securely attached to both the cabinet and the wall.
- Avoid exposing the cabinet to excessive moisture or direct sunlight, which can cause warping or fading.

5. TROUBLESHOOTING

If you encounter issues with your shoe cabinet, refer to the following common solutions.

Cabinet Wobbles:

- **Check Level Surface:** Ensure the cabinet is placed on a flat, level surface.
- **Tighten Fasteners:** Verify that all assembly screws and fasteners are securely tightened.
- **Anti-Toppling Device:** Confirm the anti-toppling device is correctly installed and anchored to the wall. This is crucial for stability.

Drawers Do Not Close Properly:

- **Obstruction:** Check for any shoes or objects obstructing the drawer mechanism.
- **Alignment:** Ensure the drawer mechanism is correctly aligned. If recently assembled, re-check the assembly steps for the drawers.

Missing or Damaged Parts:

- If you find any parts missing or damaged upon unboxing, do not proceed with assembly. Contact HOMCOM customer support immediately for assistance.

6. SPECIFICATIONS

Detailed specifications for the HOMCOM Slim Shoe Cabinet (Model 837-415CF).





Image 6.1: Product dimensions of the shoe cabinet.

| Specification | Detail |
|--------------------------------|---|
| Brand | HOMCOM |
| Model Name | Shoe Cabinet |
| Model Number | 837-415CF |
| Color | Espresso |
| Product Dimensions (L x W x H) | 23.5" x 9.5" x 52" |
| Item Weight | 57.3 Pounds |
| Material | Engineered Wood, Metal, Plastic |
| Number of Drawers | 3 |
| Mounting Type | Floor Mount (with anti-toppling device for wall securing) |
| Assembly Required | Yes |
| Recommended Use | Indoor, Entryway |

7. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product functionality, please contact HOMCOM customer

support.

Customer Support:

- Refer to your purchase documentation or the HOMCOM official website for the most current contact information.
- When contacting support, please have your model number (837-415CF) and proof of purchase ready.

For more information about HOMCOM products, visit the official [HOMCOM Store](#).