Beurer BR 60

Beurer BR 60 Insect Bite Healer Instruction Manual

1. Introduction

The Beurer BR 60 is an insect bite healer designed to quickly alleviate discomfort from mosquito bites, horsefly bites, and other insect stings. It utilizes concentrated heat to reduce itching, swelling, and irritation without the need for chemical additives or creams. The device offers two selectable programs to suit skin sensitivity: a 3-second program for quick relief and a 6-second program for more intensive application. The BR 60 is clinically tested, suitable for use during pregnancy, and ideal for the entire family. Its portable and lightweight design makes it convenient for travel and outdoor activities. It operates on batteries (included), heats up quickly, and provides a fast, safe application without direct contact with broken skin.



Image 1.1: The Beurer BR 60 Insect Bite Healer and its retail packaging.

2. Safety Information

Please read these instructions for use carefully and keep them for later reference. Make them accessible to other users and observe the information they contain.

Important Warnings:

- Always read the label, warnings, and instructions provided with the product before use.
- Do not use on irritated, broken, or open skin.
- Avoid contact with eyes and mucous membranes.
- Keep out of reach of children.
- If symptoms persist or worsen, consult a medical professional.

- The device generates heat. Ensure the application time is appropriate for your skin sensitivity to avoid discomfort.

3. Product Overview

The Beurer BR 60 is a compact and effective device for treating insect bites and stings. It uses a ceramic heating plate to deliver targeted heat.



Image 3.1: The Beurer BR 60 device, highlighting its ergonomic design.

Key Features:

- **Targeted Heat Application:** Relieves itching and swelling by applying concentrated heat to the affected area.
- **Two Programs:** Offers 3-second and 6-second application times for varying skin sensitivities.
- **Chemical-Free:** Operates solely with heat, making it suitable for pregnant women and individuals with sensitive skin.
- **Fast-Heating Ceramic Plate:** Ensures quick and efficient treatment.
- **Compact and Portable:** Ideal for travel and outdoor use.



Image 3.2: Summary of the Beurer BR 60's main features.

4. Setup

What's in the Box:

- 1x Beurer BR 60 Insect Bite Healer
- 2x AAA (LR03 1.5V) Batteries
- 1x Instruction Manual

Inserting Batteries:

The Beurer BR 60 requires 2 AAA batteries (included). To insert or replace batteries:

1. Locate the battery compartment cover on the back of the device.
2. Slide the cover open.

3. Insert the 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image 4.1: Side view of the Beurer BR 60, indicating the power switch location.

5. Operating Instructions

Follow these steps to use your Beurer BR 60 Insect Bite Healer:

1. **Power On:** Slide the power switch (located on the side of the device) to the 'ON' position.
2. **Position Device:** Place the ceramic heating plate directly onto the insect bite or sting.
3. **Select Program:** Press the activation button once for the 3-second program (suitable for sensitive skin). Press the activation button twice in quick succession for the 6-second program.
4. **Treatment:** The device will heat up and apply warmth for the selected duration. A beep will sound when the treatment is complete.
5. **Remove Device:** Once the beep sounds, remove the device from the skin.



Image 5.1: Step-by-step guide to using the Beurer BR 60 for insect bites.

Understanding the Heat Treatment:

The Beurer BR 60 applies heat to the affected area. This localized heat helps to break down the proteins in insect venom, which are responsible for causing itching and swelling. The device is designed to reach a safe and effective temperature of approximately 50°C (122°F).



Image 5.2: Temperature comparison, showing the BR 60's operating temperature is safe and effective.



Image 5.3: Illustration of the heat mechanism reducing itching and swelling.

6. Maintenance

To ensure the longevity and hygiene of your Beurer BR 60:

- **Cleaning:** After each use, gently wipe the ceramic heating plate with a clean, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the device no longer heats up effectively or the indicator light dims.

7. Troubleshooting

If you encounter issues with your Beurer BR 60, refer to the following common solutions:

- **Device not turning on:**
  - Check if the power switch is in the 'ON' position.
  - Ensure batteries are inserted correctly with the right polarity.
  - Replace batteries with new ones.
- **Device not heating up:**
  - Confirm the device is powered on and batteries are fresh.
  - Ensure the activation button is pressed correctly for the desired program (once for 3s, twice for 6s).
- **Discomfort during use:**
  - If the heat feels too intense, use the 3-second program or remove the device immediately.
  - Do not use on highly sensitive or broken skin.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Specification	Detail
Model Number	60617
Dimensions	9.8 x 3.5 x 1.9 cm
Weight	100 grams
Power Supply	2 x AAA (LR03 1.5V) Batteries
Brand	Beurer
Country of Origin	Germany
Special Feature	Lightweight
Recommended Use	Travel
Color	Black

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Beurer website. If you require technical support or have questions about your Beurer BR 60, please contact Beurer customer service:

Manufacturer: Beurer GmbH
Söflinger Str. 218
89077 Ulm, Germany

You can also find more information and support on the official Beurer website:www.beurer.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question