

## PowerLocus KWSS3059

# PowerLocus P3 Bluetooth Headphones User Manual

Model: KWSS3059

## INTRODUCTION

---

This manual provides comprehensive instructions for the PowerLocus P3 Bluetooth Headphones. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. The PowerLocus P3 headphones offer high-fidelity stereo sound with deep bass, Bluetooth 5.0 connectivity, and a comfortable over-ear design suitable for extended use.



Figure 1: PowerLocus P3 Bluetooth Headphones with included protective carrying case.

## PACKAGE CONTENTS

---

Upon unboxing, verify that all components are present:

- PowerLocus P3 Bluetooth Headphones
- USB Charging Cable
- 3.5mm Audio Cable
- Protective Carrying Case
- User Manual (this document)



Figure 2: All items included in the PowerLocus P3 headphone package.

## SETUP

---

### 1. Initial Charging

Before first use, fully charge the headphones. Connect the USB charging cable to the headphone's charging port and to a compatible USB power source. A full charge takes approximately **2 hours**. The LED indicator will change color or turn off once charging is complete.

Your browser does not support the video tag.

Video 1: This video demonstrates the quick charging capability of the PowerLocus P3 headphones, highlighting the USB charging port and the estimated 40 hours of battery life after a full charge.

### 2. Bluetooth Pairing

The PowerLocus P3 headphones utilize **Bluetooth 5.0** for a quick and stable connection. They can connect to iOS, Android, and Windows devices.

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "PowerLocus P3" in the list of available devices.
4. Select "PowerLocus P3" to connect. The LED indicator will turn solid blue once successfully paired.

The headphones can connect to **two devices simultaneously**, allowing seamless switching between, for example, a laptop and a smartphone.

Your browser does not support the video tag.

Video 2: This video illustrates the Bluetooth connectivity of the PowerLocus P3 headphones, showing how they can connect to multiple devices like a laptop and a smartphone.

## OPERATING INSTRUCTIONS

---

### Controls Overview

The PowerLocus P3 headphones feature intuitive controls located on the earcup:

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up/Next Track:** Short press for volume up. Long press for next track.
- **Volume Down/Previous Track:** Short press for volume down. Long press for previous track.
- **Microphone:** Built-in for hands-free calls.




Figure 3: Key features of the PowerLocus P3 headphones, including control functions.

### Wired Mode

For situations where wireless connectivity is not desired or battery is low, you can use the included **3.5mm audio cable**. Simply plug one end into the headphone's audio jack and the other into your device's audio output. In wired mode, the built-in microphone remains functional for calls.

### Comfort and Portability

The headphones are designed for comfort with **soft memory foam earmuffs** and an adjustable headband. They are also **foldable** for easy storage and portability in the included protective case.



Figure 4: Design features emphasizing comfort and portability.

## MAINTENANCE

---

Proper maintenance ensures the longevity and performance of your PowerLocus P3 headphones:

- **Cleaning:** Use a soft, dry cloth to wipe the headphones. For earmuffs, a slightly damp cloth can be used, but ensure they are completely dry before storage. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in the provided protective carrying case to prevent dust accumulation and physical damage.
- **Temperature:** Avoid exposing the headphones to extreme temperatures (hot or cold) or high humidity, as this can damage internal components and battery life.
- **Liquid Contact:** The headphones are not water-resistant. Avoid contact with liquids.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully (approx. 2 hours).
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn device Bluetooth off and on. Move headphones closer to the device (within 10 meters).
No sound or poor sound quality.	Volume too low; incorrect audio source; loose wired connection.	Increase headphone and device volume. Ensure correct audio output is selected on your device. If using wired mode, ensure the 3.5mm cable is securely connected.
Microphone not working.	Microphone muted on device; incorrect input selected.	Check device settings to ensure the microphone is not muted and the PowerLocus P3 is selected as the input device.

## SPECIFICATIONS

Feature	Detail
Model Name	P3
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Bluetooth Version	5.0
Bluetooth Range	10 Meters (33 feet)
Battery Life	Up to 40 Hours
Charging Time	2 Hours
Audio Driver Type	Dynamic Driver (40mm)
Noise Control	Sound Isolation (Passive)
Earpiece Shape	Over-Ear
Material	Plastic/Metal, Synthetic Leather, Foam
Item Weight	175 Grams (6.2 ounces)
Dimensions	7.05 x 6.38 x 3.19 inches
Color	Matt Rose Gold

## WARRANTY AND SUPPORT

PowerLocus offers a **24-month warranty** for the P3 Bluetooth Headphones. This warranty covers manufacturing defects and ensures repair or replacement within 24 hours if you are not satisfied with the performance.

For any inquiries, technical assistance, or warranty claims, please contact PowerLocus Customer Support. They provide **24/7 customer support** to assist you.

For the most up-to-date contact information, please refer to the official PowerLocus website or the contact details provided with your product packaging.

