

[Manuals.plus](#) /

› [Easytry123](#) /

› Easytry Replacement Remote Control User Manual for Fujitsu Air Conditioners (Models AR-DL10, AR-DL9, AR-DL6, AR-DL5, ABG36RGA3W, ABY30RGA-W, ABT45RGA3, ASY24RGA-W, AS20A, AS20R, AS24R, AS24A)

Easytry123 Easytry Replacement Remote Control (B089JWYCLR)

Easytry Replacement Remote Control User Manual

For Fujitsu Air Conditioners (Models: AR-DL10, AR-DL9, AR-DL6, AR-DL5, ABG36RGA3W, ABY30RGA-W, ABT45RGA3, ASY24RGA-W, AS20A, AS20R, AS24R, AS24A)

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Easytry replacement remote control. This remote is designed to be compatible with various Fujitsu air conditioner models, including AR-DL10, AR-DL9, AR-DL6, AR-DL5, ABG36RGA3W, ABY30RGA-W, ABT45RGA3, ASY24RGA-W, AS20A, AS20R, AS24R, and AS24A. Please read this manual carefully before using the remote control.

Important Note: This replacement remote control may not support all functions of your original Fujitsu air conditioner remote. Refer to your air conditioner's original manual for specific unit features.

SETUP

Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect installation can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Back view of the remote control with the battery compartment open, illustrating where to insert two AAA batteries. Note the polarity markings (+/-) inside the compartment.

After installing the batteries, the remote control is ready for use. No programming is typically required for this replacement unit.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your remote control. The layout is designed for intuitive operation of your Fujitsu air conditioner.



Figure 2: Front view of the remote control, displaying the LCD screen and various function buttons.

Button Functions

- **START/STOP:** Powers the air conditioner ON or OFF.
- **MASTER CONTROL:** Selects the operating mode (e.g., Cool, Heat, Fan, Dry, Auto). Press repeatedly to cycle through modes.
- **SET TEMP (+/-):** Adjusts the desired temperature setting. Use '+' to increase and '-' to decrease.
- **FAN CONTROL:** Adjusts the fan speed (e.g., Auto, Low, Medium, High). Press repeatedly to cycle through speeds.
- **TIMER:** Activates or adjusts the timer functions for scheduled ON/OFF operations.
- **SET TIME:** Used in conjunction with the TIMER button to set specific times.
- **AIR CLEAN:** Activates or deactivates the air purification function (if supported by your AC unit).
- **SWING:** Controls the louver swing function for air direction.
- **SET:** Confirms settings or enters a setting mode.
- **TIME ADJUST ACL:** Likely a reset or adjustment button for internal clock/timer settings. Use a pointed object to press.

Basic Operation

1. **Turning On/Off:** Press the **START/STOP** button once to turn the unit on, and again to turn it off.
2. **Selecting Mode:** Press the **MASTER CONTROL** button to cycle through available modes (Cool, Heat, Fan, Dry, Auto). The selected mode will typically display on the remote's LCD screen.
3. **Adjusting Temperature:** Use the **SET TEMP (+)** or **(-)** buttons to set your desired room temperature.
4. **Adjusting Fan Speed:** Press the **FAN CONTROL** button to change the fan speed.

MAINTENANCE

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim or unresponsive. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the unit.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are installed correctly with the correct polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
 - Verify that you are within the effective operating range of the air conditioner.
- **Some functions do not work:**
 - This replacement remote may not support all advanced or specific functions of your original Fujitsu air conditioner remote. This is a common characteristic of universal or replacement remotes.
 - Refer to your air conditioner's original manual to confirm if the function is supported by your unit.
- **Display is dim or blank:**
 - Replace the batteries.

SPECIFICATIONS

Brand	Easytry123
Compatible Devices	Fujitsu Air Conditioners (Models: AR-DL10, AR-DL9, AR-DL6, AR-DL5, ABG36RGA3W, ABY30RGA-W, ABT45RGA3, ASY24RGA-W, AS20A, AS20R, AS24R, AS24A)
Connectivity Technology	Infrared (IR)

Controller Type	Button Control
Batteries Required	2 x AAA (not included)
Special Feature	Ergonomic design

WARRANTY AND SUPPORT

This product is a replacement remote control. For specific warranty information, please refer to the purchase documentation or contact the seller, Easytry123, directly through the platform where the purchase was made. Keep your proof of purchase for any warranty claims.

For further assistance or inquiries, please contact the manufacturer or seller.