

[Manuals.plus](#) /

› [BoostArea](#) /

› BoostArea Torchiera Floor Lamp User Manual

BoostArea HD005BYH

BoostArea Torchiera Floor Lamp User Manual

Model: HD005BYH | Brand: BoostArea

1. INTRODUCTION

Thank you for choosing the BoostArea Torchiera Floor Lamp. This 30W super bright LED standing lamp is designed to provide versatile and energy-efficient lighting for your living room, bedroom, or office. With its stepless dimming capability and durable metal construction, it offers both functionality and modern aesthetics. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your lamp.

Key features include: 3000K natural daylight with up to 3600 lumens, stepless dimming via a rotary switch with memory function, and compatibility with smart home devices for enhanced convenience.

2. WHAT'S IN THE BOX

- Lampshade with Integrated LED Bulb
- Lamp Pole Sections (Multiple pieces)
- Lamp Base
- Power Cord (pre-attached to base)
- User Manual



Figure 2.1: All lamp components including the lampshade, pole sections, and base.

3. SETUP AND ASSEMBLY

Assembly of your BoostArea Torchiere Floor Lamp is designed to be quick and tool-free. Please follow these steps carefully:

1. Carefully unpack all components and lay them out on a clean, flat surface.
2. Screw the top pole section into the lampshade. Ensure the connection is secure but do not overtighten.
3. Gently pull the power cord from the bottom of the base to ensure there is enough slack for assembly.
4. Connect the remaining lamp pole sections one by one, screwing them together clockwise. Ensure each connection is firm

and straight to maintain the lamp's stability. Be careful not to cross-thread the connections.

5. Once all pole sections are connected, screw the assembled pole into the lamp base. Ensure the power cord is not twisted or pinched during this step.
6. Adjust the lamp to its desired position. The lamp stands approximately 70.5 inches tall when fully assembled.



Figure 3.1: Assembling the lamp pole sections.

Easy Assembly

Fix it within 5minutes, no tools needed



Figure 3.2: The assembled lamp, ready for use.

Assembly Video Guide

Video 3.1: Step-by-step installation guide for the BoostArea dimmable floor lamp.

4. OPERATING INSTRUCTIONS

Your BoostArea Torchiere Floor Lamp offers intuitive control for a personalized lighting experience.

4.1 Power and Dimming Control

The lamp features a rotary switch located on the pole for easy operation:

- **Turn On/Off:** Rotate the switch clockwise until you hear a click to turn the lamp on. Rotate counter-clockwise until it clicks to turn it off.
- **Stepless Dimming:** Once the lamp is on, continue rotating the switch clockwise to increase brightness and counter-clockwise to decrease brightness. The lamp offers stepless dimming from 5% to 100% brightness.
- **Memory Function:** The lamp will remember your last brightness setting when turned off and will return to that setting when

turned back on.

Stepless Dimmable Brightness



Find the perfect light for your task



Figure 4.1: Stepless dimming capability from low to high brightness.



Figure 4.2: The lamp provides 3000K natural daylight, ideal for reading and working.

4.2 Smart Device Compatibility

For added convenience, this dimmable floor lamp is compatible with smart plugs (not included) or wall switches (not included). You can integrate it into your smart home system and control it via your smartphone or voice assistant.

Product Overview Video

Video 4.1: An overview of the BoostArea 24W LED Floor Lamp's features and design.

5. MAINTENANCE

To ensure your BoostArea Torchiere Floor Lamp remains in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Dust the lamp regularly with a soft, dry cloth. For more stubborn marks, use a slightly damp cloth and wipe dry immediately. Avoid abrasive cleaners or solvents that could damage the finish.
- **LED Care:** The lamp uses an integrated LED light source designed for long-term use. There is no need to replace bulbs. The LED technology ensures the lamp remains cool during operation, minimizing heat-related issues.
- **Stability Check:** Periodically check that all pole connections are secure and the base is stable. Tighten if necessary.

6. TROUBLESHOOTING

If you encounter any issues with your BoostArea Torchiere Floor Lamp, please refer to the following common troubleshooting steps:

- **Lamp Does Not Turn On:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the rotary switch is fully turned to the 'ON' position.
 - Verify that the wall outlet is receiving power by testing it with another device.
- **Dimming Function Not Working:**
 - Ensure the lamp is fully turned on before attempting to adjust brightness.
 - Rotate the switch slowly and deliberately to observe changes in brightness.
- **Lamp Flickers or Shuts Off:**
 - Check for loose connections in the lamp pole sections. Disassemble and reassemble if necessary, ensuring all parts are screwed in tightly.
 - Ensure the lamp is not connected to a non-compatible dimmer switch or smart plug that might interfere with its internal dimming mechanism.
- **Unstable Lamp:**
 - Ensure the base is on a flat, level surface.
 - Verify that all pole sections are securely screwed together and into the base.

If the issue persists after trying these steps, please contact customer support for further assistance.

7. SPECIFICATIONS

Brand	BoostArea
Model Number	HD005BYH
Product Dimensions	11"D x 11"W x 70.5"H
Item Weight	10.4 Pounds
Material	Metal
Finish Type	Painted
Light Source Type	LED
Wattage	30 watts
Brightness	3600 Lumen
Color Temperature	3000 Kelvin

Switch Type	Rotary
Room Type	Living Room, Bedroom
UPC	191893132623

8. WARRANTY AND SUPPORT

BoostArea is committed to providing high-quality products. For information regarding product warranty, please refer to the documentation included with your purchase or visit the official BoostArea website. Optional protection plans are available for purchase to extend coverage for your lamp:

- 3-Year Protection Plan
- 4-Year Protection Plan
- Complete Protect (monthly plan covering eligible purchases)

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact BoostArea customer service through the retailer where you purchased the product or via the contact information provided on the BoostArea official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

