GAPPO Y40174-US

Gappo Kitchen Faucet User Manual

Model: Y40174-US | Brand: GAPPO

1. Product Overview

The Gappo Kitchen Faucet with Pull Down Sprayer is a contemporary single-handle kitchen sink faucet crafted from solid brass with a brushed nickel finish. Designed for both functionality and style, it features a spring spout and a pull-down sprayer, offering versatile water delivery options for your kitchen tasks.



Figure 1: Gappo Kitchen Faucet - Main Unit

This faucet combines a sleek design with practical features, including a ceramic disc cartridge for durability and a 360-degree swivel spout for full sink access. Its corrosion and rust-resistant finish ensures long-lasting aesthetic appeal and easy maintenance.



Figure 2: Key Features of the Gappo Kitchen Faucet

2. Setup and Installation

The Gappo Kitchen Faucet is designed for easy single-hole deck mount installation. All necessary tool accessories are included in the package. The faucet uses US standard 3/8" water hoses, which are compatible with most US kitchen setups.

2.1. Pre-Installation Checklist

- Ensure all components are present as per the packing list.
- Turn off the main water supply to your kitchen sink.
- Clear the area under the sink for easy access.

2.2. Installation Steps

1. Insert the faucet into the single hole on your sink or countertop.
2. From underneath the sink, slide the rubber gasket, then the metal washer, onto the threaded shank of the

faucet. This metal washer is crucial for protecting the counter material and ensuring a secure fit.

3. Secure the faucet using the mounting nut. Hand-tighten first, then use a basin wrench to fully tighten, ensuring the faucet is aligned correctly.
4. Connect the hot and cold water supply lines to your angle stops. Ensure connections are tight to prevent leaks.
5. Connect the pull-down sprayer hose to the main faucet body.
6. Attach the weight to the pull-down hose, typically 6-8 inches from the sprayer head, to ensure smooth retraction.
7. Once all connections are secure, slowly turn on the main water supply and check for any leaks.




Figure 3: Faucet Dimensions for Installation Planning

3. Operation

The Gappo Kitchen Faucet offers intuitive control and versatile water delivery for various kitchen tasks.

3.1. Water Flow and Temperature Control

The single lever handle controls both water flow and temperature. Lift the handle to increase flow, and move it left for hot water or right for cold water.

3.2. Dual-Function Sprayer

The pull-down sprayer features two distinct modes: Stream Mode and Spray Mode. A button on the sprayer head allows for easy toggling between these modes. The unique lock design on the sprayer allows you to keep the spray mode active without continuously holding the button, enabling one-hand rinsing.



Figure 4: Using the Pull-Down Sprayer for Rinsing



Figure 5: Sprayer in use for washing produce



Figure 6: Close-up of the Sprayer Head



Figure 7: Dual-Functionality of the Faucet

3.3. 360-Degree Swivel Spout

The main spout can swivel 360 degrees, providing complete access to all areas of your sink without blind spots, making it ideal for double sinks or large basins.

3.4. Official Product Video

Video 1: GAPPO Spring Kitchen Faucet 2 Function. This video demonstrates the two functions of the GAPPO Spring Kitchen Faucet: stream and spray modes, highlighting its versatility and ease of use.

4. Care and Maintenance

To ensure the longevity and pristine appearance of your Gappo Kitchen Faucet, follow these simple care and maintenance guidelines:

- **Regular Cleaning:** Clean the faucet regularly with a soft cloth and mild soap or a non-abrasive liquid cleaner. The superior corrosion and rust-resistant brushed nickel finish is designed to resist water spots, fading, and fingerprints, making cleaning effortless.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, ammonia, bleach, or cleaners containing alcohol or harsh chemicals, as these can damage the finish and internal components.
- **Dry After Use:** Wiping the faucet dry after each use can help prevent water spots and mineral buildup, especially in areas with hard water.
- **Check Connections:** Periodically check all connections for tightness to prevent leaks.

5. Troubleshooting

This section addresses common issues you might encounter with your Gappo Kitchen Faucet.

Problem	Possible Cause	Solution
Low Water Flow/Pressure	Partially closed shut-off valves; clogged aerator; kinked supply lines.	Ensure shut-off valves are fully open. Unscrew and clean the aerator. Check supply lines for kinks or obstructions.
Leaks from Sprayer Head	Loose connection; damaged O-ring; internal sprayer issue.	Ensure the sprayer hose connection is tight. Inspect and replace O-rings if damaged. If the issue persists, contact customer support.
Water Leaking from Base of Faucet	Loose mounting nut; improperly seated gaskets.	Tighten the mounting nut under the sink. Ensure all gaskets and washers are correctly positioned and not damaged during installation.
No Hot or Cold Water	Supply line valves closed; cross-connection.	Check that both hot and cold water supply valves are fully open. Consult a plumber if cross-connection is suspected.

6. Product Specifications

Feature	Detail
Brand	GAPPO
Model Number	Y40174-US
Material	Solid Brass (Lead-free)
Finish Type	Brushed Nickel (Oil Rubbed)
Mounting Type	Single Hole Deck Mount
Number of Handles	1 (Lever Handle)
Special Feature	360° Swivel Spout, Pull-Down Sprayer with Lock Design
Item Weight	5.73 pounds
Product Dimensions	19.29 x 11.61 x 3.15 inches

Feature	Detail
UPC	783710051028

7. Warranty and Customer Support

GAPPO is committed to providing high-quality products and excellent customer service. For any issues regarding your faucet, including installation, operation, or troubleshooting, please do not hesitate to contact us.
While specific warranty details may vary, GAPPO stands behind its products. Please refer to your purchase documentation for precise warranty terms. For direct support, you can typically reach out to the seller or manufacturer through the platform where the product was purchased.
Contact Information:
For support, please visit the official GAPPO store on Amazon or contact their customer service directly via the contact details provided with your purchase or on their official website.

© 2024 GAPPO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question