

[Manuals.plus](#) /

› [RASTAR](#) /

› RASTAR Audi RC Car, 1/14 Audi R8 Performance Model Toy Car Sports Racing Remote Control Car for Adults Boys Girls Kids Instruction Manual

RASTAR S00075300-01

RASTAR Audi R8 Performance RC Car Instruction Manual

Model: S00075300-01

INTRODUCTION

Thank you for purchasing the RASTAR Audi R8 Performance RC Car. This 1:14 scale model is officially licensed by Audi and designed for an engaging remote control experience. This manual will guide you through the setup, operation, and maintenance of your new RC car to ensure long-lasting enjoyment.



Image: The RASTAR Audi R8 Performance RC Car in white with racing decals, accompanied by its black steering wheel-shaped remote control.

PACKAGE CONTENTS

- 1 x Rastar Audi Remote Control Car
- 1 x Dual-grip Remote-controller
- 1 x User Guide



Image: The RASTAR Audi R8 Performance RC Car and its remote control displayed in front of the product packaging, which reads "LET HEALTH & HAPPINESS SURROUND YOU".

SETUP

Battery Installation

The RC car and remote control require batteries (not included). For optimal performance and longevity, rechargeable batteries are highly recommended.

- **For the RC Car:** Locate the battery compartment on the underside of the car. Open the cover and insert five (5) AA batteries, ensuring correct polarity (+/-). Close the cover securely.
- **For the Remote Control:** Locate the battery compartment on the back of the remote control. Open the cover and insert two (2) AA batteries, ensuring correct polarity (+/-). Close the cover securely.



Image: The underside of the RC car, showing the battery compartment designed for five AA batteries, along with the power switch and direction adjustment knob.

Initial Pairing

Once batteries are installed in both the car and the remote, turn on the power switch on the car (usually located on the underside). Then, turn on the remote control. The car and remote should automatically pair. If not, turn both off and on again. The 2.4GHz frequency allows multiple users to race together without interference.

OPERATING INSTRUCTIONS

Controls

The dual-grip remote controller provides intuitive control over the RC car:

- **Forward:** Push the forward lever/button.
- **Reverse:** Push the reverse lever/button.
- **Turn Left:** Use the left steering control.

- **Turn Right:** Use the right steering control.
- **Stop:** Release the control levers/buttons.

BATTERIES-POWERED

- Full functions - Forward, Reverse, Turn Left/Right
- Remote range up to 98 feet
- Speed 5 mph
- Frequency 2.4GHz
- Batteries NOT included



Image: An overhead view of the RC car with arrows indicating forward, reverse, left, and right movement, alongside the remote control, highlighting its battery-powered functionality.

Driving Tips

- The car performs best on flat, smooth surfaces. It can be used both indoors and outdoors.
- The remote range is up to 98 feet (approximately 30 meters).
- The car can reach speeds of up to 5 mph.
- Working LED headlights and taillights activate as the car moves forward and reverses, enhancing realism.



Image: A detailed diagram of the RC car pointing out key features such as the officially licensed Audi logo, extraordinary profile, rear wing, working taillights, independent suspension system, front shock absorption, and rear differential mechanism.




Image: Close-up views of the RC car's details, including working headlights, inner decoration (steering wheel), rims and tires, and side mirror.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the car and remote. Avoid using water or chemical cleaners, as they may damage electronic components.
- **Storage:** When not in use, store the car and remote in a cool, dry place away from direct sunlight. Remove batteries if the product will not be used for an extended period to prevent leakage.
- **Battery Care:** If using rechargeable batteries, follow the manufacturer's instructions for charging and discharging. Do not mix old and new batteries, or different types of batteries.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Car does not move or responds poorly.	Low batteries in car or remote; Car and remote not paired; Interference.	Replace or recharge batteries; Turn both car and remote off then on again to re-pair; Move to an area with less electronic interference.
Lights not working.	Low batteries; Damaged wiring.	Replace or recharge batteries; Contact customer support if issue persists.
Short control range.	Low batteries; Obstacles blocking signal; Environmental interference.	Replace or recharge batteries; Operate in an open area; Avoid areas with strong radio signals.

SPECIFICATIONS

- **Scale:** 1:14
- **Product Dimensions:** 12.6 x 5.63 x 3.27 inches (32 x 14.3 x 8.3 cm)
- **Item Weight:** 2.31 pounds
- **Model Number:** S00075300-01
- **Manufacturer Recommended Age:** 6 years and up
- **Car Batteries:** 5 x AA (not included)
- **Remote Control Batteries:** 2 x AA (not included)
- **Speed:** Up to 5 mph
- **Remote Range:** Up to 98 feet
- **Frequency:** 2.4GHz



Image: A diagram illustrating the dimensions of the RASTAR Audi R8 RC Car, showing its length as 32cm (12.6 inches), width as 14.3cm (5.6 inches), and height as 8.3cm (3.3 inches).

WARRANTY AND SUPPORT

RASTAR products are manufactured with quality and care. For any questions, technical support, or warranty inquiries, please contact RASTAR customer service. Refer to the contact information provided on the product packaging or the official RASTAR website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question