

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [VASAGLE](#) /

> [VASAGLE TV Stand ULTV027X01 Instruction Manual](#)

VASAGLE ULTV027X01

VASAGLE TV Stand ULTV027X01 Instruction Manual

Model: ULTV027X01

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VASAGLE TV Stand, model ULTV027X01. Please read these instructions carefully before assembly and use to ensure safe and correct installation and to maximize the lifespan of your product.

SAFETY INFORMATION

- Assemble furniture correctly and securely.
- Do not exceed the maximum static load capacity of **176 lb (80 kg)**.
- Ensure all connections are tightened before use. Periodically check and re-tighten all fasteners.
- Keep small parts away from children during assembly.
- Place the TV stand on a flat, stable surface.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x TV Cabinet
- 1 x Assembly Kit (includes all necessary hardware and tools)
- 1 x Instructions Manual (this document)

Note: A drill, pencil, and hammer are not required for assembly, as all necessary tools are provided.

SETUP AND ASSEMBLY

Assembly is required for this product. Follow the detailed, easy-to-understand instructions provided in the assembly kit. All parts are numbered, and hardware is clearly marked in individual bags to simplify the process.

1. **Unpack Components:** Carefully remove all pieces from the packaging. Inspect each piece for any damage.
2. **Identify Parts:** Match each component with its corresponding letter as indicated in the assembly instructions. Identify all hardware by their numbers.
3. **Follow Step-by-Step Instructions:** Refer to the pictorial guide in the assembly kit for a clear, sequential assembly process. Ensure all connections are secure but do not overtighten until instructed.
4. **Attach Legs:** Securely attach the legs to the base of the TV stand.
5. **Install Shelves:** The shelves are height-adjustable. Insert the shelf pins into the desired holes before placing the shelves.
6. **Install Doors:** Attach the magnetic doors. Ensure they align properly and close securely.



Image: Fully assembled VASAGLE TV Stand in a living room setting, showcasing its rustic brown finish and overall design.



Image: Detail of the adjustable shelf pins, illustrating how shelves can be positioned at different heights.

OPERATING INSTRUCTIONS

The VASAGLE TV Stand is designed to accommodate televisions up to 60 inches and provide organized storage for media devices and accessories.

- **TV Placement:** Place your television securely on the top surface of the stand. Ensure the TV's base fits within the stand's dimensions and does not exceed the maximum weight capacity of 176 lb (80 kg).
- **Open Shelves:** Utilize the two open shelves for media players, gaming consoles, or decorative items. The height of the left open shelf is adjustable.
- **Storage Compartments:** The two compartments behind the magnetic doors offer concealed storage for DVDs, remote controls, or other items. The shelves inside these compartments are also height-adjustable.
- **Cable Management:** The stand features cut-outs on the back panel for easy cable routing, helping to keep wires organized and out of sight.



Image: The TV stand used in a bedroom, demonstrating the open shelves for devices and the closed storage compartments.



Image: A close-up view of a door slightly open, showing the interior storage space and the rustic finish.

MAINTENANCE

To maintain the appearance and longevity of your TV stand, follow these care instructions:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood material.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Environmental Conditions:** Avoid placing the stand in direct sunlight or near heat sources, as this can cause fading or warping.

TROUBLESHOOTING

If you encounter any issues with your TV stand, consider the following common solutions:

- **Wobbly Stand:** Ensure all screws and bolts are fully tightened. Verify that the stand is placed on a level surface. Adjust the feet if necessary.
- **Doors Not Closing Properly:** Check the alignment of the door hinges and magnetic catches. Adjust them if they appear misaligned. Ensure no items inside the cabinet are obstructing the doors.
- **Missing Parts:** If you find any parts missing during assembly, refer to the "Package Contents" section and contact customer support for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	ULTV027X01
Brand	VASAGLE
Material	Engineered Wood (Particleboard, FSC-certified)
Color	Rustic Brown
Product Dimensions (L x W x H)	55.1" x 15.7" x 19.7" (140 x 40 x 50 cm)
Item Weight	59 lb (26.8 kg)
Overall Max. Static Load Capacity	176 lb (80 kg)
Assembly Required	Yes
Compatible TV Size	Up to 60 inches



Image: Dimensional diagram of the TV stand, including length, width, height, and maximum weight capacity.

WARRANTY INFORMATION

Specific warranty details for the VASAGLE TV Stand ULTV027X01 are not provided in the product information. Please refer to the retailer's or manufacturer's official website for any applicable warranty policies or contact their customer service directly for more information.

CUSTOMER SUPPORT

For further assistance, questions, or to report missing/damaged parts, please contact VASAGLE customer support through their official website or the retailer where the product was purchased. Keep your model number (ULTV027X01) and purchase details ready for faster service.



© 2023 VASAGLE. All rights reserved.