

CHULUX B089LT3FXC

CHULUX Centrifugal Juicer Machine User Manual

Model: B089LT3FXC

1. INTRODUCTION

Thank you for choosing the CHULUX Centrifugal Juicer Machine. This appliance is designed to efficiently extract juice from various fruits and vegetables, providing fresh and nutritious beverages. This manual provides essential information for the safe and effective use, maintenance, and care of your juicer.

The CHULUX juicer features a 500W high-power motor for quick juice extraction, a wide mouth feeding chute to accommodate whole fruits like apples, and dual-speed settings for different produce types. It is constructed from 304 food-grade stainless steel, is BPA-free, and includes safety features such as a locking arm and overheat protection. Many parts are dishwasher safe for easy cleaning.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is switched off and unplugged before assembling, disassembling, or cleaning.
- Always use the food pusher to guide food into the feeding chute. Never use fingers or other utensils.
- Ensure the safety locking arm is securely in place before operating the juicer. The juicer will not operate if the locking arm is not engaged.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is equipped with overheat protection. If the motor overheats, the juicer will automatically shut off. Allow it to cool down before resuming operation.
- Keep hands and utensils out of the feeding chute during operation to prevent injury.
- Do not use attachments not recommended or sold by the manufacturer.

- This appliance is for household use only.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your CHULUX Centrifugal Juicer Machine:

- **Motor Base:** Contains the motor and control dial.
- **Pulp Container:** Collects discarded pulp.
- **Juice Collector/Spout:** Directs extracted juice into the juice cup.
- **Filter Basket:** Stainless steel mesh filter that separates juice from pulp.
- **Feeding Chute:** Wide opening for inserting fruits and vegetables.
- **Food Pusher:** Used to push produce down the feeding chute.
- **Safety Locking Arm:** Secures the juicer components in place for safe operation.
- **Juice Cup:** Collects the fresh juice.



Image: Overview of the CHULUX Centrifugal Juicer Machine with its main components visible.

4. SETUP INSTRUCTIONS

Follow these steps to assemble your juicer before first use:

1. Place the motor base on a stable, flat, and dry surface.
2. Install the juicer outlet onto the motor base.
3. Carefully place the filter basket into the juicer outlet, ensuring it sits firmly.
4. Position the pulp container on the side of the motor base, aligning it with the pulp ejection spout.
5. Install the feeding chute cover onto the juicer outlet, ensuring it clicks into place.
6. Lift the safety locking arm upwards and secure it into the grooves on the feeding chute cover. The juicer will not operate unless this arm is locked.
7. Place the juice cup under the juice spout.

EASY TO USE



1 Install the juicer outlet



2 Place the filter basket



3 Place pulp container



4 Install the feeding chute



5 Lift the protection arm upwards to secure



6 Place the juicer cup under juice spout

Image: A visual guide showing six steps for assembling the juicer, from installing the outlet to securing the safety arm and placing the juice cup.

5. OPERATING INSTRUCTIONS

Before juicing, ensure all components are correctly assembled and the safety locking arm is engaged. Plug the juicer into a grounded electrical outlet.

5.1 Preparing Fruits and Vegetables

- Wash all fruits and vegetables thoroughly.

- For fruits with large seeds or hard pits (e.g., peaches, plums, cherries), remove them before juicing.
- Peel citrus fruits (oranges, lemons, grapefruits) as their peels can impart a bitter taste.
- For produce with a wide mouth, such as whole apples, you may not need to chop them. For smaller or fibrous items, cut them into pieces that fit easily into the feeding chute.

5.2 Juicing Process

1. Turn the control dial to the desired speed setting:
 - **Speed 'I' (Low Speed):** Ideal for soft fruits and vegetables such as oranges, watermelons, strawberries, and kiwi.
 - **Speed 'II' (High Speed):** Suitable for harder produce like apples, carrots, beets, and celery.
2. With the motor running, gradually feed the prepared fruits or vegetables into the feeding chute.
3. Use the food pusher to gently guide the produce down. Do not force the food pusher, as this can strain the motor and reduce juice yield.
4. Fresh juice will flow into the juice cup, and pulp will be collected in the pulp container.
5. Once juicing is complete, turn the control dial to '0' (Off) and unplug the appliance.




Image: Close-up of the juicer's control dial, showing the 'I' (low speed) and 'II' (high speed) settings for different types of produce.

Your browser does not support the video tag.

Video: Demonstrates the CHULUX Centrifugal Juicer Machine in operation, showing how fruits and vegetables are fed into the chute and juice is extracted.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your juicer. Always unplug the appliance before cleaning.

6.1 Disassembly for Cleaning

1. Unlock and lower the safety locking arm.
2. Remove the feeding chute cover.
3. Carefully lift out the filter basket.
4. Remove the pulp container and juice cup.

6.2 Cleaning Instructions

- **Removable Parts:** The feeding chute cover, filter basket, pulp container, juice collector, and food pusher are dishwasher safe. Alternatively, wash them by hand with warm, soapy water and rinse thoroughly.
- **Filter Basket:** Use the included cleaning brush to remove any pulp residue from the fine mesh of the filter basket. This is crucial for efficient juicing.
- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water.
- Dry all parts completely before reassembling or storing.

EASY TO CLEAN

Convenient to take down the filter to clean with attached brush, dishwasher safe.



Image: A hand using a brush to clean the stainless steel filter basket under running water, demonstrating the ease of

cleaning.

7. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; Safety locking arm not engaged; Overheat protection activated.	Ensure the power cord is securely plugged in. Check that the safety locking arm is fully engaged. If the motor is hot, unplug and allow it to cool for 30 minutes before restarting.
Low juice yield or excessive pulp.	Incorrect speed setting; Filter basket clogged; Produce not suitable for juicing.	Use the appropriate speed setting for the produce (Speed I for soft, Speed II for hard). Clean the filter basket thoroughly. Ensure produce is fresh and suitable for centrifugal juicing.
Motor stops during operation.	Overload or overheat protection activated.	Turn off the juicer, unplug it, and remove any blockages. Allow the motor to cool down for at least 30 minutes before resuming. Avoid overfilling the feeding chute or forcing produce.
Loud noise or vibration.	Improper assembly; Juicer not on a stable surface.	Check that all parts are correctly assembled and securely locked. Ensure the juicer is placed on a firm, level surface.

8. SPECIFICATIONS

- **Brand:** CHULUX
- **Model:** B089LT3FXC
- **Color:** Silver
- **Material:** Stainless Steel (304 food grade)
- **Maximum Power:** 500 Watts
- **Voltage:** 120 Volts
- **Number of Speeds:** 2 (Low 'I', High 'II')
- **Special Features:** BPA Free, Overheat Protection, Powerful Motor, Wide Mouth Feeding Chute
- **Product Care Instructions:** Dishwasher Safe (removable parts)
- **Item Weight:** 6.5 pounds
- **Package Dimensions:** 13.62 x 11.93 x 7.76 inches
- **Certifications:** ETL certified

9. WARRANTY AND SUPPORT

The CHULUX Centrifugal Juicer Machine comes with an ETL certificate, ensuring it meets recognized safety standards. CHULUX is committed to customer satisfaction.

If you have any questions, concerns, or require support regarding your juicer, please contact our customer service team. We aim to provide a satisfactory response within 24 hours.

For assistance, please refer to the contact information provided with your product packaging or visit the

official CHULUX website.