

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BENEWY](#) /

> [BENEWY 1080P Full HD Webcam User Manual](#)

BENEWY PC-W1

BENEWY 1080P Full HD Webcam User Manual

Brand: BENEWY

Model: PC-W1

PRODUCT OVERVIEW AND FEATURES

The BENEWY 1080P Full HD Webcam is designed for high-quality video communication, streaming, and recording. It features advanced video processing technology to deliver crisp, clear images at 30 frames per second, ensuring smooth video for various applications such as video chats, conferences, and webinars.

- **Full HD 1080P Resolution:** Captures sharp and clear visuals for an enhanced video experience.
- **Built-in Dual-Track Microphone:** Equipped with noise reduction technology to record clear audio from up to 8 meters away, suitable for online conferences, meetings, or chats.
- **Plug and Play (Drive-Free):** Simple USB 2.0 connectivity allows for immediate use without installing additional drivers.
- **Adjustable Clip and Tripod:** Features a versatile clip for mounting on monitors, laptop covers, or flat surfaces, and includes a tripod for flexible placement.
- **Ultra-Wide Compatibility:** Compatible with a broad range of operating systems including Windows (10/8/7/XP 2), Mac OS (10.6 or beyond), Android (5.0 or beyond), Chrome OS, Xbox One, and Ubuntu 10.04 or beyond.



Image: The BENEWEY 1080P Full HD Webcam shown with its adjustable clip and a small tripod.



Image: A diagram highlighting key features of the webcam, including 1080P HD video, 360-degree rotation, built-in microphone, and USB 2.0 plug-and-play functionality.

PACKAGE CONTENTS

Please verify that all items are present in the package before proceeding with setup.

- BENEWEY 1080P Full HD Webcam
- USB Cable (integrated)
- Webcam Bracket (integrated adjustable clip)
- Webcam Privacy Cover
- Tripod



Image: The front of the BENEWEY HD Webcam product box, showing the webcam and model number PC-W1.

SETUP INSTRUCTIONS

The BENEWEY webcam is designed for easy plug-and-play installation. Follow these steps to set up your webcam:

1. Choose Placement:

Decide where to place your webcam. The adjustable clip allows for versatile mounting options:

- **On a Monitor/Laptop Screen:** Open the clip and place it securely on top of your screen, ensuring the front part of the clip rests on the screen and the back part supports it from behind.
- **On a Flat Surface:** Fold the clip to form a stable base and place the webcam on a desk or table.
- **On the Tripod:** Screw the webcam onto the included tripod for more flexible positioning on any flat surface.

Universal Clip

Well compatible with Windows, Mac OS and Android etc




Image: The webcam securely clipped onto the top edge of a computer monitor.

Multifunctional base

It can be placed on the desktop and clamped on the top of the screen



Flat on the table



Clip above screen

Image: Illustrations demonstrating the webcam's multifunctional base, allowing it to be placed flat on a table or clipped onto the top of a screen.

2. Connect to Computer:

Plug the USB cable of the webcam into an available USB 2.0 port on your PC, laptop, desktop, or Android TV.

3. Automatic Installation:

The webcam is plug-and-play. Your operating system should automatically detect and install the necessary drivers.

This may take a few moments. No additional software installation is typically required.

4. **Verify Installation:**

Once installed, you can verify its functionality by opening a video conferencing application (e.g., Zoom, Skype, Microsoft Teams) or your computer's camera application. Select the BENEWY webcam as your video and audio input device.

OPERATING INSTRUCTIONS

Using your BENEWY webcam for various applications is straightforward:

1. **Starting a Video Call/Meeting:**

Open your preferred video communication software (e.g., Zoom, Skype, Google Meet, Microsoft Teams). In the settings of the application, select "BENEWY Webcam" as your video device and "BENEWY Microphone" (or similar) as your audio input device.

2. **Adjusting Camera Angle:**

The webcam features a 360-degree rotating base and an adjustable vertical tilt. Gently pivot the camera head to achieve your desired viewing angle.

3. **Using the Privacy Cover:**

When the webcam is not in use, slide the integrated privacy cover over the lens to ensure your privacy and protect the lens from dust.

4. **Microphone Usage:**

The built-in dual-track microphone with noise reduction will automatically capture your voice. Ensure your application's audio settings are configured to use the webcam's microphone for optimal sound quality.

5. **Compatibility:**

The webcam is broadly compatible with various platforms and operating systems. This includes Windows, Mac OS, Android, Chrome OS, and Linux distributions, as well as popular applications like Zoom, Skype, OBS, YouTube, Twitch, and more.



Image: A visual representation of the webcam's wide compatibility with different operating systems (Mac OS, Linux, Windows, Android, Xbox One) and popular communication/streaming platforms.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your BENEWEY webcam:

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optics to gently wipe the webcam lens. Avoid using abrasive materials or harsh chemical cleaners, which can scratch or damage the lens.
- **Cleaning the Body:** Wipe the body of the webcam with a soft, slightly damp cloth. Ensure no moisture enters the USB port or microphone openings.
- **Using the Privacy Cover:** Always use the integrated privacy cover when the webcam is not in use. This protects the lens from dust, scratches, and accidental smudges.
- **Storage:** When not in use for extended periods, store the webcam in a clean, dry place, away from extreme temperatures and direct sunlight.
- **Cable Care:** Avoid bending or crimping the USB cable excessively. Do not pull the cable to disconnect the webcam; always grasp the USB connector.

TROUBLESHOOTING

If you encounter issues with your BENEWEY webcam, try the following troubleshooting steps:

- **Webcam Not Detected:**
 - Ensure the USB cable is securely plugged into a working USB port. Try a different USB port.
 - Restart your computer.
 - Check your computer's Device Manager (Windows) or System Information (Mac) to see if the webcam is listed.
- **No Video Output:**
 - Make sure the privacy cover is not blocking the lens.
 - In your video application's settings, confirm that the BENEWEY webcam is selected as the video input device.
 - Check if other applications are currently using the webcam, which might prevent your desired application from accessing it.
- **No Audio Input (Microphone):**
 - In your application's audio settings, ensure the BENEWEY microphone is selected as the audio input device.
 - Check your system's sound settings to ensure the microphone is enabled and not muted.
 - Ensure there are no physical obstructions blocking the microphone openings on the webcam.
- **Poor Video Quality:**
 - Ensure you have adequate lighting in your environment.
 - Check your internet connection speed if streaming or in a video call, as bandwidth can affect quality.
 - Clean the webcam lens as described in the Maintenance section.

If these steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

SPECIFICATIONS

Brand	BENEWEY
Model Number	PC-W1
Product Dimensions	13 x 7 x 6.5 cm
Item Weight	20 g
Colour	Black
Form Factor	Portable
Resolution	1080p Full HD (Video Capture Resolution)
Rear Webcam Resolution	2 MP
Photo Sensor Technology	CMOS
Connectivity Technology	USB 2.0
Number of USB 2.0 Ports	1

Number of Microphone Ports	2 (Dual-track microphone)
Operating System Compatibility	Linux, Windows (10/8/7/XP 2), iOS (Mac OS 10.6+), Android (5.0+), Chrome OS, Xbox One, Ubuntu 10.04+
Are Batteries Included	No
Video Capture Format	AVI
Supported Audio Format	MP4, AAC, WMA



Image: Detailed dimensions of the webcam, including length, width, and height.

WARRANTY AND SUPPORT

Specific warranty terms and conditions are not provided within this manual. For detailed warranty information, product

support, or technical assistance, please contact BENEWY customer service through the retailer where you purchased the product or refer to the contact information provided on the product packaging.

General support inquiries can often be directed to the manufacturer's official support channels, which may be found on their website or through the contact details provided on the product's retail page.

UK	REP
----	-----

GOAL REACH CONSULTING LTD

OFFICE 1029 3 HARDMAN STREET 10TH FLOOR,
SPINNINGFIELDS MANCHESTER, UK M3 3HF
goalservice@hotmail.com

EU	REP
----	-----

SUCCESS COURIER SL

Calle de RIO TORMES 13A, oficina 1,
Fuenlabrada, Madrid, 28947 Spain
successservice2@hotmail.com



BENEWY

Model No: PC-W1



MADE IN CHINA

Image: The back of the product box, which includes contact information for UK and EU representatives (e.g., goalservice@hotmail.com, succeservice2@hotmail.com).

