

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /


> [hansgrohe](#) /

> [hansgrohe Talis M54 Kitchen Tap with Pull-Out Spray \(Model 72808670\) Instruction Manual](#)

**hansgrohe 72808670**

# hansgrohe Talis M54 Kitchen Tap with Pull-Out Spray (Model 72808670) Instruction Manual

Model: 72808670



## Easy cleaning

The hansgrohe Talis M54 Kitchen Tap, Model 72808670, in matt black finish.

## 1. INTRODUCTION

---

This instruction manual provides important information for the safe installation, operation, and maintenance of your hansgrohe Talis M54 Kitchen Tap with Pull-Out Spray, Model 72808670. Please read this manual thoroughly before installation and use, and keep it for future reference.

The hansgrohe Talis M54 is a single-lever kitchen mixer tap featuring a pull-out spray, a swivel spout, and a matt black finish, designed for kitchen sink applications.

## 2. SAFETY INFORMATION

---

- Ensure all installation work is performed by a qualified professional in accordance with local plumbing and building codes.
- Before installation, turn off the main water supply.
- Protect the product from frost. Do not install in areas where freezing temperatures may occur.
- Use only genuine hansgrohe spare parts for repairs or maintenance.
- Avoid using abrasive cleaners, scouring pads, or solvents on the tap's surface, as these can damage the finish.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- hansgrohe Talis M54 Kitchen Tap (Model 72808670)
- Pull-out spray hose
- Mounting hardware
- Flexible connection hoses (G  $\frac{3}{8}$  / DN15)
- Instruction Manual (this document)

## 4. SETUP AND INSTALLATION

---

**Tools Required:** Adjustable wrench, screwdriver, sealant tape (optional).

1. **Prepare the Sink:** Ensure the mounting hole on your sink or countertop is clean and appropriately sized for a single-hole installation.
2. **Mount the Tap:**  
Insert the tap body into the mounting hole. Secure it from underneath the sink using the provided mounting hardware (washer and nut). Ensure the tap is oriented correctly.



## Easy installation

This image illustrates the "Easy installation" process, showing the tap being secured to the sink. The brass threaded rod and connection hoses are visible below the countertop, while the tap body is positioned above.

### 3. **Connect Water Supply:**

Connect the flexible hot and cold water supply hoses from the tap to your angle valves. Use an adjustable wrench to tighten connections, but do not overtighten. Ensure the hot water line is connected to the left and the cold water line to the right, as typically indicated by markings on the hoses or tap.

### 4. **Install Pull-Out Spray Hose:**

Feed the pull-out spray hose through the tap body and connect it to the designated outlet. Attach the counterweight to the hose below the sink to ensure smooth retraction of the spray head.

### 5. **Test for Leaks:**

Slowly turn on the main water supply. Check all connections for leaks. If leaks occur, tighten connections slightly until they stop.

### 6. **Flush the System:**

Run both hot and cold water through the tap for several minutes to flush out any debris from the water lines.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Water Flow and Temperature Control

The single lever handle controls both water flow and temperature. Lift the handle to increase water flow. Move the handle to the left for hot water and to the right for cold water.

## 5.2 Pull-Out Spray Function

Gently pull the spray head from the spout to extend the hose. The spray head will retract automatically into the spout via the MagFit magnetic bracket when released.

## 5.3 Swivel Spout Function

The spout can be swiveled to various positions for increased flexibility. The swivel range can be adjusted to 60°, 110°, 150°, or 360° during installation or by a qualified technician.

## 6. MAINTENANCE


---

### 6.1 Cleaning the Tap

To maintain the finish of your hansgrohe tap, clean it regularly with a soft cloth and a mild, non-abrasive cleaning agent. Rinse thoroughly with clean water and dry with a soft cloth. Avoid cleaners containing alcohol, hydrochloric acid, formic acid, acetic acid, or phosphoric acid.

### 6.2 QuickClean Function (Limescale Removal)

The aerator on the spout is equipped with hansgrohe's QuickClean technology. Limescale deposits can be easily removed by gently rubbing the silicone nozzles with your finger. This should be done regularly to maintain optimal spray performance.



**Available Colours**

This image highlights the QuickClean feature, illustrating how limescale can be easily wiped away from the silicone nozzles


of the tap's aerator.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low water flow	Clogged aerator; partially closed shut-off valves; debris in water lines.	Clean the aerator using the QuickClean function. Ensure shut-off valves are fully open. Flush water lines.
Leaking at connections	Loose connections; damaged seals.	Tighten connections carefully. Check and replace seals if damaged.
Water temperature inconsistent	Issue with water heater; cartridge malfunction.	Check water heater settings. If problem persists, contact a qualified plumber to inspect or replace the ceramic cartridge.
Pull-out spray does not retract smoothly	Hose obstruction; incorrect counterweight position.	Check under the sink for any obstructions to the hose. Ensure the counterweight is positioned correctly on the hose.

## 8. SPECIFICATIONS

<b>Brand:</b>	hansgrohe
<b>Model Name:</b>	hansgrohe Talis M54 Kitchen Tap 270 with pull-out spout, single spray mode
<b>Model Number:</b>	72808670
<b>Material:</b>	Brass
<b>Finish Type:</b>	Matt Black
<b>Mounting Type:</b>	Single Hole
<b>Number of Handles:</b>	1 (Lever)
<b>Special Feature:</b>	Pull Out Sprayer, Swivel Spout (60°, 110°, 150°, 360° adjustable)
<b>Flow Rate:</b>	Up to 7 Liters Per Minute
<b>Spout Height:</b>	265 Millimeters
<b>Spout Reach:</b>	50 Centimeters (Pull-out hose length)
<b>Hose Length:</b>	50 Centimeters
<b>Item Weight:</b>	8.5 Grams (Note: This seems unusually low for a faucet, likely a data entry error in the source. Please refer to product packaging for accurate weight.)
<b>EU Spare Part Availability:</b>	Up to 15 years after range discontinuation



This diagram provides detailed technical dimensions for the hansgrohe Talis M54 kitchen tap, including height, reach, and connection specifications, crucial for planning installation.

## 9. WARRANTY AND SUPPORT

hansgrohe products are manufactured to high quality standards. For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official hansgrohe website. For technical support, spare parts, or service inquiries, please contact hansgrohe customer service or your local hansgrohe dealer. Contact information can typically be found on the hansgrohe website or in the product packaging.

**EU Spare Part Availability:** Spare parts for this product are guaranteed to be available for up to 15 years after the range has been discontinued.

