Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Logitech 910-005899

Logitech MX Anywhere 3 for Mac User Manual

Model: 910-005899

Introduction What's in the Box Features Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The Logitech MX Anywhere 3 for Mac is a compact performance mouse designed for seamless use with Apple MacBook Pro, MacBook Air, iMac, and iPad models. It offers advanced features for enhanced productivity and comfort, whether you are working from a home office, a cafe, or on the go.

This manual provides detailed instructions on setting up, operating, maintaining, and troubleshooting your MX Anywhere 3 for Mac mouse.



Figure 1: Logitech MX Anywhere 3 for Mac Mouse (Pale Grey)
This image shows the Logitech MX Anywhere 3 for Mac mouse in its pale grey finish, highlighting its compact and ergonomic design.

2. What's in the Box

Verify that all items are present in the product packaging:

- MX Anywhere 3 For Mac Mouse
- USB-C to USB-C Charging Cable (1 meter length)
- User Documentation



Figure 2: Package Contents
This image displays the Logitech MX Anywhere 3 for Mac mouse alongside its included USB-C to USB-C charging cable and user documentation, illustrating the complete package contents.

3. Key Features

- **MagSpeed Scrolling:** The electromagnetic scroll wheel provides ultrafast, precise, and quiet scrolling. It can scroll 1,000 lines per second and automatically shifts between ratchet (precise) and hyper-fast (free-spinning) modes.
- **Go-Anywhere Comfort:** Designed with a low-profile contour that fits comfortably in your hand, featuring ultra-soft silicone side grips for enhanced tactile feel and durability against mobile work bumps and drops.
- **Track Anywhere Sensor:** Equipped with a 4000 DPI sensor that allows tracking on virtually any surface, including glass (minimum 4mm thickness).

- **USB-C Quick Charging:** A full charge provides up to 70 days of power. A 1-minute quick charge can provide 3 hours of use. Charging is done via the included USB-C to USB-C cable.
- **Mastered for Mac:** Optimized for macOS and iPadOS, allowing seamless connectivity and performance with Apple devices.
- **Multi-Device Connectivity:** Connects to up to three devices and allows switching between them with a tap of a button.
- **Customizable Buttons:** App-specific button customizations and predefined profiles are available for popular applications such as Adobe Photoshop, Adobe Premiere Pro, Final Cut Pro, Google Chrome, Safari, Microsoft Word, Excel, and PowerPoint.
- **Modern Design:** Features a steel scroll wheel and grippy silicon side grips in a Pale Grey finish.
- **Logitech Flow Enabled:** Control multiple computers (across Windows and macOS) and effortlessly transfer text, images, and files between them.



Figure 3: Mouse Features Diagram

This diagram labels key features of the MX Anywhere 3 for Mac, including the MagSpeed wheel, customizable buttons, USB-C charging port, track-anywhere sensor, Easy-Switch buttons, and silicon side grips, along with its dimensions.

4. Setup Guide

4.1 Initial Charge

Before first use, it is recommended to fully charge your MX Anywhere 3 for Mac mouse. Connect the included USB-C to USB-C charging cable from the mouse's front port to a USB-C port on your Mac or a compatible power adapter.



Figure 4: USB-C Charging
This image illustrates the Logitech MX Anywhere 3 for Mac mouse being charged via its USB-C port, emphasizing the quick charging capability and long battery life.

4.2 Connecting to Your Mac or iPad

The MX Anywhere 3 for Mac can connect via Bluetooth Low Energy.

1. Turn on the mouse using the power switch on the bottom.
2. Press and hold one of the Easy-Switch buttons (1, 2, or 3) on the bottom of the mouse for three seconds until the LED light next to the number starts blinking rapidly. This indicates the mouse is in pairing mode.

3. On your Mac:
    - Go to **System Settings** (or **System Preferences**) > **Bluetooth**.
    - Select "MX Anywhere 3 for Mac" from the list of available devices and click **Connect**.
4. On your iPad:
    - Go to **Settings** > **Bluetooth**.
    - Select "MX Anywhere 3 for Mac" from the list of available devices.
5. Once connected, the LED light on the mouse will glow solid for 5 seconds.

You can pair up to three devices and switch between them by pressing the corresponding Easy-Switch button on the bottom of the mouse.

5. Operating Your Mouse

5.1 MagSpeed Scroll Wheel

The MagSpeed scroll wheel offers two modes:

- **Ratcheted Mode:** Provides precise, line-by-line scrolling, ideal for navigating lists or detailed documents.
- **Hyper-Fast Mode:** Automatically engages when you spin the wheel quickly, allowing you to scroll through thousands of lines in seconds. This mode is ideal for long web pages or large spreadsheets.



Figure 5: MagSpeed Scrolling in Action
This image shows a hand operating the Logitech MX Anywhere 3 for Mac mouse, emphasizing the smooth and rapid scrolling capability of the MagSpeed wheel.

5.2 Customizable Buttons

The MX Anywhere 3 for Mac features customizable buttons that can be configured for specific functions or application-specific shortcuts. To customize buttons, download and install the Logitech Options software from the official Logitech website (www.logitech.com/software/logi-options-plus.html).
With Logitech Options, you can:

- Assign custom actions to the side buttons and the middle button.
- Enable application-specific settings for popular software like Adobe Photoshop, Microsoft Office, and web browsers.
- Adjust pointer speed and scroll direction.



Figure 6: Logitech Options Software
This image displays the Logitech Options software interface on a Mac screen, demonstrating how users can customize the mouse buttons and settings for enhanced workflow.

5.3 Tracking on Any Surface

The advanced 4000 DPI Darkfield sensor allows the MX Anywhere 3 for Mac to track accurately on virtually any surface, including glass, wood, and fabric. This eliminates the need for a mouse pad in most environments.



Figure 7: Tracking on Glass
This image shows the Logitech MX Anywhere 3 for Mac mouse positioned on a clear glass surface, illustrating its ability to track accurately on various materials, including glass.

5.4 Logitech Flow

If you use multiple computers (Mac or Windows), Logitech Flow allows you to seamlessly move your mouse cursor across screens and even copy-paste text, images, and files between them. This feature requires the Logitech Options software to be installed on all connected computers.

6. Maintenance

6.1 Cleaning

To clean your MX Anywhere 3 for Mac mouse:

- Use a soft, lint-free cloth slightly dampened with water or an alcohol-based cleaner.

- Avoid using abrasive cleaners, solvents, or aerosol sprays directly on the mouse.
- Ensure no liquid enters the openings.

6.2 Battery Care

The mouse uses a rechargeable Lithium Polymer battery. To maximize battery life:

- Avoid exposing the mouse to extreme temperatures.
- Charge the mouse regularly, but it is not necessary to fully discharge it before recharging.
- If storing the mouse for an extended period, charge it to about 50% before storage.

7. Troubleshooting

Problem	Possible Solution
Mouse not connecting via Bluetooth.	◦ Ensure the mouse is turned on and fully charged. ◦ Press and hold an Easy-Switch button until the LED blinks rapidly to enter pairing mode. ◦ On your Mac/iPad, turn Bluetooth off and then on again. ◦ Remove "MX Anywhere 3 for Mac" from your device's Bluetooth list and try pairing again. ◦ Restart your Mac/iPad.
Mouse cursor is erratic or not tracking.	◦ Ensure the optical sensor on the bottom of the mouse is clean and free of debris. ◦ Try using the mouse on a different surface. ◦ Check battery level and charge if low.
MagSpeed scroll wheel not switching modes.	◦ Ensure Logitech Options software is installed and up to date. ◦ Check the scroll wheel settings within Logitech Options.
Battery life is shorter than expected.	◦ Ensure the mouse is fully charged before use. ◦ Avoid extreme temperatures. ◦ If the issue persists, contact Logitech support.

8. Specifications

Feature	Detail
Model Number	910-005899
Connectivity	Bluetooth Low Energy, USB-C (for charging)
Sensor Technology	Darkfield High Precision (Optical)
DPI Range	200 to 4000 dpi (adjustable in 50 dpi increments)
Buttons	6 buttons (Left/Right-click, Back/Forward, Wheel mode-shift, Middle click)
Scroll Wheel	MagSpeed Electromagnetic scrolling
Battery Type	Rechargeable Li-Po (500 mAh)

Feature	Detail
Battery Life	Up to 70 days on a single full charge (depending on usage)
Dimensions (LxWxH)	100.5 mm x 65 mm x 34.4 mm (3.96 in x 2.56 in x 1.35 in)
Weight	99 g (3.49 oz)
Operating System Compatibility	macOS 10.15 or later, iPadOS 13.4 or later, Android
Color	Pale Grey

9. Warranty and Support

9.1 Limited Hardware Warranty

Logitech warrants that your hardware product shall be free from defects in material and workmanship for the length of time stated on your product package and/or at Logitech's official website, beginning from the date of the original retail purchase. This warranty does not cover problems or damage resulting from (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech.
For specific warranty terms and conditions, please refer to the official Logitech website or the documentation included with your product.

9.2 Customer Support

For technical support, troubleshooting assistance, or to access additional resources, please visit the official Logitech support website:

support.logi.com

The support website offers FAQs, troubleshooting guides, software downloads, and contact information for Logitech customer service.

© 2025 Logitech. All rights reserved. Logitech, Logi, and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089N5L1YQ

More documents and user manuals: **https://manuals.plus/**