

[Manuals.plus](#) /

> [VASAGLE](#) /

> VASAGLE TV Cabinet with 2 Doors, Adjustable Shelves, 140 cm Length, for 65-inch TVs, Rustic Brown LTV027X01 Instruction Manual

VASAGLE LTV027X01

VASAGLE TV Cabinet Instruction Manual

Model: LTV027X01

Brand: VASAGLE

INTRODUCTION

Thank you for choosing the VASAGLE LTV027X01 TV Cabinet. This manual provides detailed instructions for assembly, operation, and maintenance of your new furniture. Please read this manual carefully before beginning assembly and keep it for future reference.

This rustic brown TV cabinet is designed to accommodate televisions up to 65 inches, offering ample storage with two open compartments and two cabinets with doors. Its sturdy construction and adjustable shelves make it a versatile addition to your living room, bedroom, or dining area.

IMPORTANT SAFETY INSTRUCTIONS

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Contact customer support if any parts are missing or defective.
- Do not overtighten screws during assembly, as this may damage the material.
- For safety, it is recommended that two people assemble this TV cabinet.
- Do not exceed the maximum weight capacity of 80 kg (176 lbs) on the top surface.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Secure the TV cabinet to the wall using anti-tip hardware (if included) to prevent accidental tipping, especially in households with children.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- 1 x VASAGLE TV Cabinet (disassembled parts)
- 1 x Assembly Kit (hardware, screws, tools if applicable)

- 1 x Instruction Manual (FR, DE, EN, ES, IT)

If any parts are missing or damaged, please contact VASAGLE customer service for assistance.

ASSEMBLY INSTRUCTIONS

Follow the numbered steps and diagrams carefully for proper assembly. All parts are labeled with letters and hardware with numbers for easy identification.

Step 1: Unpack and Identify Parts

Carefully unpack all components and lay them out on a clean, soft surface. Identify each part by its corresponding letter and all hardware by its number as per the included parts list.



Image: Overview of the TV cabinet, showing its rustic brown finish and design.

Step 2: Attach Legs

Attach the four tapered legs to the bottom panel of the TV cabinet using the provided screws. Ensure they are securely fastened but do not overtighten.



Image: Detail of the sturdy, angled legs with protective pads.

Step 3: Assemble Main Frame

Connect the side panels, back panel, and top panel to form the main frame of the TV cabinet. Use the designated screws and dowels as indicated in the manual. Ensure all connections are flush and stable.



Image: The durable top surface of the cabinet, suitable for placing a television and decor.

Step 4: Install Shelves and Doors

Insert the adjustable shelves into the desired positions within the open compartments. The shelves can be moved up or down by 3.2 cm (1.26 inches) to accommodate various items. Attach the doors to the cabinet using the provided hinges. Ensure the doors open and close smoothly.



Image: The adjustable shelves provide flexible storage options for media devices and other items.



Image: The cabinet doors conceal storage, helping to keep your living space tidy.

Step 5: Final Checks

Once assembled, gently lift and move the cabinet to its desired location. Ensure it is stable and level. Re-check all screws and connections to confirm they are tight and secure.

80 kg



Image: Dimensions of the TV cabinet (140 x 40 x 50 cm) and its robust 80 kg weight capacity.

OPERATING INSTRUCTIONS

Placement of Television

Place your television centrally on the top surface of the cabinet. Ensure the TV's base fits within the cabinet's dimensions (140 cm length, 40 cm depth). The cabinet is designed to support TVs up to 65 inches and a maximum weight of 80 kg.



Image: The TV cabinet seamlessly integrates into a modern living room, providing a stable platform for your television.

Storage and Organization

Utilize the two open shelves for media devices such as DVD players, gaming consoles, or soundbars. The two cabinets with doors provide concealed storage for DVDs, remote controls, or other accessories, helping to maintain a clutter-free environment.



Image: The TV cabinet offers practical storage solutions, keeping your entertainment area organized.

Cable Management

The back panel features cut-outs for cable management, allowing you to neatly route power cords and AV cables, keeping them out of sight and preventing tangles.



Image: Integrated cable management holes for a tidy setup.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Stability:** Periodically check all screws and connections to ensure they remain tight and the cabinet is stable. Re-tighten if necessary.

TROUBLESHOOTING

Cabinet is Wobbly/Unstable

- **Solution:** Ensure all screws are fully tightened. Check that the cabinet is placed on a level surface. If your floor is uneven, you may use shims under the legs to stabilize it.

Doors Do Not Align Properly

- **Solution:** Adjust the hinges on the doors. Most hinges allow for minor adjustments to align the doors vertically, horizontally, and in depth. Refer to the hinge manufacturer's instructions if needed.

Missing or Damaged Parts

- **Solution:** Do not attempt to assemble the product with missing or damaged parts. Contact VASAGLE customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Specification
Brand	VASAGLE
Model Number	LTV027X01
Color	Rustic Brown
Material	Engineered Wood
Style	Rustic
Item Dimensions (L x W x H)	140 x 40 x 50 cm (55.1 x 15.7 x 19.7 inches)
Item Weight	26.8 Kilograms (59.1 lbs)
Maximum Weight Capacity	80 Kilograms (176 lbs)
Product Compatibility	Television (up to 65 inches)

Feature	Specification
Assembly Required	Yes
Care Instructions	Wipe with a dry cloth
UPC	194343107127

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official VASAGLE website. Warranty terms and conditions may vary by region.

If you encounter any issues with your VASAGLE TV Cabinet, require replacement parts, or have questions not covered in this manual, please contact VASAGLE customer support. Contact details can typically be found on the brand's official website or on your purchase receipt.

We are committed to providing high-quality products and support to ensure your satisfaction.
