

MIFA A10P-A

MIFA A10Plus Portable Bluetooth Speaker User Manual

Model: A10P-A

1. GETTING STARTED

1.1. What's in the Box

Verify that all components are included in your package:

- A10 Plus Bluetooth Speaker
- USB-C Cable
- 3.5mm Jack Audio Cable
- Instruction Manual



Image: Contents of the MIFA A10Plus speaker box.

1.2. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The speaker has a built-in 2200 mAh rechargeable Lithium battery, offering up to 20 hours of playtime and recharging in approximately 3 hours.

The LED indicator lights will show the charging status. A red light typically indicates low battery, while a green light indicates a full charge.



Image: Charging and input ports of the MIFA A10Plus speaker.

2. OPERATING YOUR MIFA A10PLUS SPEAKER

2.1. Power On/Off

To power on the speaker, press and hold the Power button for 2 seconds. The speaker will emit an audible prompt and the LED indicators will light up. To power off, press and hold the Power button again for 2 seconds.

2.2. Bluetooth Pairing

The MIFA A10Plus uses Bluetooth 5.0 for stable and efficient wireless connection.

1. Turn on the speaker. The Bluetooth indicator light will begin blinking, indicating it is in pairing mode.
2. On your smartphone or audio device, enable Bluetooth and search for available devices.
3. Select "MIFA A10Plus" from the list of devices.
4. Once connected, the speaker will emit a confirmation sound, and the Bluetooth indicator light will become solid.

TRUE WIRELESS STEREO

Pairing 2 speakers simultaneously



Image: MIFA A10Plus speaker demonstrating Bluetooth 5.0 connectivity.

2.3. Audio Playback Modes

The speaker supports multiple audio input options:

- **Bluetooth 5.0:** Wireless connection to compatible devices.
- **Micro-SD Card:** Insert a Micro SD card with audio files into the designated slot.
- **USB Flash Drive:** Insert a USB flash drive with audio files into the USB port.
- **AUX:** Connect an audio device using the provided 3.5mm AUX cable.

FOUR OPTIONAL MODES



Bluetooth 5.0



Micro-SD Card



USB Flash Drive



AUX



Image: MIFA A10Plus speaker with multiple input options.

2.4. Controls

The top panel of the speaker features several control buttons:

- **Volume Up / Next:** Short press for volume up, long press for next track.
- **Volume Down / Previous:** Short press for volume down, long press for previous track.
- **Play / Pause:** Press to play or pause audio.
- **Single Loop:** Use this button to repeat your favorite songs when playing from a Micro SD card or USB flash drive.
- **Power / Mode:** Press and hold to power on/off. Short press to switch between input modes (Bluetooth, Micro SD, USB, AUX).
- **Built-in Microphone:** For hands-free calling when connected via Bluetooth.



Image: Control layout of the MIFA A10Plus speaker.

2.5. True Wireless Stereo (TWS) Pairing

You can pair two MIFA A10Plus speakers together for a true wireless stereo sound experience.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS pairing button (refer to the speaker's specific button layout if not explicitly labeled).
3. The primary speaker will search for the secondary speaker. Once connected, both speakers will emit a confirmation sound.
4. Now, connect your audio device to the primary speaker via Bluetooth. Audio will play through both speakers in stereo.



Image: Two MIFA A10Plus speakers paired for True Wireless Stereo.

2.6. Operational Video Guide

For a visual guide on basic operations including unboxing, power on/off, Bluetooth pairing, button functions, battery check, and multi-speaker pairing, please refer to the video below. Note: The specific model shown in the video may vary, but the operational steps are generally applicable to MIFA portable speakers.

Video: General operational guide for MIFA portable speakers. (Note: Model shown may differ from A10Plus)

3. CARE AND MAINTENANCE

3.1. Waterproofing

The MIFA A10Plus speaker is IPX6-rated, meaning it is protected against powerful water jets. This makes it suitable for use in environments where it might be exposed to splashes or rain, such as by the pool or in the kitchen. However, it is not designed for submersion in water.

OUTDOOR-PROOF

IPX6-Rated Protection



Image: MIFA A10Plus speaker demonstrating IPX6 water resistance.

3.2. Cleaning

To clean the speaker, use a soft, damp cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the surface or internal components. Ensure all port covers are securely closed before cleaning with a damp cloth.

3.3. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the speaker before storing it for a long time to maintain battery health.

4. TROUBLESHOOTING

If you encounter issues with your MIFA A10Plus speaker, refer to the following common problems and solutions:

- **Speaker does not turn on:**

Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable and try again.

- **Cannot pair via Bluetooth:**

Make sure the speaker is in pairing mode (blinking Bluetooth indicator). Ensure Bluetooth is enabled on your device and it is within range (up to 10 meters). Try turning both the speaker and your device's Bluetooth off and on again. Clear previous Bluetooth connections on your device if necessary.

- **No sound:**

Check the volume level on both the speaker and your connected device. Ensure the correct input mode is selected (Bluetooth, Micro SD, USB, AUX). If using AUX, ensure the cable is fully inserted and functional.

- **Poor sound quality:**

Move the speaker closer to your Bluetooth device to reduce interference. Check for obstacles between the speaker and the device. Ensure the audio source file is of good quality.

- **USB flash drive/Micro SD card not recognized:**

Ensure the storage device is formatted correctly (FAT32 is generally recommended) and contains compatible audio files (MP3, FLAC, WAV, WMA, APE). Try reinserting the card/drive or using a different one.

5. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	A10 Plus
Item Model Number	A10P-A
Brand	MIFA
Speaker Type	Subwoofer
Speaker Maximum Output Power	20 Watts
Audio Output Mode	Stereo
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.0
Connectivity Technology	Bluetooth, Auxiliary, USB
Water Resistance Level	IPX6 Waterproof
Battery Life	20 Hours
Battery Capacity	2200 Millamp Hours
Charging Time	3 Hours
Power Source	Battery Powered
Item Weight	1.6 pounds
Package Dimensions	8.1 x 4.1 x 3 inches
Included Components	A10 Plus Bluetooth Speaker, USB-C Cable, 3.5mm Jack Audio Cable, Instruction Manual

Feature	Specification
Manufacturer	MIFA INNOVATIONS LLC

6. WARRANTY AND SUPPORT

6.1. Warranty Information

The MIFA A10Plus Portable Bluetooth Speaker comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage period and limitations.

6.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact MIFA customer support through the official channels provided in your product documentation or on the MIFA website. When contacting support, please have your product model number (A10P-A) and purchase information ready.