Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jura 15358

Jura S8 Automatic Coffee and Espresso Machine

User Manual

Model: 15358 | Brand: Jura

1. Introduction

Welcome to the world of premium coffee with your new Jura S8 Automatic Coffee and Espresso Machine. This manual provides essential information for setting up, operating, and maintaining your machine to ensure you enjoy perfect coffee specialties for years to come. The Jura S8 combines elegant design with advanced technology, offering a wide range of beverages at the touch of a button.



Figure 1: The Jura S8 Automatic Coffee and Espresso Machine in Piano Black, showcasing its sleek design and a prepared latte macchiato.

2. Key Features

- **15 Different Specialties:** Create a full range of beverages from espresso to latte macchiato.
- **Pulse Extraction Process (PEP):** Ensures optimal extraction time for short specialties, delivering intense flavor.
- **4.3-Inch Color Touchscreen Display:** Provides intuitive operation and guides you through preparation steps.
- **Professional Fine Foam Frother:** Produces the very best fine-textured milk foam for milk-based coffee drinks.
- **Premium Design:** Combines compact class elements with premium segment features for a sophisticated look.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials. Ensure all components are present.

2. **Water Tank:** Fill the water tank with fresh, cold water. The tank is located on the side of the machine and may feature an illuminated chamber.
3. **Water Filter Installation:** Insert the provided CLARIS Smart water filter into the water tank. The machine uses RFID technology to detect the filter. Follow the on-screen prompts for activation.
4. **Bean Container:** Open the aroma preservation cover on top of the machine and fill the bean container with fresh coffee beans.
5. **Initial Cleaning Cycle:** Upon first startup or after prolonged inactivity, the machine will prompt an automatic cleaning cycle. Place a container under the coffee spout to collect the water.

4. Operating the Machine

4.1. Touchscreen Interface

The Jura S8 features an intuitive 4.3-inch high-resolution color touchscreen display. Navigate through menus and select your desired beverages with a gentle touch.



Figure 2: Interacting with the Jura S8's touchscreen to select a beverage.

4.2. Beverage Preparation

The machine offers 15 pre-programmed specialties. Simply touch the icon for your desired drink. You can customize coffee strength and volume before brewing.

- **Espresso & Coffee:** Place a cup under the coffee spout and select your desired strength and volume. The Pulse Extraction Process (PEP) ensures optimal extraction for rich flavor.
- **Milk-Based Specialties (Latte Macchiato, Flat White, Cappuccino):** Connect the milk frother to a milk container. The professional fine foam frother will create perfectly textured milk foam.
- **Hot Water & Milk Foam:** Dedicated options are available for dispensing hot water or just milk foam.



Figure 3: Coffee being dispensed from the Jura S8.



Figure 4: The professional fine foam frother for milk specialties.

5. Maintenance

Regular maintenance is crucial for the longevity and optimal performance of your Jura S8 machine. The machine will prompt you for necessary cleaning cycles.

1. **Daily Milk System Cleaning:** After preparing milk-based drinks, the machine will prompt you to clean the milk system. This is vital to prevent blockages and maintain hygiene. Use Jura milk system cleaner or an equivalent product.
2. **Coffee System Cleaning:** The machine will indicate when a coffee system cleaning is required. Use Jura cleaning tablets and follow the on-screen instructions. This typically occurs after a certain number of coffee preparations.
3. **Water Filter Replacement:** The machine monitors filter usage and will prompt you when it's time to replace the CLARIS Smart filter. Ensure you use genuine Jura filters for proper function and water quality.

4. **Emptying Drip Tray and Coffee Grounds Container:** Regularly empty and clean the drip tray and the container for used coffee grounds. The machine will alert you when these need attention.
5. **Cleaning the Bean Container:** Periodically clean the bean container to remove any coffee oil residue that can affect bean freshness.

6. Troubleshooting

- **"Insert filter" message persists:** If the machine does not recognize a new CLARIS Smart filter, ensure it is correctly inserted and fully seated. If the issue persists, the filter's RFID chip might be defective. Try a different filter.
- **Touchscreen Unresponsive:** Ensure the screen is clean and dry. If issues persist, try restarting the machine by unplugging it for a few minutes and plugging it back in.
- **Coffee Not Hot Enough:** Check the temperature settings in the machine's menu. Ensure cups are pre-warmed.
- **No Coffee Dispensed:** Check water tank level, bean container level, and ensure no blockages in the coffee spout. Perform a cleaning cycle if prompted.

For more complex issues, refer to the detailed troubleshooting section in the full product manual or contact Jura customer support.

7. Specifications

Attribute	Detail
Brand	Jura
Model Number	15358
Color	Black
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Voltage	120 Volts
Product Dimensions	19.9 x 16.9 x 12.5 inches
Item Weight	27.6 pounds
Human Interface Input	Touchscreen

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your Jura S8 machine or visit the official Jura website. Customer support can assist with product inquiries, service requests, and troubleshooting beyond the scope of this manual.
You can also find helpful resources and contact information on theJura Store on Amazon.

© 2024 Jura. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089NKJCB3

More documents and user manuals: **https://manuals.plus/**