

Jocca 1436

Jocca Essential Oil Diffuser and Air Humidifier

MODEL: 1436

1. Important Safety Warnings

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Avoid direct skin contact with undiluted essential oils.
- Keep the device out of reach of children and pets.
- Ensure adequate ventilation during use.
- Do not exceed the maximum water fill line.
- Do not tilt or move the device when it is operating or contains water.
- Unplug the device before cleaning or refilling.
- Use only the provided USB cable and a compatible universal charger.

2. Product Overview

The Jocca Essential Oil Diffuser and Air Humidifier is designed to create a comfortable atmosphere, promote relaxation, and improve air circulation. It functions as an aromatherapy tool, air humidifier, and a night light.



Figure 2.1: Front view of the Jocca Essential Oil Diffuser, showcasing its wood-look finish and control buttons.

Key Features:

- 300 ml water capacity
- 3 timer settings
- USB cable included
- 7-color LED light
- Up to 10 hours of autonomy
- Ultrasonic technology for quiet operation

Components:

1. Diffuser Base with control buttons
2. Water Tank (300ml capacity)
3. Lid (wood-look finish)
4. USB Power Cable



Figure 2.2: The diffuser with its lid removed, revealing the internal water tank with a 'Max' fill line indicator.

3. Setup

1. Place the diffuser on a flat, stable surface.

2. Remove the top lid by gently lifting it upwards.
3. Fill the water tank with clean tap water up to the 'Max' line (300 ml capacity). Do not overfill.
4. If desired, add 2-3 drops of your preferred essential oil directly into the water.



Figure 3.1: A hand carefully adding essential oil drops into the water-filled diffuser tank.

5. Replace the lid securely.
6. Connect the USB cable to the diffuser's power port and plug the other end into a universal USB charger (not included) or a compatible USB port.

4. Operating Instructions

Once set up and powered, operate the diffuser using the two control buttons on the front:

Mist Control Button (Left Button):

- Press once for continuous mist.
- Press again to cycle through timer settings (1H, 3H, 6H). The diffuser will automatically turn off after the selected time.
- Press and hold to turn off the mist function.

Light Control Button (Right Button):

- Press once to turn on the LED light, which will cycle through 7 colors automatically.
- Press again to fix the light to a specific color. Continue pressing to cycle through colors.
- Press and hold to turn off the light function.



Figure 4.1: The diffuser actively emitting a fine mist, enhancing the ambiance of a room.

5. Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your diffuser.

1. Unplug the diffuser from the power source.
2. Remove the lid and empty any remaining water from the tank.
3. Wipe the inside of the water tank with a soft, damp cloth. For stubborn residue, use a cotton swab dipped in white vinegar to gently clean the ultrasonic plate at the bottom of the tank.
4. Rinse the tank with clean water, being careful not to get water into the air outlet.
5. Wipe the exterior of the diffuser with a dry, soft cloth.
6. Allow all parts to air dry completely before reassembling or storing.

Note: Do not use harsh detergents, abrasive cleaners, or corrosive liquids, as these can damage the diffuser.



Figure 5.1: The diffuser displayed alongside various essential oil bottles, emphasizing its primary function.







6. Troubleshooting

If you encounter issues with your diffuser, please refer to the following common solutions:

- **No Mist or Weak Mist:**
 - Ensure the water level is adequate and not above the 'Max' line.
 - Check if the ultrasonic plate is clean. Clean it as per maintenance instructions.
 - Verify the lid is properly secured.
- **No Power:**
 - Confirm the USB cable is securely connected to both the diffuser and the power source.
 - Try a different USB charger or port to rule out a faulty power source.
- **Leaking:**
 - Ensure the lid is properly aligned and sealed.
 - Do not overfill the water tank.
 - Avoid moving the diffuser when it contains water.

7. Specifications

Specification	Detail
Brand	Jocca
Model Number	1436
Color	Wood Look
Dimensions (L x W x H)	16 x 16 x 16 cm
Weight	520 grams
Capacity	300 Milliliters
Material	Wood (exterior finish)
Auto Shut-off Function	Yes
Operating Time	Up to 10 hours
Special Feature	Ultrasonic Technology
Power Source	USB Cable (Electric)
Light Source Type	LED

 <p>JOCCA Ventilateur RA Fraîchisseur d'Air JOCCA 1228</p> <p>MANUEL D'UTILISATION</p> <p>Version 1.0 - 2023</p>	<p>JOCCA 1228 Air Cooler User Manual and Instructions</p> <p>User manual for the JOCCA 1228 personal air cooler. Find instructions on operation, safety, cleaning, technical specifications, and environmental recycling information. Keep your space cool and comfortable with JOCCA.</p>
 <p>JOCCA HOME & LIFE Ref: 1588</p> <p>1588 Instruction manual 1588 Manual de l'utilisateur 1588 Manual de l'utilisateur 1588 Manual de l'utilisateur 1588 Manual de l'utilisateur</p>	<p>Jocca Kitchen Scale Instruction Manual</p> <p>This manual provides instructions and safety warnings for the Jocca Kitchen Scale, model ref: 1588. Learn how to use, clean, and maintain your scale for accurate measurements.</p>
 <p>JOCCA Sport Mini Exercise Bike</p> <p>JOCCA Sport Mini Exercise Bike JOCCA Sport Mini Exercise Bike JOCCA Sport Mini Exercise Bike JOCCA Sport Mini Exercise Bike JOCCA Sport Mini Exercise Bike</p>	<p>JOCCA Sport Mini Exercise Bike - User Manual and Instructions</p> <p>Comprehensive user manual for the JOCCA Sport Mini Exercise Bike, covering setup, operation, safety guidelines, and maintenance. Learn how to use your pedaler for effective home workouts.</p>
 <p>JOCCA HEALTHY INNOVATION</p> <p>JOCCA 2219P Air Fryer JOCCA 2219P Air Fryer JOCCA 2219P Air Fryer JOCCA 2219P Air Fryer JOCCA 2219P Air Fryer</p>	<p>JOCCA 2219P Air Fryer: User Manual & Operating Guide</p> <p>Discover the JOCCA 2219P Air Fryer. This comprehensive guide provides essential safety information, operating instructions, preset cooking programs, and maintenance tips for healthier, convenient home cooking.</p>
 <p>JOCCA Nature</p> <p>JOCCA 2187N Air Fryer JOCCA 2187N Air Fryer JOCCA 2187N Air Fryer JOCCA 2187N Air Fryer JOCCA 2187N Air Fryer</p>	<p>JOCCA 2187N Air Fryer: Instruction Manual & User Guide</p> <p>Comprehensive instruction manual for the JOCCA 2187N Air Fryer. Includes safety guidelines, operating instructions, cooking charts, cleaning tips, and technical data. Learn to use your JOCCA Nature air fryer effectively.</p>
 <p>JOCCA by ROBIN FOOD</p> <p>JOCCA 2157RF Air Fryer JOCCA 2157RF Air Fryer JOCCA 2157RF Air Fryer JOCCA 2157RF Air Fryer JOCCA 2157RF Air Fryer</p>	<p>JOCCA 2157RF Air Fryer: User Manual, Instructions, and Safety Guide</p> <p>Comprehensive user manual for the JOCCA 2157RF Air Fryer by ROBIN FOOD. Includes safety warnings, product description, operating instructions, cooking programs, cleaning guide, and technical specifications.</p>