

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lafocuse](#) /

› [Lafocuse Silent Analog Alarm Clock ZH0012A - Black Metal, Large 3D Numbers, Snooze, Night Light User Manual](#)

Lafocuse ZH0012A

Lafocuse Silent Analog Alarm Clock ZH0012A User Manual

INTRODUCTION

Thank you for purchasing the Lafocuse Silent Analog Alarm Clock ZH0012A. This manual provides essential information for the proper setup, operation, and maintenance of your new alarm clock. Please read these instructions carefully before use and retain them for future reference.

PRODUCT FEATURES

- **Silent Quartz Movement:** Ensures a quiet environment without ticking sounds.
- **Large 3D Numbers:** Provides clear and easy readability from a distance.
- **Night Light Function:** Illuminates the dial for visibility in low-light conditions.
- **Snooze Function:** Allows for a temporary pause of the alarm.
- **Durable Construction:** Features a high-quality ABS back cover and a sturdy black metal frame.

PACKAGE CONTENTS

- 1 x Lafocuse Silent Analog Alarm Clock ZH0012A
- 1 x User Manual

Note: 2 AA batteries are required and are not included in the package.

COMPONENT IDENTIFICATION



Image: Rear view of the Lafocuse Silent Analog Alarm Clock ZH0012A, highlighting key components such as the Light & Snooze Button, Alarm Speaker, Set the Time knob, Set the Alarm knob, Alarm ON/OFF switch, and Battery Compartment.

- 1. Light & Snooze Button:** Located at the top, used to activate the night light and snooze function.
- 2. Alarm Speaker:** Emits the alarm sound.
- 3. Set the Time Knob:** Used to adjust the current time.
- 4. Set the Alarm Knob:** Used to set the desired alarm time.
- 5. Alarm ON/OFF Switch:** Toggles the alarm function on or off.
- 6. Battery Compartment:** Holds 2 AA batteries.

SETUP

1. Installing Batteries

1. Open the battery compartment cover located on the back of the clock.
2. Insert 2 new AA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

2. Setting the Time

1. Locate the 'Set the Time' knob on the back of the clock.

2. Rotate this knob in either direction until the hour and minute hands display the correct current time.

3. Setting the Alarm

1. Locate the 'Set the Alarm' knob on the back of the clock.
2. Rotate this knob to align the alarm hand with your desired alarm time.
3. Ensure the 'Alarm ON/OFF' switch is in the 'ON' position to activate the alarm.

OPERATING INSTRUCTIONS

1. Using the Snooze Function

1. When the alarm sounds, press the 'Light & Snooze Button' on top of the clock.
2. The alarm will pause for approximately 5 minutes before sounding again.
3. To fully turn off the alarm, slide the 'Alarm ON/OFF' switch to the 'OFF' position.

2. Using the Night Light



Image: A hand pressing the top button of the Lafocuse Silent Analog Alarm Clock ZH0012A, activating the night light which illuminates the clock face for easy reading in the dark.

1. Press and hold the 'Light & Snooze Button' on top of the clock.

2. The dial will illuminate, allowing you to read the time in the dark.
3. Release the button to turn off the night light.

3. Turning the Alarm On/Off

- To activate the alarm, slide the 'Alarm ON/OFF' switch on the back of the clock to the 'ON' position.
- To deactivate the alarm, slide the 'Alarm ON/OFF' switch to the 'OFF' position.

MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the clock hands slow down or the alarm sound weakens. Always replace both batteries at the same time.
- **Storage:** If the clock will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working or running slow.	Batteries are low or incorrectly installed.	Replace batteries with new AA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm switch is OFF or alarm time is not set correctly.	Slide the 'Alarm ON/OFF' switch to 'ON'. Verify the alarm time is set.
Night light not working.	Batteries are low or depleted.	Replace batteries with new AA batteries.
Alarm time is slightly inaccurate.	Analog alarms may have minor deviations.	This is normal for analog clocks; a deviation of up to 5 minutes is typical. Adjust if necessary.

SPECIFICATIONS

Feature	Detail
Model Number	ZH0012A
Dimensions (L x W x H)	10.5 x 3.81 x 10.5 cm (4.13 x 1.5 x 4.13 inches)
Weight	270 grams (approx. 9.5 oz)
Material	Metal frame, ABS back cover
Color	Black
Display Type	Analog
Power Source	2 x AA Batteries (not included)
Special Features	Snooze, Night Light, 3D Numbers, Silent Movement

SAFETY INFORMATION

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Keep out of reach of small children.
- Do not attempt to disassemble or repair the clock yourself. Contact customer support if issues arise.
- Dispose of used batteries responsibly according to local regulations.

WARRANTY AND SUPPORT

Lafocuse products are designed for quality and reliability. Specific warranty details may vary by region and retailer. Please refer to your purchase documentation or contact your retailer for information regarding warranty coverage.

For technical support or inquiries, please visit the official Lafocuse website or contact their customer service department through the contact information provided with your purchase.