

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PowerLocus](#) /

› [PowerLocus P2 Kids Wireless Headphones User Manual](#)

## PowerLocus P2 Kids

# PowerLocus P2 Kids Wireless Headphones User Manual

Model: P2 Kids

## INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your PowerLocus P2 Kids Wireless Headphones. Please read this manual thoroughly before using the product and retain it for future reference.



Image: PowerLocus P2 Kids Wireless Headphones in blue, shown with its protective carry case.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x PowerLocus P2 Kids Wireless Headphones
- 1x 3.5mm Audio Cable
- 1x USB Charging Cable
- 1x Hard Shell Protective Carry Case

# OUR PACKAGE INCLUDES:



**1x PowerLocus P2 Kids**  
Wireless Headphones



**3.5mm**  
**Audio Cable**



**USB**  
**Charging Cable**



**Elegant Hard Shell**  
**Carry Case**

Image: Contents of the PowerLocus P2 Kids Headphones package, including the headphones, audio cable, USB charging cable, and carry case.

## PRODUCT OVERVIEW

The PowerLocus P2 Kids Wireless Headphones are designed for comfort and safety, featuring an 85dB volume limit to protect hearing. They offer multiple connectivity options and a foldable design for portability.

### Key Features:

- **85dB Volume Limited:** Ensures safe listening levels for children.
- **Wireless (Bluetooth 5.0):** Connects to devices wirelessly up to 36 feet.
- **Wired Mode:** Use with the included 3.5mm audio cable.
- **Micro SD Mode:** Supports Micro SD cards up to 32GB for direct music playback.
- **Built-in Microphone:** For online communication.
- **Foldable Design:** For easy storage and transport.
- **Soft Earmuffs:** Foam-filled for comfort and sound isolation.
- **Lightweight:** Weighs 165 grams (5.8 ounces).



Image: Detailed view of the headphone features, including adjustable headband, soft earcups, and control buttons.



Image: Close-up of the headphone's control panel, indicating buttons for playback, volume, and mode selection.

## SETUP INSTRUCTIONS

### 1. Charging the Headphones

Before first use, fully charge the headphones. Connect the USB charging cable to the headphone's charging port and to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status and turn off when fully charged.

### 2. Bluetooth Pairing (Wireless Mode)

1. Ensure the headphones are turned off.
2. Press and hold the Power/Multi-function button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "PowerLocus P2 Kids" from the list of devices.
5. Once paired, the LED indicator will flash blue slowly.

**Note:** The headphones can pair with up to two devices simultaneously. To pair with a TV, an additional Bluetooth adapter may be required.

### 3. Wired Connection (Aux Mode)

To use the headphones in wired mode:

1. Connect one end of the 3.5mm audio cable to the AUX port on the headphones.
2. Connect the other end of the 3.5mm audio cable to the audio output jack of your device.
3. The headphones will automatically switch to wired mode.

### 4. Micro SD Card Mode

To play music directly from a Micro SD card:

1. Insert a Micro SD card (up to 32GB) with audio files into the Micro SD card slot on the headphones.
2. Press the 'M' (Mode) button to switch to Micro SD card mode.
3. The headphones will automatically begin playing music from the card.

## OPERATING INSTRUCTIONS

### Button Controls:

Button	Function (Short Press)	Function (Long Press)
Power/Play/Pause/Call	Play/Pause music; Answer/End call	Power On/Off; Enter Bluetooth pairing mode (when off)
Volume Up (+) / Next Track	Increase volume	Next track
Volume Down (-) / Previous Track	Decrease volume	Previous track

Button	Function (Short Press)	Function (Long Press)
Mode (M)	Switch between Bluetooth, Micro SD, and FM Radio (if available) modes	N/A

**Volume Limit:** The headphones are designed with an 85dB volume limit to protect children's hearing. This limit cannot be exceeded.

## MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use liquid cleaners or aerosols.
- Storage:** When not in use, store the headphones in the provided hard shell protective carry case to prevent damage. Store in a cool, dry place.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.
- Avoid Extreme Conditions:** Do not expose the headphones to extreme temperatures, humidity, or direct sunlight.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones using the USB charging cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth disabled on device; too far from device.	Ensure headphones are in pairing mode (flashing blue/red LED). Enable Bluetooth on your device. Move headphones closer to the device (within 36ft).
No sound in wired mode.	Audio cable not fully inserted; incorrect audio source selected on device.	Ensure the 3.5mm audio cable is securely connected to both the headphones and the device. Check device's audio output settings.
Volume is too low.	Device volume is low; headphones are volume-limited.	Increase the volume on your connected device. Note that the headphones have an 85dB volume limit for hearing protection.
Micro SD card not playing.	Card not inserted correctly; unsupported file format; card capacity too large.	Reinsert the Micro SD card. Ensure audio files are in a compatible format. Use a Micro SD card up to 32GB. Press the 'M' button to select Micro SD mode.

## SPECIFICATIONS

**Model Name:** P2 Kids

**Connectivity Technology:** Wireless (Bluetooth), Wired (3.5mm AUX), Micro SD

**Wireless Communication Technology:** Bluetooth 5.0

**Bluetooth Range:** Up to 36 feet (10.97 meters)

**Audio Driver Size:** 40 Millimeters

**Frequency Range:** 20Hz – 20,000Hz

**Impedance:** 32 Ohm

**Sensitivity:** 85 dB (Volume Limited)

**Battery Life:** Approximately 15 Hours

**Item Weight:** 165 Grams (5.8 ounces)

**Material:** Foam (earmuffs)

**Earpiece Shape:** Over Ear

**Special Features:** Foldable, Microphone Included, Volume Control

**Compatible Devices:** Gaming Consoles, Laptops, Tablets, Television (with adapter), iPhone, iPad, Samsung, PC, Android, Smartphones, Macbook, all Bluetooth and Aux enabled devices.

## WARRANTY AND SUPPORT

PowerLocus offers a **24-month warranty** for the P2 Kids Wireless Headphones. If you encounter any issues with the product, please contact PowerLocus customer support. They provide 24/7 customer service and will assist with repairs or replacements within 24 hours if the product performance is not satisfactory.

For support, please refer to the contact information provided with your product packaging or visit the official PowerLocus website.

© 2025 PowerLocus. All rights reserved.

## Related Documents - P2 Kids

 USER MANUAL PowerLocus P2 <small>For Warranty or problems with the product, please contact us! Email Support: info@powerlocus.com</small> 	<p><a href="#"><u>PowerLocus P2 User Manual: Features, Operation, and Safety</u></a></p> <p>Comprehensive user manual for the PowerLocus P2 headphones, detailing product features, pairing instructions, audio modes, charging, and safety guidelines. Includes technical specifications and compliance information.</p>
 PowerLocus P7 <small>EN Web: PowerLocus.com Email: info@powerlocus.com</small>	<p><a href="#"><u>PowerLocus P7 Wireless Headphones User Manual</u></a></p> <p>Comprehensive user manual for the PowerLocus P7 wireless headphones. Learn about specifications, Bluetooth pairing, button controls, charging, troubleshooting, and safety guidelines.</p>

 <b>USER MANUAL</b>  <b>PowerLocus</b> <b>P2 Kids Princess</b>  <small>For Warranty or Problems with the product, please contact us!</small> <small>Email Support: info@powerlocus.com</small> 	<p><a href="#"><b>PowerLocus P2 Kids Princess User Manual</b></a></p> <p>Comprehensive user manual for the PowerLocus P2 Kids Princess wireless headphones, covering setup, operation, features, and safety guidelines.</p>
 <b>USER MANUAL</b>  <b>PowerLocus</b> <b>P2 Kids</b>  <small>For Warranty or Problems with the product, please contact us!</small> <small>Email Support: info@powerlocus.com</small> 	<p><a href="#"><b>PowerLocus P2 Kids User Manual</b></a></p> <p>User manual for the PowerLocus P2 Kids wireless headphones, detailing features, setup, specifications, and safety guidelines.</p>
	<p><a href="#"><b>PowerLocus Move   Jumpy Open Ear Headphones User Manual</b></a></p> <p>User manual for the PowerLocus Move   Jumpy Open Ear Headphones, providing instructions on setup, usage, safety, technical specifications, and compliance information.</p>
	<p><a href="#"><b>PowerLocus P4 Wireless Headphones User Manual and Specifications</b></a></p> <p>Comprehensive user manual for PowerLocus P4 wireless headphones, covering setup, Bluetooth pairing, charging, technical specifications, safety, and disposal. Features Hi-Fi stereo sound and long battery life.</p>