

[Manuals.plus](#) /

> [oneisall](#) /

> oneisall Dog Clippers with Double Blades,Cordless Small Pet Hair Grooming Trimmer,Low Noise for Trimming Dog's Hair Around Paws, Eyes, Ears, Face, Rump (White)

oneisall C61

oneisall Pet Paw Trimmer Instruction Manual

Model: C61

INTRODUCTION

Thank you for choosing the oneisall Pet Paw Trimmer. This cordless grooming trimmer is designed for precise and quiet trimming of pet hair around sensitive areas such as paws, eyes, ears, face, and rump. Its compact size and low-noise operation make grooming easier and more comfortable for your pet.

SAFETY INFORMATION

- Avoid contact with skin and eyes.
- Keep the trimmer away from water sources.
- Follow recommended cleaning and maintenance procedures.
- Do not use on humans or infants.
- Always supervise pets during use.

WHAT'S INCLUDED

Your oneisall dog clipper set includes:

- One oneisall dog clipper (with one small blade and one middle blade)
- One cleaning brush
- One USB charging cord
- Blade oil (small bottle)



Image: The complete onesall Pet Paw Trimmer kit with all included accessories.

SETUP

1. Charging the Trimmer

The trimmer is rechargeable via USB. A full charge takes approximately 2 hours and provides about 2 hours of working time. An indicator light will show the charging status.

120 Minutes Long Working Time

Run Time
2 Hours

Charging Time
2 Hours



Image: The trimmer being charged via USB, illustrating its 120-minute run time and charging time.

2. Attaching Blades

Your trimmer comes with two interchangeable blade heads: a small blade for detailed work and a middle blade for larger trimming needs. To attach a blade, align it with the trimmer body and gently push until it clicks into place. To remove, pull the blade head away from the body.



Image: The trimmer and its two distinct blade attachments.

3. Initial Oiling

Before first use, and periodically thereafter, apply a small amount of the included blade oil to the blades to ensure smooth operation and longevity. This is step 1 in the grooming process.



Image: Oiling the blade before use, as part of the grooming preparation.

OPERATING INSTRUCTIONS

The oneisall Pet Paw Trimmer is designed for ease of use and pet comfort. It features a low-noise and low-vibration design to minimize stress for your pet during grooming.

General Use

Press the power button to turn the trimmer on. The trimmer offers two adjustable speeds (5000 rpm and 5700 rpm) for different hair types and grooming needs. Press the power button again to cycle through speeds or turn off.



Image: Demonstrating the two-speed adjustable motor of the trimmer.

Trimming Specific Areas

The small-sized blade is ideal for precise trimming in various detailed areas. The trimmer's design allows for close trimming without guards, making it safe for sensitive skin.

- **Paws:** Carefully trim hair around paw pads to prevent slipping and dirt accumulation.
- **Eyes & Face:** Use the small blade to gently trim hair that may obstruct your pet's vision or irritate their eyes.
- **Ears:** Trim excess hair inside and around the ears to maintain hygiene and prevent matting.
- **Rump/Belly:** Use for sanitary trims in these sensitive areas.

Perfect For Trimming Small Area



Image: The trimmer is perfect for small areas like face, ears, paws, and rump.



Great for Trimming Dog Paw Pads



Before



After

Image: Effective for trimming dog paw pads, showing a before and after comparison.



Image: The oneisall trimmer is great for trimming puppy paws, suitable for all dog breeds.

Low Noise Operation

The oneisall trimmer operates at a low noise level (less than 60dB), which helps prevent scaring your pet, making grooming a more pleasant experience for both of you.



Image: The quiet paw clippers won't scare your dog, operating at less than 60dB.

Wireless and Charging Use

The trimmer supports both wireless operation and use while charging, providing flexibility during grooming sessions.



Image: Two operating methods: wireless use and charging use.

Official Product Video

Your browser does not support the video tag.

Video: An unboxing and demonstration of the oneisall Pet Paw Trimmer, highlighting its features and ease of use for pet grooming.

MAINTENANCE

Cleaning the Blades

To ensure optimal performance and hygiene, regularly clean the trimmer blades. The blades are removable and washable. Use the included cleaning brush to remove hair debris.



Image: Instructions for removing and washing the trimmer blade.

Oiling the Blades

After cleaning and drying, apply a few drops of the provided oil to the blades. This lubricates the blades, reduces friction, and extends their lifespan.



Image: Oiling the blade for proper maintenance.

TROUBLESHOOTING

If you encounter any issues with your oneisall Pet Paw Trimmer, please consider the following:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Connect it to the USB charging cord and allow it to charge for 2 hours.
- **Reduced cutting performance:** Clean the blades thoroughly to remove any trapped hair. Apply blade oil to ensure smooth operation. If performance does not improve, the blades may need replacement.
- **Excessive noise or vibration:** Check if the blade head is securely attached. Ensure the blades are clean and properly oiled.

For further assistance, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	C61
Product Dimensions	5.59 x 1.22 x 0.98 inches
Item Weight	7.76 ounces (0.22 Kilograms)
Battery Type	1 A battery (included)
Charging Time	2 hours (120 minutes)
Working Time	Approx. 2 hours (120 minutes)
Noise Level	< 60 dB
Speeds	2 speeds (5000 rpm, 5700 rpm)
Color	White




Image: Key specifications of the oneisall Model C61 trimmer.

WARRANTY AND SUPPORT

oneisall stands behind the quality of its products.

- **Warranty:** This product comes with a 2-year warranty.
- **Customer Service:** 24-hour customer service is available for any inquiries or assistance.

For support, please visit the [oneisall Store on Amazon](#) or refer to the contact information provided in your product packaging.



Pet Peasy

At Oneisall, we put pets first and are committed to making pet care easy and cozy. Pets deserve the finest care.

Image: Customer Satisfaction Guarantee highlighting 24-hour customer service and 2-year warranty.