

Manuals.plus /

› Kiano /

› Kiano Slim TV 32" Instruction Manual

## Kiano Slim TV 32

# Kiano Slim TV 32" Instruction Manual

Model: Slim TV 32

## 1. INTRODUCTION

---

Thank you for choosing the Kiano Slim TV 32". This manual provides essential information for the safe and efficient use of your television. Please read it thoroughly before operating the device and keep it for future reference.

## 2. SAFETY INFORMATION

---

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury.

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Unplug the TV during lightning storms or when unused for long periods.
- Keep the TV away from direct sunlight and heat sources.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the box:

- Kiano Slim TV 32" Television
- Remote Control
- TV Stand (2 pieces)
- Screws for Stand Assembly
- Power Cable
- User Manual (this document)
- Quick Start Guide

- Warranty Card




Image: Kiano Slim TV 32" with remote control.

## 4. SETUP

### 4.1 Attaching the Stand

1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
2. Align the stand pieces with the corresponding slots on the bottom of the TV.
3. Secure the stand pieces using the provided screws.





Image: Kiano Slim TV 32" securely placed on its stand.

#### **4.2 Wall Mounting (Optional)**

This TV supports VESA 100 x 100 mm mounting. Use compatible wall mount brackets (not included) and follow the instructions provided with the wall mount. Ensure the wall can support the weight of the TV.




Image: Kiano Slim TV 32" mounted on a wall.

### 4.3 Connecting Peripherals

Connect your devices to the TV's ports:

- **Power:** Connect the power cable to the TV and a power outlet.
- **Antenna/Cable:** Connect your antenna or cable to the RF (C/T2) input.
- **Satellite:** Connect your satellite dish to the LNB IN input (DVB-S/S2).
- **HDMI Devices:** Use HDMI ports for Blu-ray players, game consoles, etc. (2x HDMI inputs available).
- **USB Devices:** Insert USB drives for media playback (2x USB inputs available).
- **VGA:** Connect a PC using the VGA port and PC Audio In.
- **CI Slot:** Insert a CI+ module for encrypted channels.
- **AV Input:** Connect older devices using the AV input.
- **Headphone Output:** Connect headphones for private listening.






Image: Rear view of the Kiano Slim TV 32" displaying its connectivity ports.

#### 4.4 First-Time Setup

Upon first power-on, the TV will guide you through initial setup, including language selection, country, and channel scanning. Follow the on-screen prompts.

## 5. OPERATING THE TV

### 5.1 Remote Control Functions

The remote control allows you to access all TV functions. Ensure batteries are correctly inserted.



Image: The Kiano Slim TV 32" remote control.

- **Power Button:** Turns the TV on/off.
- **Input:** Selects input source (HDMI, AV, USB, etc.).
- **Volume +/-:** Adjusts volume level.
- **Channel +/-:** Changes TV channels.
- **Menu:** Accesses the main menu for settings.
- **Navigation Buttons (Up/Down/Left/Right):** Navigates through menus.
- **OK:** Confirms selections.
- **Exit:** Exits the current menu.
- **Numeric Buttons:** Direct channel selection.

### 5.2 Picture and Sound Settings

Access the main menu to adjust picture (brightness, contrast, color temperature) and sound (equalizer, sound mode) settings to your preference.

### 5.3 USB Multimedia Playback

Insert a USB drive into one of the USB ports. The TV will typically prompt you to open the media browser. You can play photos, music, and videos stored on the drive.



Image: Kiano Slim TV 32" demonstrating USB PVR functionality.

### 5.4 PVR (Personal Video Recorder) Function

The PVR function allows you to record TV programs to a connected USB storage device. Consult the on-screen menu for detailed PVR setup and operation instructions.

### 5.5 Hotel Mode

This feature is designed for use in hospitality environments, allowing for restricted access to certain TV functions. Refer to the advanced settings menu for Hotel Mode activation and configuration.

## 6. MAINTENANCE

---

### 6.1 Cleaning the TV

Always unplug the TV before cleaning. Use a soft, dry cloth to wipe the screen and cabinet. Do not use liquid cleaners or aerosol sprays directly on the TV.

### 6.2 Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features. Updates may be available via USB or over-the-air (if connected to the internet, though this model is not explicitly stated as Smart TV with internet connectivity).

## 7. TROUBLESHOOTING

---

If you encounter issues, try the following solutions before contacting support:

- **No Power:** Check if the power cable is securely connected and the outlet is working.
- **No Picture/Sound:** Verify the correct input source is selected. Check cable connections to external devices.
- **Poor Picture Quality:** Adjust picture settings in the menu. Ensure antenna/cable connection is strong.
- **Remote Control Not Working:** Check and replace batteries. Ensure no obstructions between remote and TV sensor.
- **No Channels Found:** Perform a new channel scan in the setup menu.

## 8. SPECIFICATIONS

---

| Feature              | Description                                     |
|----------------------|---|
| Screen Size          | 32 Inches (80 cm)                               |
| Display Technology   | LED HD TV (DLED)                                |
| Resolution           | 720p  |
| Refresh Rate         | 60 Hz   |
| Contrast Ratio       | 3500:1  |
| Viewing Angles       | 178° x 178°                                     |
| Audio Technology     | Dolby Audio, Dolby Digital Plus                 |
| Speakers             | 2.0 Channel Stereo Speakers                     |
| HDMI Inputs          | 2   |
| USB Inputs           | 2   |
| Other Connectivity   | VGA, PC Audio In, Headphone Out, CI Slot, AV In |
| Tuners               | DVB-S/S2, ATV/DVB-C/T/T2                        |
| VESA Mounting        | 100 x 100 mm                                    |
| Power Consumption    | 60 Watts  |
| Dimensions (Product) | 24 x 69 x 2.5 cm                                |
| Weight (Product)     | 3.5 kg  |

## 9. WARRANTY AND SUPPORT

---

Your Kiano Slim TV 32" comes with a limited warranty. Please refer to the included warranty card for details on coverage and duration. For technical support, product inquiries, or service requests, please visit the official Kiano website or contact their customer service department.

Official Kiano Website: [www.kiano.com](http://www.kiano.com)

