

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [XTREME](#) /

› [Xtreme Armor All Wireless Bluetooth FM Transmitter \(AHF9-1010-BLK\) User Manual](#)

## XTREME AHF9-1010-BLK

# Xtreme Armor All Wireless Bluetooth FM Transmitter (Model: AHF9-1010-BLK) User Manual

Comprehensive instructions for setup, operation, and maintenance.

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Xtreme Armor All Wireless Bluetooth FM Transmitter. Please read this manual thoroughly before operating the device and retain it for future reference.

## SAFETY INFORMATION

For your safety and to prevent damage to the device, please observe the following:

- Handle the device with care.
- Avoid exposure to water and high temperatures.
- Do not attempt to disassemble or modify the device.
- Ensure proper ventilation when in use.

## PRODUCT OVERVIEW

The Xtreme Armor All Wireless Bluetooth FM Transmitter allows you to stream music wirelessly from your Bluetooth-enabled device to your vehicle's stereo system. It also features dual USB charging ports, voice control capabilities, and a bass boost function.

## Component Identification



Figure 1: Front view of the FM Transmitter with labeled components.

This image illustrates the key components of the FM Transmitter:

- **Volume & Voice Assistant Knob:** Rotate to adjust volume, press to activate voice assistant or answer/end calls.
- **Built-in Mic:** For hands-free calling and voice commands.
- **2 USB Ports:** For charging devices. The left port also supports USB flash drive music playback.
- **Display:** Shows the current FM frequency.
- **Bass Boost Button:** Enhances bass output.
- **Frequency Adjustment Buttons (Back/Forward):** Used to change the FM frequency.

## SETUP INSTRUCTIONS

1. **Power On:** Insert the FM Transmitter into your vehicle's 12V power outlet (cigarette lighter socket). The device will power on automatically, and the LED display will illuminate.
2. **Tune FM Frequency:**
  - Tune your vehicle's FM radio to an unused, clear frequency. Avoid frequencies with strong radio stations to minimize interference.
  - Adjust the FM Transmitter to the same frequency as your car radio. Use the "CH" button to enter frequency

adjustment mode, then use the left and right arrow buttons to select the desired frequency.

### 3. Pair Bluetooth:

- On your smartphone or Bluetooth-enabled device, enable Bluetooth and search for available devices.
- Select "AHF9-1010-BLK" (or similar name) from the list to pair. A confirmation tone will sound upon successful pairing.

### 4. Test Connection:

Play audio from your paired device. The sound should now transmit through your vehicle's stereo system. Adjust the volume on both your device and car stereo for optimal sound.



Figure 2: The FM Transmitter properly installed in a vehicle's 12V power outlet.

This image demonstrates the correct installation of the FM Transmitter into a car's power socket, ready for operation.

## OPERATING INSTRUCTIONS

### Music Playback

- **Bluetooth Streaming:** Once paired, music from your device will automatically stream to your car stereo.

- **USB Flash Drive Playback:** Insert a USB flash drive containing MP3 files into the left USB port. The device will automatically detect and play music from the drive.
- **Volume Control:** Rotate the multi-function knob to adjust the output volume of the transmitter.
- **Track Navigation:** Use the left and right arrow buttons to skip to the previous or next track.
- **Bass Boost:** Press the "B1" (Bass Boost) button to activate or deactivate the bass enhancement feature.



Figure 3: Detailed view of the control buttons and digital display on the FM Transmitter.

This image highlights the various control buttons and the digital frequency display, essential for operating the device.

## Hands-Free Calling

- **Answer/End Call:** Press the multi-function knob once to answer an incoming call. Press it again to end a call.
- **Reject Call:** Press and hold the multi-function knob to reject an incoming call.
- **Redial:** Double-press the multi-function knob to redial the last number.

## Voice Control

- **Activate Voice Assistant:** Press and hold the multi-function knob to activate your smartphone's voice assistant (e.g., Siri, Google Assistant).

- You can then use voice commands for tasks such as selecting playlists, sending texts, or asking for navigation.



Figure 4: Visual representation of voice assistant functionality and echo reduction.

This image demonstrates how to use voice commands with the device, such as asking for weather or sending messages, and highlights the echo reduction feature for clear communication.

## USB Charging

- The two USB ports provide 3.4 Amps of power for charging mobile devices.
- Connect your device's charging cable to either USB port on the transmitter.



Figure 5: The dual USB charging ports on the FM Transmitter, capable of charging two devices simultaneously.

This image clearly shows the two USB ports, indicating their function for charging electronic devices.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight.
- **Avoid Impact:** Protect the device from drops and impacts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Device not turning on.	Loose connection in 12V outlet; vehicle's 12V outlet fuse blown.	Ensure the transmitter is firmly seated. Check your vehicle's fuse box for a blown fuse and replace if necessary.
Poor sound quality/Static.	FM frequency interference; volume levels too low/high; weak Bluetooth connection.	<ul style="list-style-type: none"> <li>Find a clearer, unused FM frequency on both your car radio and the transmitter.</li> <li>Adjust volume on both your phone and car stereo.</li> <li>Ensure your phone is within close proximity to the transmitter.</li> </ul>
Bluetooth not pairing.	Bluetooth not enabled on device; transmitter not in pairing mode; incorrect device selected.	<ul style="list-style-type: none"> <li>Ensure Bluetooth is enabled on your smartphone.</li> <li>Restart the transmitter by unplugging and re-plugging it.</li> <li>Select "AHF9-1010-BLK" from your device's Bluetooth list.</li> </ul>
USB charging not working.	Cable issue; device not compatible; transmitter not powered.	<ul style="list-style-type: none"> <li>Try a different USB charging cable.</li> <li>Ensure the transmitter is powered on.</li> <li>Verify your device is compatible with USB charging.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model Number	AHF9-1010-BLK
Connectivity Technology	Bluetooth, USB, FM
Power Source	Vehicle Powered (12V)
USB Charging Output	3.4 Amps (Total for 2 ports)
Special Features	Bluetooth FM Transmitter, Dual USB Charging, Voice Controls, Bass Boost, Hands-Free Calling, Music Streaming
Item Weight	3.52 ounces
Package Dimensions	7.8 x 4.53 x 2.4 inches
Manufacturer	Armor All

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Xtreme Digital Lifestyle Accessories website. Keep your purchase receipt as proof of purchase.

**Manufacturer:** Armor All

**Brand:** XTREME

© 2024 Xtreme Digital Lifestyle Accessories. All rights reserved.