

## ANCwear TWS-BT208T

# ANCwear TWS-BT208T Portable Bluetooth Speaker User Manual

Model: TWS-BT208T

## INTRODUCTION

Thank you for choosing the ANCwear TWS-BT208T Portable Bluetooth Speaker. This mini wireless speaker is designed for enhanced bass and HD sound, featuring a wearable design with a built-in microphone, 9.5 hours of playtime, and IPX6 waterproof rating. It is suitable for various activities including sports, outdoor travel, and indoor use. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

## WHAT'S IN THE BOX

- Speaker
- Detachable Wearable Wristband
- Detachable Clip
- Detachable Clip with Hanger
- Type-C Recharge Cord

## Compact design diverse function



Bluetooth 5.0



Phone Answer



Microphone



Long Working Time



3w Speaker



Image: The ANCwear TWS-BT208T speaker and its included accessories, such as the wristband, clip, and charging cable.

## SETUP

### 1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C recharge cord to the charging port on the speaker and plug the other end into a USB power source. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 1.5 hours.



Image: The Type-C charging port on the side of the ANCwear TWS-BT208T speaker.

## 2. Powering On/Off

To power on the speaker, press and hold the power button (usually the middle button) for a few seconds until you hear an audible prompt and the LED indicator light flashes. To power off, press and hold the same button until you hear a power-off prompt.

## 3. Bluetooth Pairing

1. Ensure the speaker is powered off.
2. Press and hold the power button until the LED indicator light flashes rapidly, indicating it's in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "ANCwear" from the list. Once connected, the LED light will stop flashing and remain solid blue.



Image: The top of the ANCwear TWS-BT208T speaker, highlighting the LED indicator light for pairing status.

## 4. True Wireless Stereo (TWS) Pairing (Optional)

To achieve a stereo sound experience, you can pair two ANCwear TWS-BT208T speakers together:

1. Ensure both speakers are fully charged and powered off.
2. Power on both speakers simultaneously by pressing and holding their respective power buttons.
3. Wait for a few seconds. The speakers will automatically attempt to pair with each other. A successful TWS connection will be indicated by an audible prompt.

4. Once TWS paired, connect one of the speakers to your device via Bluetooth as described in step 3. Both speakers will now play audio in stereo.

Your browser does not support the video tag.

Video: This video demonstrates how to use the TWS (True Wireless Stereo) function to pair two ANCwear Portable Bluetooth Speakers for a stereo sound experience.

## OPERATING INSTRUCTIONS

---

### 1. Basic Functions

- **Play/Pause:** Press the power button once to play or pause music.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.

### 2. Hands-Free Calling

- **Answer Call:** Press the power button once when a call comes in.
- **End Call:** Press the power button once during a call.
- **Reject Call:** Long press the power button when a call comes in.
- **Redial Last Number:** Double-press the power button.

Your browser does not support the video tag.

Video: This video provides a comprehensive guide on how to use the ANCwear Portable Bluetooth Speaker, covering its various functions and controls.

### 3. Wearing Options

The speaker comes with multiple accessories for versatile wearing:

- **Wristband:** Attach the speaker to the wearable wristband for use during sports or on the go. The wristband is adjustable and features reflective material for visibility in low light.
- **Clip:** Use the detachable clip to attach the speaker to clothing, bags, or other items.
- **Clip with Hanger:** For more secure attachment or hanging, use the clip with the integrated hanger.

Your browser does not support the video tag.

Video: This video demonstrates the three different ways to wear the ANCwear Portable Bluetooth Speaker, including the wristband and clip options.




Image: The ANCwear TWS-BT208T speaker worn on a wristband, ideal for active use.

# Powerful Bass

Hang on your T-shirt and jeans, Portable and fashionable



Image: The ANCwear TWS-BT208T speaker clipped to clothing, offering hands-free audio.

## MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Waterproof Care:** The speaker is IPX6 waterproof, meaning it can withstand strong jets of water. However, do not submerge it in water for extended periods. Ensure the charging port cover is securely closed before exposure to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Life:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for long periods.



Image: The ANCwear TWS-BT208T speaker in a bathroom, demonstrating its IPX6 waterproof capability.

## TROUBLESHOOTING

- **Speaker does not power on:** Ensure the speaker is fully charged. Connect it to a power source and try again.
- **Cannot pair with device:** Make sure Bluetooth is enabled on your device and the speaker is in pairing mode (rapidly flashing LED). Ensure no other devices are currently connected to the speaker. Try restarting both the speaker and your device.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is successfully paired and connected.
- **Poor sound quality/disconnections:** Ensure the speaker is within the 15-meter Bluetooth range of your device. Avoid obstacles that may interfere with the Bluetooth signal.
- **TWS pairing fails:** Ensure both speakers are powered off before attempting TWS pairing. Make sure they are close to each other during the pairing process.

## SPECIFICATIONS

<b>Model Number</b>	TWS-BT208T
<b>Speaker Type</b>	Portable, Outdoor
<b>Connectivity Technology</b>	Bluetooth
<b>Bluetooth Range</b>	15 Meters
<b>Waterproof Rating</b>	IPX6
<b>Playtime</b>	Up to 9.5 hours
<b>Charging Time</b>	Approx. 1.5 hours
<b>Speaker Output Power</b>	3 Watts

<b>Item Weight</b>	3.17 ounces (0.09 Kilograms)
<b>Product Dimensions</b>	4.4 x 3.5 x 1.8 inches

## **WARRANTY AND SUPPORT**

---

For warranty information or technical support, please refer to the product packaging or contact ANCwear customer service directly. Keep your purchase receipt for any warranty claims.