

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [U ULTTY](#) /

› [ULTTY Bladeless Fan & Circulator User Manual](#)

## U ULTTY SKJ-CR309WD

# ULTTY Bladeless Fan & Circulator User Manual

Model: SKJ-CR309WD

## 1. INTRODUCTION

Thank you for purchasing the ULTTY Bladeless Fan & Circulator. This innovative product combines safety, efficiency, and modern design to provide optimal air circulation in your home or office. Its bladeless technology ensures safety for children and pets, while its versatile 2-in-1 design allows for both floor-standing and wall-mounted use. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: The ULTTY Bladeless Fan in white, accompanied by its black remote control.

## 2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Do not insert fingers or foreign objects into the fan's air inlet or outlet.
- Ensure the power cord is not damaged or pinched.
- Do not use the fan near water or in excessively humid environments.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- Keep the fan away from heat sources and direct sunlight.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

### 3. PACKAGE CONTENTS

Please check the package for the following items:

- ULTTY Bladeless Fan Unit
- Remote Control
- Wall Mounting Hardware (screws, anchors)
- User Manual (this document)

### 4. PRODUCT FEATURES

- **Bladeless Design:** Ensures safety for households with children and pets by eliminating exposed rotating blades.
- **2-in-1 Versatility:** Can be used as a floor-standing fan or easily mounted on a wall to save space.
- **7-Speed Air Volume Adjustment:** Offers a wide range of airflow settings from a gentle breeze to a strong current.
- **Wide Oscillation:** Features 180-degree vertical adjustment and 80-degree automatic horizontal oscillation to distribute air effectively throughout the room.
- **Timer Function:** Includes a sleep mode that gradually reduces air volume and a power-off timer settable from 1 to 8 hours.
- **Quiet Operation:** Designed for low noise, making it suitable for use during sleep.



Image: A diagram highlighting key features of the fan, including the remote control, operation buttons, air inlet, base, and bladeless design.



Image: Illustrations demonstrating the fan's 135-degree manual vertical adjustment and 90-degree automatic horizontal oscillation capabilities.



Image: A split image illustrating the fan's dual functionality: mounted on a wall and placed on the floor.

## 5. SETUP

### 5.1 Floor Placement

Place the fan on a stable, flat surface. Ensure there is adequate space around the fan for optimal air circulation and oscillation.

## 5.2 Wall Mounting

To mount the fan on a wall:

1. Select a suitable wall location, ensuring it is sturdy enough to support the fan's weight and near a power outlet.
2. Use the included wall mounting hardware (screws and anchors) to securely attach the fan's base to the wall. Refer to the diagram for proper alignment.
3. Once securely mounted, connect the power cord.

## 5.3 Remote Control Setup

Insert the required batteries (not included) into the remote control. Ensure correct polarity.

# 6. OPERATING INSTRUCTIONS

## 6.1 Power ON/OFF

Press the power button on the fan unit or the remote control to turn the fan ON or OFF.

## 6.2 Adjusting Air Volume

Use the '+' and '-' buttons on the fan unit or remote control to cycle through the 7 air volume settings.

## 6.3 Oscillation Control

- **Horizontal Oscillation:** Press the oscillation button on the fan unit or remote control to activate/deactivate the 80-degree automatic horizontal oscillation.
- **Vertical Adjustment:** Manually adjust the fan head up or down to achieve the desired vertical airflow angle (up to 180 degrees).

## 6.4 Timer Setting

Press the timer button on the remote control to set the automatic power-off timer. Each press will cycle through available timer settings (e.g., 1 hour, 2 hours, up to 8 hours). The fan will automatically turn off after the set time.

## 6.5 Sleep Mode

Activate sleep mode via the remote control. In this mode, the fan's air volume will gradually decrease to provide a comfortable sleeping environment and save energy.

# 7. MAINTENANCE

Regular cleaning will help maintain the fan's performance and longevity.

- **Cleaning:** Always unplug the fan before cleaning. Wipe the exterior surfaces of the fan with a soft, damp cloth or rag. Do not use abrasive cleaners or solvents.
- **Dust Prevention:** The bladeless design inherently reduces dust accumulation compared to traditional fans. However, periodically wipe the air inlet and outlet areas to ensure clear airflow.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

# 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Power button not pressed.	Check if the power cord is securely plugged in. Press the power button.
Weak airflow.	Low speed setting; Air inlet/outlet blocked.	Increase the fan speed. Check and clear any obstructions from the air inlet/outlet.
Fan makes unusual noise during oscillation.	Obstruction in oscillation mechanism; Unit not on a stable surface.	Ensure no objects are interfering with the fan's movement. Place the fan on a flat, stable surface.
Remote control not working.	Batteries are dead or incorrectly inserted.	Replace batteries, ensuring correct polarity. Ensure line of sight to the fan's receiver.
Unpleasant odor from fan.	New product odor; Dust accumulation.	The odor should dissipate with use. Clean the fan thoroughly as per maintenance instructions.

## 9. SPECIFICATIONS

Feature	Specification
Brand	U ULTTY
Model Number	SKJ-CR309WD
Color	White
Material	ABS
Product Dimensions	29D x 30.5W x 35.6H cm
Package Size	37 x 32 x 24 cm
Package Weight	2.68 Kilograms
Wattage	26 W
Voltage	220 Volts
Power Source	Corded Electric
Other Functions	Remote control, Oscillation, Bladeless
Recommended Use	Cooling, Air Circulation
Room Type	Living Room, Bedroom
Care Instructions	Wipe with a rag
Date First Available	2020/6/10

## 10. WARRANTY AND SUPPORT

This ULTTY Bladeless Fan & Circulator comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact ULTTY customer service through the retailer's platform or the official ULTTY website. Please have your purchase receipt and product model number (SKJ-CR309WD) ready when contacting support.