

NQD 757-C274-pink

# NQD 4WD Remote Control Truck Instruction Manual

Brand: NQD | Model: 757-C274-pink

## PRODUCT OVERVIEW

The NQD 4WD Remote Control Truck is a robust 1:14 scale monster stunt car engineered for thrilling off-road experiences. Its advanced 2.4Ghz remote control system ensures stable and interference-free operation, allowing multiple users to play simultaneously. Equipped with bright LED headlights and a unique nitrogen spray effect (activated by adding water), this truck delivers an immersive play experience. Built with high-strength ABS plastic and durable climbing tires, it's designed to conquer various terrains and withstand impacts.



Figure 1: NQD 4WD Remote Control Truck (Pink) with its remote and rechargeable batteries.

## What's in the Box

Upon unboxing your NQD 4WD Remote Control Truck, please verify that all components are present:

- 1 x 1:14 Scale Remote Control Car
- 1 x Remote Control (requires 2 AA batteries, not included)
- 2 x 3.7V/1200mAh Rechargeable Batteries (for the truck)
- 1 x USB Charging Cable
- 1 x Screwdriver
- 1 x Water Bottle (for spray effect)

# Remote Control Instructions

High-speed driving, multi -scene climbing!



Figure 2: All items included in the NQD 4WD Remote Control Truck package.

## SETUP GUIDE

### 1. Battery Installation

#### For the Remote Control:

1. Locate the battery compartment on the back of the remote control.
2. Use a screwdriver to open the battery cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Replace the battery cover and secure it with the screw.

#### For the RC Truck:

1. Locate the battery compartment on the underside of the truck.
2. Use the provided screwdriver to open the battery cover.
3. Connect the rechargeable battery pack to the truck's battery connector.
4. Carefully place the battery pack inside the compartment.
5. Close the battery cover and secure it with the screw.

## 2. Charging the Truck Battery

The truck's 3.7V/1200mAh battery is rechargeable. Use the included USB charging cable to charge the battery. Connect the battery to the USB cable, then plug the USB end into a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light on the USB cable will show the charging status. Allow sufficient time for a full charge before first use (approximately 2-3 hours).

## 3. Filling Water for Spray Effect

The truck features a unique nitrogen spray effect. To activate this, you need to add water:

1. Locate the water filling port at the rear of the truck (near the exhaust).
2. Use the provided small water bottle to carefully fill the reservoir with clean water. Do not overfill.
3. Ensure the cap is securely closed after filling to prevent leaks.



Figure 3: Illustration of adding water to the truck for the spray effect.

## 4. Pairing the Remote Control

Turn on the truck using the power switch located on its underside. Then, turn on the remote control. The remote and truck should automatically pair. If they do not pair, turn both off and then on again, ensuring they are close to each other.

Video 1: Demonstrates the NQD RC Truck's features, including battery installation and basic operation. (Source: NQD Official)

## OPERATING INSTRUCTIONS

### 1. Remote Control Functions

The 2.4Ghz remote control provides precise command over your truck. Familiarize yourself with the controls:

- **Forward/Backward Lever:** Push forward to move the truck forward, pull back to move backward.
- **Turn Left/Turn Right Lever:** Push left to turn left, push right to turn right.
- **Right Spray Button:** Press to activate the nitrogen spray effect from the rear of the truck.
- **Automatic Demonstration Button:** Press for an automated display of the truck's capabilities.
- **Indication Light:** Shows the remote's power status.



Figure 4: Detailed layout of the remote control functions.

## 2. Special Features

- **LED Headlights:** The truck is equipped with bright LED headlights, allowing for play even in low-light conditions.
- **Nitrogen Spray Effect:** Once water is added, activate the spray effect via the remote for a cool visual.
- **All-Terrain Capability:** The truck's design, with its large wheels and robust suspension, allows it to traverse various surfaces including flat ground, grass, muddy roads, and sand.



## Led Front Headlight & Rechargeable Battery

Play with your friends even in the dim light.



Figure 5: The truck's LED headlights provide visibility during play.



Figure 6: The NQD RC Truck is designed for diverse terrains.

Video 2: Showcases the NQD RC Truck's off-road capabilities and spray feature. (Source: NQD Official)

## MAINTENANCE

### 1. Cleaning

After use, especially after driving on dirty or wet surfaces, gently wipe down the truck with a dry or slightly damp cloth. Avoid using harsh chemicals or excessive water directly on electronic components.

### 2. Storage

Store the truck and remote control in a cool, dry place away from direct sunlight and extreme temperatures. For prolonged storage, remove batteries from both the truck and the remote control to prevent leakage and damage.

### 3. Battery Care

To maximize battery life, always fully charge the truck's rechargeable battery before first use and after each play session. Avoid overcharging or completely draining the battery. If the truck will not be used for an extended period, charge the battery partially (around 50%) before storing.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Truck does not move or respond to remote.	Low battery in truck or remote; not paired; power switch off.	Charge truck battery; replace remote batteries; ensure both are powered on and paired.
Spray effect not working.	No water in reservoir; clogged nozzle.	Refill water reservoir; gently clear nozzle if clogged.
Limited range or interference.	Obstructions; other 2.4Ghz devices nearby.	Move to an open area; minimize other wireless device usage.
Truck moves slowly or inconsistently.	Low truck battery; debris in wheels.	Recharge truck battery; inspect and clean wheels/axles.





## SPECIFICATIONS

- **Brand:** NQD
- **Model Number:** 757-C274-pink
- **Scale:** 1:14
- **Control Frequency:** 2.4Ghz
- **Truck Battery:** 3.7V/1200mAh Rechargeable
- **Remote Battery:** 2 x AA (not included)
- **Recommended Age:** 8 years and up
- **Item Weight:** 2.16 pounds
- **Package Dimensions:** 11.57 x 8.15 x 7.36 inches

## WARRANTY AND SUPPORT

The NQD team is committed to product quality. If you have any questions or encounter issues with your NQD 4WD Remote Control Truck, please contact our after-sales mailbox for prompt assistance and a satisfactory solution. For additional information, you may refer to the official User Manual (PDF) available for download in the product details section on the retailer's website.

For further assistance, please visit the [NQD Official Store](#).

 The image shows the packaging for the NPD 757-C271 Remote Control Monster Truck. It features a black and red remote control with a trigger and buttons. Text on the box includes 'NPD 757-C271', 'NPD Remote Control Monster Truck, 2.4GHz and Off Road Rock Crawler Vehicle, 1:16 Scale, 4WD, Rechargeable Battery, Toy', 'REMOTE CONTROL INSTRUCTION', '2.4GHz ANTI-INTERFERENCE', and 'INSTRUCTION OF CHARGING'. There is also a 'CAUTION' section at the bottom.	<p><a href="#">NPD 757-C271 Remote Control Monster Truck: 1:16 4WD Rock Crawler - Instructions &amp; Warranty</a></p> <p>Comprehensive guide for the NPD 757-C271 1:16 scale 4WD Remote Control Monster Truck. Includes remote control operation, battery charging instructions, and warranty information.</p>
 The image shows the packaging for the NPD Gesture Remote Control Car. It features a black and white remote control with a watch-like sensor. Text on the box includes 'NPD Gesture Remote Control Car', '2.4G Pairing', 'Battery Installation', and 'Precautions'.	<p><a href="#">NPD Gesture Remote Control Car Instruction Manual</a></p> <p>Comprehensive instruction manual for the NPD Gesture Remote Control Car (Model 757-C337), covering remote layout, watch sensor controls, 2.4G pairing, battery installation and precautions, charging instructions, car operation, troubleshooting, and customer service.</p>
 The image shows the packaging for the Powerextra Gesture RC Car. It features a blue and black remote control with a watch-like sensor. Text on the box includes 'Powerextra', 'GESTURE RC CAR', and '360° ROTATION'.	<p><a href="#">Powerextra Gesture RC Car 'Transfigured Person': Transformable Stunt Vehicle with Watch and Handle Remote Control</a></p> <p>Discover the Powerextra Gesture RC Car 'Transfigured Person', a versatile stunt vehicle offering dual control modes: watch gesture and traditional handle remote. Features include 360° rotation, 4WD, and multi-directional movement for exciting play. This manual covers battery installation, remote operation, and safety guidelines.</p>
 The image shows the packaging for the Shiningstone Kids Toy Phone. It features a black and white remote control with a watch-like sensor. Text on the box includes 'Shiningstone Kids Toy Phone', 'Dual Cameras', 'MP3 Player', 'Games', and 'Voice Recording'.	<p><a href="#">Shiningstone Kids Toy Phone: User Guide and Features</a></p> <p>Comprehensive user guide for the Shiningstone Kids Toy Phone, featuring dual cameras, MP3 player, games, and voice recording for children aged 3-6. Includes setup, usage, and safety instructions.</p>