

[Manuals.plus](#) /

› [Motorola](#) /

› Motorola Moto G Stylus User Manual

Motorola Moto G Stylus

Motorola Moto G Stylus User Manual

Model: Moto G Stylus

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your Motorola Moto G Stylus cell phone. The Moto G Stylus is designed to offer a versatile smartphone experience with its integrated stylus, advanced camera system, and responsive performance.



Image 1.1: The Motorola Moto G Stylus smartphone, showcasing its display and the integrated stylus.

2. SETUP

2.1. Inserting the SIM Card

1. Locate the SIM card tray on the side of your phone.
2. Insert the SIM ejector tool (or a small paper clip) into the small hole on the tray to open it.
3. Place your Nano-SIM card into the tray with the gold contacts facing down. Ensure it is correctly oriented.
4. Gently push the tray back into the phone until it clicks into place.

2.2. Initial Power On and Setup

- Press and hold the Power button until the Motorola logo appears.
- Follow the on-screen instructions to select your language, connect to Wi-Fi, and sign in with your Google account.
- You will be guided through setting up security features like fingerprint unlock or a PIN/pattern.

2.3. Charging the Device

Connect the USB-C cable to the charging port at the bottom of your phone and plug the other end into a power adapter. For optimal battery life, fully charge your device before first use.

3. OPERATING INSTRUCTIONS

3.1. Basic Functions

- **Power On/Off:** Press and hold the Power button. Select "Power off" or "Restart" from the menu.
- **Screen Lock/Unlock:** Press the Power button briefly to lock or unlock the screen.
- **Volume Control:** Use the Volume Up and Volume Down buttons on the side of the phone to adjust media, call, and alarm volumes.

3.2. Using the Built-in Stylus

The Moto G Stylus features an integrated stylus for enhanced precision and functionality.

- **Removing the Stylus:** Gently pull the stylus from its slot at the bottom right of the phone. A stylus menu will automatically appear on the screen.
- **Stylus Features:** Use the stylus for precise navigation, taking notes with the Moto Note app, drawing, editing photos, and more.
- **Inserting the Stylus:** Push the stylus back into its slot until it clicks securely.

3.3. Camera Operation

Your Moto G Stylus is equipped with a 48 MP triple camera system for high-quality photos and videos.

1. **Opening the Camera:** Tap the Camera icon on your home screen or double-twist your wrist while holding the phone.
2. **Taking Photos:** Tap the Shutter button on the screen.
3. **Recording Videos:** Switch to video mode and tap the Record button.
4. **Switching Cameras:** Tap the camera switch icon to toggle between front and rear cameras.
5. **Camera Modes:** Explore various modes like Portrait, Night Vision, Macro Vision, and Ultra-wide angle for different shooting scenarios.

3.4. Storage Management

The device comes with 128 GB of internal storage. To manage your storage:

- Go to **Settings > Storage** to view usage and free up space.

- Consider using cloud storage services or transferring files to a computer to optimize available space.

3.5. Display Features

The 6.4-inch Full HD+ Max Vision display offers an immersive viewing experience.

- **Brightness:** Adjust screen brightness from the Quick Settings panel or **Settings > Display**.
- **Dark Theme:** Enable Dark Theme for reduced eye strain in low light conditions.

4. MAINTENANCE

4.1. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.
- For the stylus, wipe gently with a dry cloth.

4.2. Battery Care

- Avoid extreme temperatures, which can degrade battery performance.
- Use only approved chargers and cables.
- For optimal long-term health, avoid consistently draining the battery to 0% or charging to 100%.

4.3. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > System > System updates**.

5. TROUBLESHOOTING

- **Device Not Responding:** If your phone freezes, press and hold the Power button for about 10-15 seconds to force a restart.
- **Network Issues:** If you experience problems with calls or mobile data, ensure your SIM card is properly inserted and airplane mode is off. Try restarting the device. Verify with your carrier that your plan is active and correctly provisioned for an unlocked device.
- **Battery Draining Quickly:** Check background app usage in **Settings > Battery**. Reduce screen brightness and disable unnecessary features like GPS or Wi-Fi when not in use.
- **Camera Not Working:** Ensure no other app is using the camera. Restart the phone. Clear the camera app's cache and data in **Settings > Apps > Camera > Storage**.
- **Stylus Not Responding:** Ensure the stylus is fully inserted and removed correctly. Restart the device.
- **Factory Reset (Last Resort):** If persistent issues occur, you may need to perform a factory reset. **Warning: This will erase all data on your phone. Back up important data before proceeding.** Go to **Settings > System > Reset options > Erase all data (factory reset)**.

6. SPECIFICATIONS

Feature	Detail
Model Name	Moto G Stylus
Brand	Motorola

Feature	Detail
Operating System	Android
Memory Storage Capacity	128 GB
Screen Size	6.4 Inches (Full HD+ Max Vision)
Resolution	1920 x 1080 pixels
Rear Camera	48 MP Triple Camera System
Front Camera	Yes
CPU Speed	1.4 GHz Octa-core processor
Connectivity Technology	Wi-Fi, 4G Cellular, GPS
Human Interface Input	Touchscreen with Stylus Support
Dimensions	15.99 x 8.99 x 1 inches
Item Weight	0.023 ounces
What's in the box	Stylus

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Motorola support website.

For further assistance, technical support, or to access additional resources, please visit the Motorola support portal.

[Motorola Official Support](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question