

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [E-Yooso](#) /

> [E-YOOSO K630 Mechanical Keyboard User Manual](#)

E-Yooso K630

E-YOOSO K630 Mechanical Keyboard User Manual

Model: K630 | Brand: E-Yooso

INTRODUCTION

This manual provides detailed instructions for the E-YOOSO K630 Mechanical Keyboard. Please read this guide thoroughly to ensure proper setup, operation, and maintenance of your device. The E-YOOSO K630 is a compact 87-key mechanical keyboard featuring low-profile blue switches and customizable rainbow backlighting, designed for both typing and gaming.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x E-YOOSO K630 Mechanical Keyboard
- 1 x USB Cable
- 1 x English User Manual

PRODUCT FEATURES

- **Compact 87-Key Layout:** Ultra-thin and light design, measuring approximately 350x120x12 mm and weighing 750g.
- **Low-Profile Blue Switches:** Provides tactile feedback and a distinct clicky sound, suitable for gaming and typing. Designed for a lifespan of up to 50 million clicks.
- **100% Anti-Ghosting:** Ensures every keystroke is registered accurately, even when multiple keys are pressed simultaneously.
- **Water-Resistant Design:** Constructed from top-grade ABS and metal material with a matte-finish texture. Features three drain holes for spill resistance.
- **Customizable Rainbow Backlighting:** Offers 9 different lighting modes, adjustable via function keys.
- **Durable Construction:** Features double-shot keycaps and a robust build for extended use.
- **Wide Compatibility:** Compatible with Windows XP, Vista, 7, 8, 10, and Mac operating systems. No additional drivers required.

SETUP

1. **Unpack the Keyboard:** Carefully remove the E-YOOSO K630 Mechanical Keyboard and its accessories from the packaging.
2. **Connect the USB Cable:** Insert the USB-C end of the provided cable into the port on the back of the keyboard.

3. **Connect to Computer:** Plug the standard USB-A end of the cable into an available USB port on your computer.
4. **Automatic Recognition:** The keyboard is plug-and-play. Your operating system should automatically detect and install the necessary drivers. No manual driver installation is required.



Image: The E-YOOSO K630 keyboard connected via its USB-C cable, highlighting its thin profile and connectivity.

OPERATING INSTRUCTIONS

Function Key Combinations (FN)

The keyboard features several function key combinations to control various settings and shortcuts:

- **FN + INS:** Cycles through 9 different backlight modes.
- **FN + W:** Swaps the WASD keys with the arrow keys. Press again to revert.
- **FN + Windows Key:** Locks the Windows key to prevent accidental presses during gaming. Press again to unlock.
- **FN + F12:** Locks the entire keyboard. Press again to unlock.
- **FN + F1-F12:** Accesses various multimedia and system shortcuts (e.g., calculator, email, web browser, volume control).

Backlight Adjustment

The brightness and speed of the looped lighting effects can be adjusted:

- **FN + Up Arrow Key:** Increases backlight brightness.
- **FN + Down Arrow Key:** Decreases backlight brightness.
- **FN + Left Arrow Key:** Adjusts the speed of looped lighting effects (slower).
- **FN + Right Arrow Key:** Adjusts the speed of looped lighting effects (faster).



Image: A close-up view of the E-YOOSO K630 keyboard, highlighting the illuminated keys and the blue mechanical switches beneath the keycaps.



Image: A user's hands actively typing on the E-YOOSO K630 mechanical keyboard, showcasing its rainbow backlighting in use.

MAINTENANCE

To ensure the longevity and optimal performance of your E-YOOSO K630 Mechanical Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For dust and debris between keys, use compressed air.
- **Spill Management:** While the keyboard is water-resistant, it is not waterproof. In case of a spill, immediately disconnect the keyboard from your computer, turn it upside down to drain liquid, and allow it to dry completely before reconnecting.
- **Keycap Removal:** Keycaps can be carefully removed for deeper cleaning or switch replacement using a keycap puller (not included). Exercise caution to avoid damaging the switches.
- **Storage:** Store the keyboard in a clean, dry environment away from extreme temperatures and direct sunlight.



Image: The underside of the E-YOOSO K630 keyboard, illustrating its adjustable rear feet, USB Type-C port, and water-resistant design with drain holes.

TROUBLESHOOTING

If you encounter issues with your E-YOOSO K630 Mechanical Keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and the computer.
- Try plugging the keyboard into a different USB port on your computer.
- Restart your computer.
- Check if the keyboard lock (FN+F12) is activated.

- **Backlighting Not Working:**

- Ensure the backlight brightness is not set to minimum (FN + Up Arrow Key to increase).

- Cycle through backlight modes using FN + INS.

- **Keys Not Registering:**

- Clean around the affected keys to remove any debris.
- Ensure the keyboard is not locked (FN+F12).

- **Windows Key Locked:**

- Press FN + Windows Key to unlock the Windows key.

SPECIFICATIONS

Feature	Detail
Model Number	K630
Keyboard Type	Mechanical, 87-Key Compact
Switch Type	Low-Profile Blue Switches
Key Durability	Up to 50 million clicks
Connectivity	USB (Wired)
Backlighting	Rainbow LED, 9 modes
Anti-Ghosting	100% Anti-Ghosting with 87 Key Roll-over
Material	ABS and Metal
Dimensions (LxWxH)	Approximately 350 x 120 x 12 mm (13.7" x 4.7" x 0.47")
Weight	Approximately 750g (26.45 oz)
Operating System Compatibility	Windows XP/Vista/7/8/10, Mac
Special Features	Water Resistant, Backlit, Multimedia Shortcuts

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact E-Yooso customer service through their official website. Keep your purchase receipt as proof of purchase for warranty claims.