



Manuals.plus /

› **ORIGBELIE** /

› ORIGBELIE External DVD Drive User Manual

ORIGBELIE BT668

ORIGBELIE External DVD/CD Drive User Manual

MODEL: BT668

External DVD Drive, CD Drive USB 3.0 Type C CD/DVD ROM +/-RW Adapter with USB Port DVD Burner for Laptop PC Desktop Computer, Optical Disk Drive CD Player Compatible with Mac Windows Linux

1. Introduction and Overview

The ORIGBELIE External DVD/CD Drive is a versatile and portable optical drive designed to provide CD and DVD read/write capabilities to modern computers that may lack a built-in drive. It features high-speed USB 3.0 and Type-C connectivity, ensuring fast data transfer rates. This device is ideal for installing software, playing movies or music, backing up data, and burning your precious memories onto discs.



Figure 1: The ORIGBELIE External DVD Drive, showcasing its compact design and included accessories.

2. What's in the Box

- External CD DVD Drive x 1
- USB A to DC Power Supply Cable x 1
- Drive Storage Bag x 1
- User Manual x 1




Figure 2: All items included in the ORIGBELIE External DVD Drive package.

3. Setup

The ORIGBELIE External DVD Drive is designed for plug-and-play functionality, requiring no driver installation for most operating systems. Simply connect the drive to your computer using the integrated USB cable.

1. Locate an available USB 3.0 or Type-C port on your laptop or desktop computer.
2. Connect the integrated USB cable from the external DVD drive to the chosen USB port on your computer.
3. The drive will be automatically detected by your operating system.
4. For optimal performance, especially when burning discs or if your computer's USB ports provide insufficient power, connect the additional USB A to DC Power Supply Cable to a separate USB port or an external 5V power adapter (not included).



Figure 3: Connecting the external DVD drive to a laptop.

4. Operating the Device

4.1 Inserting and Ejecting Discs

- To open the disc tray, press the 'IN/OUT' button located on the front of the drive. The tray will pop out.
- Carefully place your CD or DVD onto the tray, ensuring it is centered on the spindle.
- Gently push the tray back into the drive until it clicks into place.
- To eject a disc, press the 'IN/OUT' button again.



Figure 4: The pop-up disc tray design for smooth insertion and removal.

4.2 Reading and Writing Discs

Once a disc is inserted, your computer's media player or file explorer will typically recognize it. You can then play media, access files, or use burning software to write data to compatible discs. The drive supports Max 8x DVDR Read Speed and Max 24x CD Write/Read speed.

4.3 Using Additional Ports

This drive includes additional ports for enhanced functionality:

- **USB Ports:** Two additional USB 2.0 ports are available for connecting other peripherals like USB flash drives, mice, or keyboards.
- **TF and SD Card Reader Ports:** Directly insert TF (MicroSD) or SD cards to access their contents.
Note: SD and TF card ports are not to be used at the same time.



Figure 5: Detailed view of the multi-functional ports on the drive.

5. Compatibility

The ORIGBELIE External DVD Drive offers wide compatibility with various operating systems and devices:

- **Compatible Operating Systems:** Windows XP / 2003 / Win 11 / Win 10 / Win 8 / Win 7 / Vista / Linux / Mac OS X systems. (Windows 11 requires media player and network).
- **Compatible Devices:** Laptops, computers, notebooks, and desktops.
- **Supported Disc Formats:** CD±R/RW, CD-ROM, DVD±R/RW, DVD-RAM, VCD, and SVCD.

Widely Compatible



USB 3.0 High Speed

24X CD Read/Write **8X** DVD Read/Write



Figure 6: Wide compatibility across different operating systems.

5.1 Incompatible Devices and Formats

Please note the following incompatibilities:

- **Devices:** This DVD RW drive can only start its job after it is connected to a laptop or a desktop. It is **NOT COMPATIBLE** with cars, projectors, tablets, iPads, mobile phones, Chromebook, or Surface devices.
- **Disc Formats:** Blu-ray format is **NOT SUPPORTED**.



Embedded Dual Data Cable

Suitable for USB-A and USB-C port computers and other devices



Figure 7: Devices and formats not supported by the drive.

6. Troubleshooting

- **Drive Not Detected:** Ensure the USB cable is securely connected to a functioning USB 3.0 or Type-C port on your computer. Try a different USB port.
- **Insufficient Power Supply:** If the drive is not functioning stably (e.g., disc reading errors, slow performance), it may not be receiving enough power. Connect the additional USB A to DC Power Supply Cable to another USB port or an external 5V power adapter.
- **No Driver Needed:** The drive is plug-and-play. No manual driver installation is required. If your system prompts for a driver, ensure your operating system is up-to-date.
- **Disc Stuck/Forced Ejection:** In rare cases, if the disc tray does not open by pressing the 'IN/OUT' button, locate the small pinhole next to the button. Gently insert a straightened paperclip into the pinhole to manually eject the tray.
- **Windows 11 Specifics:** For Windows 11, ensure you have a media player installed and an active network connection for full functionality.

For more detailed troubleshooting steps, please refer to the official User Manual PDF [User Manual \(PDF\)](#)

7. Maintenance

- Keep the drive clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the drive to extreme temperatures or humidity.
- Handle discs carefully to prevent scratches or damage, which can affect readability.
- Store the drive in its provided storage bag when not in use to protect it from scratches and impacts.

8. Specifications

Feature	Description
Brand	ORIGBELIE
Model Number	BT668
Interface	USB 3.0 & Type-C
Optical Drive Type	CD±R/RW, CD-ROM, DVD±R/RW, DVD-RAM, VCD, SVCD
Max DVD Read Speed	8x
Max CD Write/Read Speed	24x
Additional Ports	2x USB 2.0, 1x TF (MicroSD) slot, 1x SD slot
Power Source	USB 3.0 Type C (5V DC)
Item Weight	12.3 ounces
Product Dimensions	5.71 x 5.51 x 0.63 inches

9. Warranty and Support

ORIGBELIE provides up to **2-year after-sales support** for this product. For any inquiries, technical assistance, or warranty claims, please refer to the contact information provided in the official User Manual or on the ORIGBELIE brand store.

Official User Manual (PDF): [Download Here](#)