CREATE SILKAIR HOME 36L

CREATE SILKAIR HOME Portable Air Conditioner 3-in-1 User Manual

Model: SILKAIR HOME 36L (205094_549725)

Brand: CREATE

1. Important Safety Information

Please read all instructions carefully before using this appliance. Retain this manual for future reference.

- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the unit with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Always place the unit on a flat, stable surface.
- Maintain a minimum distance of 30 cm (12 inches) from walls or other objects to ensure proper airflow.
- Do not insert objects into the air inlet or outlet.
- Unplug the appliance before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2. Product Overview

The CREATE SILKAIR HOME portable air conditioner is a versatile 3-in-1 unit designed to cool, dehumidify, and ventilate rooms up to 26m².

2.1 Components

- Main Unit (Portable Air Conditioner)
- Exhaust Hose
- Window Sealing Kit
- Remote Control
- Drain Hose (for continuous dehumidification)

2.2 Features

- **3-in-1 Functionality:** Cooling, Dehumidification, and Fan modes.
- **Cooling Capacity:** 7000 BTU, suitable for rooms up to 26m².
- **Dehumidification:** Up to 36 liters per day.
- **Control Options:** LED display panel and remote control.
- **Timer Function:** 24-hour programmable timer for automatic on/off.
- **Sleep Mode:** Adjusts airflow and reduces noise and power consumption for comfortable sleep.
- **Window Kit:** Includes an exhaust and air insulation kit for easy installation in sliding and hinged windows.


CREATE

Figure 1: Front view of the CREATE SILKAIR HOME portable air conditioner, showing the air outlet louvers and the brand logo at the bottom.



Figure 2: The portable air conditioner positioned in a modern room setting, demonstrating its compact size and aesthetic integration.

3. Setup and Installation

Proper installation is crucial for efficient operation. This unit requires an exhaust hose to vent hot air outside.

3.1 Exhaust Hose Installation

1. Attach one end of the exhaust hose to the air outlet port on the back of the unit. Ensure it is securely fastened.
2. Extend the exhaust hose to the nearest window or opening.
3. Install the window sealing kit (provided) to create a seal around the window opening and the exhaust hose. This prevents hot air from re-entering the room.
4. Ensure the exhaust hose is as short and straight as possible to maximize cooling efficiency. Avoid kinks or sharp bends.



Figure 3: Close-up view of the exhaust hose securely connected to the rear port of the portable air conditioner, ready to vent hot air.

3.2 Electrical Connection

- Plug the power cord into a grounded electrical outlet.
- Do not use extension cords or multi-plugs with this appliance.

4. Operating Instructions

The unit can be operated using the control panel on top of the unit or the included remote control.

4.1 Control Panel



Figure 4: Detailed view of the top control panel with LED display and various function buttons, being pressed by a finger.

- **Power Button:** Turns the unit on or off.

- **Mode Button:** Cycles through Cooling, Dehumidification, and Fan modes.
- **Temperature Up/Down Buttons:** Adjusts the desired temperature in Cooling mode.
- **Fan Speed Button:** Selects fan speed (Low, Medium, High).
- **Timer Button:** Sets the 24-hour timer.
- **Sleep Button:** Activates Sleep Mode.

4.2 Remote Control



Figure 5: A hand holding the remote control, which features buttons for power, mode selection, temperature adjustment, and other functions.

The remote control duplicates the functions of the control panel, allowing convenient operation from a distance. Ensure batteries are correctly inserted.

4.3 Operating Modes

- **Cooling Mode:** Select this mode for active cooling. Adjust the temperature using the Up/Down buttons. The unit will cool the room to the set temperature.
- **Dehumidification Mode:** In this mode, the unit removes excess moisture from the air. The fan speed is typically fixed to low, and temperature cannot be adjusted. Ensure the drain hose is connected for continuous drainage or regularly empty the internal water tank.
- **Fan Mode:** The unit operates as a fan, circulating air without cooling. Select desired fan speed (Low, Medium, High).

4.4 Timer Function

The 24-hour timer allows you to program the unit to turn on or off automatically.

1. Press the **Timer** button.
2. Use the Up/Down buttons to set the desired delay time (in hours) for the unit to turn on or off.
3. The timer indicator will illuminate.

4.5 Sleep Mode

Activate Sleep Mode for quieter operation and reduced energy consumption during sleep.

- Press the **Sleep** button.
- The unit will gradually increase the set temperature by 1°C after the first hour and another 1°C after the second hour, maintaining this temperature for 6 hours before turning off. Fan speed will be set to low.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your appliance.

5.1 Cleaning the Air Filter

- Turn off and unplug the unit before cleaning.
- Locate the air filter (usually at the back or side of the unit).
- Remove the filter and clean it with a vacuum cleaner or wash it with lukewarm water and mild detergent.
- Allow the filter to dry completely before reinserting it.
- Clean the filter every two weeks or more frequently if the unit is used in a dusty environment.

5.2 Draining Water

The unit collects condensed water during cooling and dehumidification. It has an internal water tank that needs to be emptied, or a continuous drain hose can be used.

- When the internal tank is full, the unit will stop operating and display an indicator.
- Turn off and unplug the unit.
- Locate the drain plug at the bottom rear of the unit.
- Place a shallow pan or container under the drain plug.

- Remove the drain plug to allow water to flow out.
- For continuous drainage, attach the provided drain hose to the drain outlet and direct it to a suitable drain.

6. Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply. Power cord not plugged in. Internal water tank full.	Check power outlet. Ensure power cord is securely plugged in. Empty the water tank.
Unit is running but not cooling.	Exhaust hose not properly installed. Air filter is dirty. Room size too large. Doors/windows open.	Ensure exhaust hose is venting hot air outside and window kit is sealed. Clean the air filter. Ensure unit is used in a room within its specified capacity (up to 26m²). Close all doors and windows.
Unit is noisy.	Unit not on a flat surface. Air filter dirty. Obstruction in fan.	Place unit on a flat, stable surface. Clean the air filter. Turn off and unplug, then check for obstructions.
Water leakage.	Drain plug not securely closed. Drain hose not properly connected.	Ensure drain plug is tightly closed. Check drain hose connection and ensure it is not blocked.

7. Specifications

Feature	Specification
Brand	CREATE
Model Name	SILKAIR HOME 36L
Model Number	205094_549725
Product Dimensions (L x W x H)	28.8 x 29.7 x 69.7 cm (11.3 x 11.7 x 27.4 inches)
Cooling Capacity	7000 BTU
Dehumidification Capacity	Up to 36 Liters/Day
Rated Power	780 Watts
Voltage	240 Volts
Material	ABS
Room Coverage	Up to 26 m²

Feature	Specification
Energy Efficiency Class	A
Installation Type	Window (with included kit)
Special Features	Rapid Cooling, 24h Timer, Sleep Mode

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official CREATE website. Please have your model number (205094_549725) and purchase date ready when contacting support.
You can also visit the CREATE store on Amazon for more information:CREATE Amazon Store

© 2024 CREATE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question