**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Noma B08B2M7WLS

# NOMA LED Advanced Cluster Christmas Lights

### User Manual

**Model: B08B2M7WLS**

## Product Overview

The NOMA LED Advanced Cluster Christmas Lights are designed to provide a vibrant and energy-efficient lighting solution for both indoor and outdoor environments. Featuring 1000 super-bright, shimmer-free LED bulbs and Constant-Lit Advanced Strand Technology, these lights ensure continuous illumination even if individual bulbs are loose or burnt out. The integrated control box offers 7 distinct lighting effects to customize your display.




Image: NOMA LED Advanced Cluster Christmas Lights on their storage reel, highlighting key features such as 7 lightshow options, advanced strand technology, weather-sealed sockets, and a 3-year limited warranty. The reel also indicates 1000 3mm LED bulbs, 83.75 ft length, and 22.8W total wattage.

## Setup Instructions

1. **Unpack and Unspool:** Carefully remove the lights from their reusable reel. Ensure the strand is free of tangles before installation.
2. **Placement:** These lights are suitable for both indoor and outdoor use. Common applications include decorating Christmas trees, mantels, railings, windows, doors, and patios. Ensure the chosen location is stable and allows for proper light distribution.
3. **Power Connection:** Locate a standard electrical outlet. Plug the light strand into the outlet. Ensure the connection is secure and protected from moisture if used outdoors, as the sockets are sealed for weather resistance.



## 7 Changing Effects

The 7 effects create a perfect light show for you and your family

## Indoor & Outdoor

Simple to install on your Christmas tree, mantel, railing, and entryway

## 1000 Energy-Efficient LEDs

Go green with 1000 long-lasting energy-efficient LED bulbs

Image: A close-up view of the NOMA LED Cluster Lights wound on their reel, accompanied by text emphasizing the product's 7 changing effects and its suitability for both indoor and outdoor installation.



Image: NOMA LED Cluster Lights elegantly draped across a mantelpiece, demonstrating an indoor application of the product.



Image: NOMA LED Cluster Lights strung along an outdoor railing, lightly covered in snow, showcasing their weatherproof design and suitability for outdoor use.

## Operating Instructions

The NOMA LED Advanced Cluster Christmas Lights feature an integrated control box that allows you to select from 7 different lighting effects. The lights will illuminate once plugged into a power source.

### Lighting Effects:

Use the button on the control box to cycle through the following modes:

- **Steady:** Lights remain continuously on.
- **Fast Fade:** Lights fade in and out quickly.
- **Slow Fade:** Lights fade in and out slowly.
- **Fast Flip:** Lights quickly switch on and off.
- **Slow Flip:** Lights slowly switch on and off.
- **Fast Flash:** Lights flash rapidly.

- **Slow Flash:** Lights flash slowly.

### Constant-Lit Advanced Strand Technology:

This technology ensures that the entire string of lights remains illuminated even if one or more individual bulbs become loose or burn out. This significantly reduces the need for individual bulb replacement and maintains a consistent light display.





Image: A detailed close-up of five individual NOMA LED light bulbs, visually representing the Constant Lit Strand Technology, which ensures the string remains lit even if a bulb fails.

## Maintenance

- **Cleaning:** If necessary, gently wipe the lights with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the lights are unplugged before cleaning.
- **Storage:** For off-season storage, carefully wind the lights back onto their reusable reel. Store in a cool, dry place away from direct sunlight and extreme temperatures to prolong their lifespan.
- **Weather Resistance:** The lights are designed with sealed sockets and are completely weatherproof. However, for optimal longevity, avoid prolonged submersion in water or exposure to extreme weather conditions beyond their intended use.

## Troubleshooting

- **Lights Not Turning On:**
  - Ensure the power plug is fully inserted into a working electrical outlet.
  - Check if the outlet itself is receiving power (e.g., by plugging in another device).
- **Effects Not Changing:**
  - Press the button on the control box firmly to cycle through the modes.
  - If the control box is unresponsive, unplug the lights for a few seconds and then plug them back in to reset.
- **Individual Bulbs Out:**
  - Due to Constant-Lit Advanced Strand Technology, the entire string should remain lit even if a bulb is loose or burnt out. If a section is out, check for any visible damage to the wire or connections in that section.

## Specifications

| Feature | Detail |
|---|---|
| Bulb Type | LED, 3mm |
| Bulb Count | 1000 |
| Strand Length | 83.75 feet (approx. 25.5 meters) |
| Power Source | Plug-in |
| Wattage | 22.8 W |
| Usage | Indoor / Outdoor |
| Special Features | Constant-Lit Advanced Strand Technology, Weather-Sealed Sockets, 7 Changing Effects |
| Bulb Lifespan | Up to 30,000 hours |
| Color | White |
| Manufacturer | NOMA |
| ASIN | B08B2M7WLS |

## Warranty Information

This NOMA LED Advanced Cluster Christmas Lights product includes a**3-year limited warranty** from the date of

purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims.

## Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact NOMA customer support. Refer to the product packaging or the NOMA official website for the most current contact information.

© 2024 NOMA. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B08B2M7WLS**

More documents and user manuals: **https://manuals.plus/**