

[Manuals.plus](#) /

› [Soul Electronics](#) /

› Soul S-FIT True Wireless Earbuds - Instruction Manual (Model SS57PP)

Soul Electronics SS57PP

Soul S-FIT True Wireless Earbuds - Instruction Manual

Model: SS57PP

INTRODUCTION

Thank you for choosing the Soul S-FIT True Wireless Earbuds. These earbuds are designed for active lifestyles, featuring a waterproof and shock-resistant build, customizable fit, Bluetooth 5.0 connectivity, and a transparency mode for enhanced situational awareness. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

Upon unboxing your Soul S-FIT True Wireless Earbuds, you should find the following items:

- Soul S-FIT True Wireless Earbuds (Left and Right)
- Charging Case
- Multiple sets of interchangeable wing tips (various sizes for a secure fit)
- Multiple sets of ear tips (small, medium, large)
- Carabiner (for attaching the charging case)
- USB-C to USB-A Charging Cable



ERGONOMIC DESIGN |

 **freebit™**
WING SHAPED EARLOCK



Image: Contents of the Soul S-FIT Earbuds package, including earbuds, charging case, and various ear tips.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and the other end to a USB-A power source. An indicator light on the back of the case will show the battery level during charging.



Image: The Soul S-FIT earbuds resting in their charging case.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
3. Select "Soul S-FIT" from the list of available devices.
4. Once connected, you will hear an audio prompt confirming successful pairing.

OPERATING INSTRUCTIONS

Touch Controls

The Soul S-FIT earbuds feature intuitive touch gestures for media control and call management. Refer to the detailed user guide for a complete list of touch commands.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.

- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.

Transparency Mode

Transparency Mode allows you to hear your surroundings while listening to audio, enhancing safety during outdoor activities. To activate or deactivate Transparency Mode, press and hold the touch sensor on either earbud for a few seconds.



Extreme Durability

Adhere to IP67 water and dust-proof protection rating, S-FIT are designed with added protection from exposure to sweat, rain, and even dust. What's more, we even engineered the S-FIT to take on a beating with a Military Standard 810H-516.8 impact resistance test for extra durability.

**Made for All Conditions**
IP67 Rating:
Water & Dust Resistant

**Military Standard
Impact Resistance**
Tested to endure abuse

Image: Visual representation of the Audio Transparency feature.

CUSTOMIZABLE FIT

The S-FIT earbuds come with multiple sizes of ear tips and Freebit™ wing-shaped ear locks to ensure a secure and comfortable fit for various ear shapes. Experiment with different combinations to find the best fit for your ears, especially during physical activities.

Powerful Hi-Definition Sound Engineering

Designed to push you through your toughest training and workouts, powerful and motivating sound HD quality with Bluetooth 5.0 technology, AAC and SBC Codec are at the core of the S-FIT.



Image: Ergonomic design with Freebit™ wing-shaped earlock for a secure fit.

BATTERY LIFE AND CHARGING

The Soul S-FIT earbuds offer extended listening times:

- **Earbuds:** Up to 6 hours of listening time on a single charge.
- **Charging Case:** Provides an additional 27 hours of battery life.
- **Total Playtime:** Up to 33 hours with the charging case.

To charge the case, use the provided USB-C cable. The case is compact and designed to be easily carried in a pocket without bulging.



Safety First

Audio Transparency Mode lets you hear your surroundings while you keep your earphones on. Great for conversations and most importantly added safety when you are on the road.

Image: Illustration of the 33-hour total battery life.

DURABILITY

The Soul S-FIT earbuds are built to withstand challenging environments:

- **IP67 Water & Dust Proof:** The earbuds are fully protected against dust ingress and can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for use during workouts, in the rain, or even for swimming.
- **Military-Grade Shock Resistance:** Designed to endure drops and impacts, ensuring durability for active use.

Move in Comfort

No ear is the same. We partnered with Freebit, a patented ergonomic solution to customize a set of secure and comfortable wing-shaped locks to ensure the S-FIT to stay in your ears. Various sizes of interchangeable eartips are also included to enhance your listening experience.



Image: IP67 Water & Dust Proof feature.

AUDIO QUALITY

The Soul S-FIT earbuds deliver a powerful audio experience with a focus on deep and rich bass. This makes them particularly well-suited for genres like pop and rap music, where a strong bass presence is desired. While the bass is prominent, it may occasionally overshadow the mid and high frequencies, leading to a less balanced sound profile for genres that require more intricate detail in those ranges, such as rock music.

MICROPHONE QUALITY

The integrated microphone provides clear audio for voice calls and virtual meetings. While sufficient for general communication, it is not optimized for professional streaming or high-fidelity audio production tasks.

Your browser does not support the video tag.

Video: A review of the Soul S-Fit Wireless Earbuds, including a microphone test. This video demonstrates the microphone's performance in a typical indoor setting.

SPECIFICATIONS

Brand	Soul Electronics
Model Number	SS57PP
Ear Placement	In Ear
Connectivity Technology	Wireless (Bluetooth 5.0)
Water Resistance Level	IP67 (Waterproof & Dustproof)
Shock Resistance	Military-Grade

Earbud Battery Life	Up to 6 hours
Total Battery Life (with case)	Up to 33 hours
Control Type	Touch Control
Specific Uses	Sports and Exercise

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.
- **Water Exposure:** While waterproof, it is recommended to dry the earbuds thoroughly before placing them back in the charging case to prevent damage to the charging contacts.

TROUBLESHOOTING

- **No Sound/Connection Issues:**
 - Ensure both earbuds are charged.
 - Verify Bluetooth is enabled on your device and "Soul S-FIT" is selected.
 - Try unpairing and re-pairing the earbuds with your device.
 - Reset the earbuds (refer to the full user manual for specific reset instructions).
- **Earbuds Not Charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
 - Try a different USB-C cable or power adapter.
- **Uncomfortable Fit:**
 - Experiment with different sizes of ear tips and wing tips provided to find the most secure and comfortable fit.

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please visit the official Soul Electronics website or contact their customer service department. Keep your proof of purchase for warranty claims.

Soul Electronics Store: [Visit Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question