Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aquasonic AQDP8

AquaSonic Duo PRO Replacement Brush Heads User Manual

Model: AQDP8

Product Overview

The AquaSonic Duo PRO 8-Pack Replacement Brush Heads are designed to provide an enhanced cleaning experience for your AquaSonic electric toothbrush. These ProFlex brush heads feature an upgraded design for improved plaque removal and whitening.



Image: The AquaSonic Duo PRO 8-Pack Replacement Brush Heads, showing the packaging and the eight individual brush heads (four white, four black) with protective caps.

Each pack contains 8 brush heads: 4 white and 4 black, ensuring you have replacements for an extended period. They are equipped with precisely angled bristles, featuring alternating hard and soft areas for effective cleaning that is gentle on gums and tough on plaque.



Image: A ProFlex replacement brush head shown next to a smiling woman, illustrating the product's focus on oral health and aesthetics.



Image: A detailed close-up of the AquaSonic ProFlex brush head bristles. Arrows indicate how the soft bristles around the perimeter are gentle on gums, while firmer bristles at the center effectively remove plaque.

Compatibility

These AquaSonic ProFlex Replacement Brush Heads are specifically designed for compatibility with the following AquaSonic electric toothbrush models:

- Black Series
- Black Series Pro
- Vibe Series
- Vibe Series Pro
- HDC Pro
- Duo Series Pro
- Elite



Image: An AquaSonic toothbrush handle displayed alongside a list of compatible AquaSonic toothbrush models, ensuring users can verify fit.

Important Note: These brush heads are *not compatible* with the original AquaSonic Duo model. They are exclusively for the Duo PRO and other listed models.



Image: A visual warning indicating that the replacement brush heads are not compatible with the original AquaSonic Duo toothbrush, featuring a red circle with a cross over the incompatible model.

Setup and Installation

1. **Remove Old Brush Head:** Gently pull the existing brush head straight off the toothbrush handle. Do not twist.
2. **Select New Brush Head:** Choose a new AquaSonic ProFlex Replacement Brush Head from the pack.
3. **Attach New Brush Head:** Align the new brush head with the metal shaft on the toothbrush handle. Push the brush head down firmly until it clicks into place. Ensure it is securely seated.
4. **Initial Rinse:** Before first use, rinse the new brush head thoroughly under running water.

Operating Instructions

Once the brush head is installed, operate your AquaSonic electric toothbrush according to its specific model's instructions. The ProFlex brush heads are designed to work seamlessly with the various brushing modes of compatible AquaSonic

toothbrushes.

- Apply a small amount of toothpaste to the bristles.
- Place the brush head against your teeth at a slight angle towards the gumline.
- Turn on the toothbrush and gently guide the brush head across all surfaces of your teeth. Allow the sonic vibrations to do the cleaning.
- Brush each quadrant of your mouth for approximately 30 seconds, ensuring thorough coverage.

Maintenance and Care

Proper maintenance of your brush heads ensures optimal performance and hygiene.

- **Daily Cleaning:** After each use, rinse the brush head thoroughly under running water to remove any toothpaste residue and debris.
- **Storage:** Store the brush head with its protective cap in a clean, dry place to prevent contamination.
- **Replacement Schedule:** For optimal brushing performance and hygiene, it is recommended to change your brush head every 3 to 4 months. Change the brush head sooner if the bristles appear frayed or worn.



Image: A visual reminder to change your brush head every 3-4 months for healthier teeth and gums, and fresher breath.



Image: The back of the AquaSonic ProFlex Replacement Brush Heads packaging, detailing care instructions such as rinsing bristles after each use and changing the brush head every 3 months for optimal performance.

Troubleshooting

Common Issues and Solutions

Issue	Possible Cause	Solution
Brush head does not fit.	Incorrect model compatibility.	Ensure your toothbrush model is listed under the "Compatibility" section. These heads are not compatible with the original AquaSonic Duo.
Bristles appear worn quickly.	Excessive pressure during brushing or prolonged use.	Brush with lighter pressure. Replace the brush head if bristles are splayed or discolored.

Issue	Possible Cause	Solution
Brush head feels loose.	Improper installation.	Remove and re-attach the brush head, ensuring it clicks securely into place.

Specifications

Feature	Detail
Product Name	AquaSonic Duo PRO Replacement Brush Heads
Model Number	AQDP8
Package Quantity	8 Count (4 White, 4 Black)
Material	Nylon bristles
Age Range	Adult
ADA Acceptance	Yes
Package Dimensions	9.13 x 5.16 x 1.22 inches
Item Weight	3.53 ounces
Manufacturer	AquaSonic
Date First Available	June 12, 2020

Warranty and Support

For any questions regarding the AquaSonic Duo PRO Replacement Brush Heads, including product performance or compatibility, please contact AquaSonic customer support directly. Refer to the official AquaSonic website or product packaging for the most current contact information.

While specific warranty details for replacement brush heads are not provided, AquaSonic stands by the quality of its products. If you experience any issues, please reach out to the manufacturer for assistance.

Manufacturer: AquaSonic
Website: www.aquasonic.com (Please note: This is a placeholder URL as no specific support URL was provided in the data. Users should refer to official product documentation.)

© 2025 AquaSonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08B3GTDQZ

More documents and user manuals: **https://manuals.plus/**