SENSYNE sensyne

Sensyne 10" Ring Light with 50" Extendable Tripod Stand User Manual

Model: sensyne | Brand: SENSYNE

Introduction

Thank you for choosing the Sensyne 10" Ring Light with 50" Extendable Tripod Stand. This manual provides essential information for setting up, operating, and maintaining your new ring light. Designed for content creators, photographers, and anyone needing enhanced lighting, this versatile kit offers adjustable brightness, color temperature, and a stable platform for your smartphone.

Product Components

Before assembly, please ensure all components listed below are present in your package:

- 10-inch LED Ring Light
- Extendable Tripod Stand (15.7 to 50 inches)
- Universal Phone Holder
- Bluetooth Wireless Remote Shutter
- USB Power Cable
- Carry Bag



Figure 1: All included components of the Sensyne Ring Light kit.

Setup Instructions

1. **Unpack Components:** Carefully remove all items from the carry bag and packaging.
2. **Set Up Tripod Stand:** Extend the tripod legs to a stable position. Adjust the height by loosening the clamps on each section of the tripod legs and extending them to your desired height (from 15.7 inches to 50 inches). Securely tighten the clamps once the desired height is reached.
3. **Attach Ring Light:** Screw the 10-inch LED ring light onto the top of the tripod stand. Ensure it is firmly attached.
4. **Install Phone Holder:** Insert the universal phone holder into the center of the ring light. The holder is spring-loaded and can extend up to 5.3 inches wide to accommodate most smartphones.
5. **Connect Power:** Plug the USB power cable into the ring light's USB port. Connect the other end to a compatible USB power source (e.g., a 10W [5V 2A] USB wall adapter, power bank, or computer USB port).
6. **Pair Remote Shutter (Optional):** Turn on the Bluetooth remote shutter. On your smartphone, go to Bluetooth settings and pair with "Sensyne" (no app download required).



Figure 2: Assembled ring light with phone holder.

Operating Instructions

Ring Light Controls:

The ring light features a high-sensitivity touch panel for easy adjustments:

- **Power Button (ON/OFF):** Press to turn the ring light on or off.
- **Brightness Adjustment (+/-):** Use the '+' button to increase brightness and the '-' button to decrease brightness. There are 10 adjustable brightness levels.
- **Color Mode Selection (Circle Icon):** Press this button to cycle through the 3 available color modes: cool white, warm yellow, and daylight.



Figure 3: Touch control panel for light adjustments.

Phone Holder Adjustment:

The phone holder allows for flexible positioning:

- The phone holder can be rotated 360 degrees to switch between portrait and landscape orientations.
- The angle of the ring light and phone holder can be adjusted using the knob on the tripod head to tilt it forward or backward.



Figure 4: Adjustable phone holder and ring light angle.

Wireless Remote Shutter:

Once paired, the pocket-sized Bluetooth remote allows you to:

- Take selfies or group photos from a distance of up to 30 feet.
- It is compatible with most Apple/Android smartphones (e.g., iPhone 8/7/6 Series, Samsung Galaxy Series).
- No additional app download is necessary for its operation.




Figure 5: Bluetooth wireless remote shutter.

Maintenance and Care

- Keep the ring light and tripod clean by wiping them with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Ensure the tripod legs are fully extended and locked when in use to prevent accidental tipping.
- Store the unit in its provided carry bag when not in use to protect it from dust and damage.
- Avoid exposing the ring light to extreme temperatures or direct moisture.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ring light does not turn on.	No power, loose connection, or faulty USB adapter.	Ensure the USB cable is securely connected to both the ring light and a working power source. Try a different USB adapter (recommended 10W/5V 2A).
Remote shutter not pairing.	Remote battery low, Bluetooth not enabled on phone, or remote not in pairing mode.	Check remote battery (1 Lithium Metal battery included). Ensure Bluetooth is enabled on your phone and the remote is turned on and discoverable. Restart both devices if necessary.
Tripod is unstable.	Legs not fully extended or locked, uneven surface.	Fully extend and securely lock all tripod leg sections. Place the tripod on a flat, stable surface.

Specifications

- **Ring Light Diameter:** 10 inches
- **Tripod Extendable Height:** 15.7 inches to 50 inches
- **Color Modes:** 3 (Cool White, Warm Yellow, Daylight)
- **Brightness Levels:** 10
- **Connectivity:** USB (for light), Bluetooth (for remote)
- **Phone Holder Compatibility:** Up to 5.3 inches wide (fits most smartphones with or without case)
- **Item Weight:** 2.27 pounds
- **Power Input:** USB (Recommended 10W / 5V 2A charger)
- **Batteries:** 1 Lithium Metal battery (included for remote)
- **Model Number:** sensyne



Figure 6: Sensyne 10" Ring Light with Tripod Stand.

Warranty and Support

SENSYNE provides a **12-month After-sale service** for this product. If you encounter any questions or issues, please do not hesitate to contact our customer support team for assistance. For further support and product information, please visit the SENSYNE Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question