

[Manuals.plus](#) /

› [Frigidaire](#) /

› Frigidaire EFMIS129-WHITE Mini Portable Fridge User Manual

Frigidaire EFMIS129-WHITE

Frigidaire Mini Portable Fridge User Manual

Model: EFMIS129-WHITE

1. PRODUCT OVERVIEW

The Frigidaire EFMIS129-WHITE Mini Portable Fridge is a versatile and compact cooling and warming solution designed for personal use. With a 4-liter capacity, it can chill up to six 12 oz. cans or store various small items like milk, yogurt, and snacks. Its lightweight and portable design makes it ideal for use at home, in the office, dorm rooms, or on the go with both standard home and 12V car power options.



Image: Front view of the Frigidaire Mini Portable Fridge in white.

Key Features:

- **Convenient Micro Fridge:** Perfect for daily use, storing lunches, drinks, and baby bottles.
- **Portable Design:** Weighs approximately 3 pounds, making it easy to transport for use in cars, offices, or dorms. Includes both home outlet and 12V car charger.
- **Space-Saving:** Compact dimensions (10 x 7 x 10 inches) with a flush-back design and reversible door for flexible placement.
- **Ample Capacity:** 4-liter capacity, capable of chilling six 12 oz. soda cans. Interior dimensions are 5 x 5 x 7.5 inches,

featuring a removable shelf for versatile storage.

- **Eco-Friendly:** Utilizes thermoelectric technology, which is 100% Freon-Free and uses advanced semiconductors, making it environmentally friendly.
- **Cooling & Warming:** Cools up to 32°F below ambient temperature and warms up to 140°F (at 75°F ambient).

2. SAFETY INFORMATION

Please read all safety instructions carefully before operating the Frigidaire Mini Portable Fridge. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power source matches the voltage requirements of the unit (110V AC for home, 12V DC for car).
- Do not immerse the unit, cord, or plug in water or other liquids.
- Unplug the unit from the power outlet when not in use or before cleaning.
- Do not block ventilation openings. Ensure adequate airflow around the unit.
- Do not use the appliance for purposes other than its intended use.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Avoid storing perishable items that require strict temperature control, such as certain dairy products or raw meats, for extended periods, as this unit is designed for cooling and warming, not deep freezing or precise refrigeration.
- The unit is cETL approved, indicating compliance with North American safety standards.

3. PACKAGE CONTENTS

Upon opening the package, please ensure all the following components are present and in good condition:

- Frigidaire Mini Portable Fridge (Cooler)
- AC Power Cord (for home outlets)
- 12V DC Car Charger (for vehicle use)
- Removable Interior Shelf

4. SETUP

Setting up your Frigidaire Mini Portable Fridge is quick and easy.

Placement:

1. Choose a flat, stable surface for the fridge.
2. Ensure there is adequate ventilation around the unit, especially at the back where the fan is located. Avoid placing it directly against a wall or in an enclosed space.
3. The flush-back design allows for versatile placement in various rooms, including bedrooms, offices, or dorms.



Image: Rear view of the mini fridge, highlighting the fan and power input ports.

Power Connection:

1. **For Home Use:** Connect the AC power cord to the unit's AC input port, then plug the other end into a standard 110V AC wall outlet.
2. **For Car Use:** Connect the 12V DC car charger to the unit's DC input port, then plug the other end into your vehicle's 12V cigarette lighter socket.
3. Ensure the power switch on the back of the unit is in the "OFF" position before connecting or disconnecting power.

5. OPERATING INSTRUCTIONS

Your Frigidaire Mini Portable Fridge offers both cooling and warming functions.

Cooling Mode:

1. With the unit powered off and connected to a power source, locate the switch on the back of the unit.
2. Flip the switch to the "COOL" position. The indicator light will illuminate (usually green or blue) to show it's in cooling mode.
3. Allow approximately 1-2 hours for the unit to reach its optimal cooling temperature. It can cool items up to 32°F (18°C) below ambient temperature.
4. The removable shelf can be adjusted or removed to accommodate taller items.



Image: Interior of the mini fridge showing its capacity to hold six 12oz cans.

Warming Mode:

1. With the unit powered off and connected to a power source, locate the switch on the back of the unit.
2. Flip the switch to the "WARM" position. The indicator light will illuminate (usually red) to show it's in warming mode.
3. The unit can warm items up to 140°F (60°C) at an ambient temperature of 75°F (24°C).
4. This mode is suitable for keeping food warm, not for cooking or reheating cold food.

Important Notes:

- Avoid switching directly between COOL and WARM modes without turning the unit off for a few minutes in between. This helps prolong the life of the thermoelectric module.
- For best results, pre-chill or pre-warm items before placing them in the fridge.
- The unit is not designed for long-term storage of highly perishable items.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mini fridge.

1. Cleaning the Interior:

- Unplug the unit before cleaning.
- Wipe the interior with a soft cloth dampened with mild soap and water.
- Do not use abrasive cleaners or solvents.
- Periodically remove the shelf and clean it separately.
- Allow the interior to air dry completely before plugging the unit back in.

2. Cleaning the Exterior:

- Wipe the exterior surface with a soft, damp cloth.
- For stubborn marks, use a mild, non-abrasive cleaner.

3. Fan and Vents:

- Regularly check the rear fan and vents for dust accumulation.
- Use a soft brush or vacuum cleaner to gently remove dust from the fan and vent areas to ensure proper airflow and prevent overheating.

4. Condensation:

- Some condensation may occur inside the unit, especially in humid environments.
- If condensation builds up, turn off the unit, unplug it, and wipe the interior dry. Leaving the door open for a few hours can help.

7. TROUBLESHOOTING

If you encounter issues with your Frigidaire Mini Portable Fridge, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit is not cooling/warming.	Not plugged in; power switch off; blocked vents; faulty power adapter.	Ensure unit is properly plugged into a working outlet. Check power switch position. Clear any obstructions from vents. Try a different power outlet or adapter if available.
Unit is noisy.	Fan obstruction; unit not level; normal operating sound.	Check for any objects obstructing the fan. Ensure the unit is on a flat, stable surface. A low hum from the fan is normal during operation.
Excessive condensation inside.	High humidity; frequent door opening; warm items placed inside.	Wipe interior dry with a cloth. Avoid leaving the door open for extended periods. Ensure items are pre-chilled before placing them in cooling mode.
Door does not close properly.	Obstruction; misaligned door.	Check for any items blocking the door. Ensure the unit is on a level surface.

If the problem persists after trying these solutions, please contact Frigidaire customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Frigidaire
Model Number	EFMIS129-WHITE
Capacity	4 Liters (chills six 12 oz. cans)
Dimensions (D x W x H)	10 x 7 x 10 inches
Item Weight	2.5 pounds
Color	WHITE
Installation Type	Countertop
Special Features	Portable, Cooling & Warming Function
Power Source	AC (110V) and DC (12V)
Defrost System	Semi-Automatic
Shelf Type	Wire (1 removable shelf)
Certification	ETL




Image: Diagram illustrating the dimensions of the mini fridge (10.6 in H x 7.1 in W x 9.9 in D).

9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, Frigidaire products typically come with a manufacturer's warranty covering defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, troubleshooting beyond this guide, or warranty inquiries, please contact Frigidaire customer support. You can usually find contact information on the official Frigidaire website or on the product packaging.

Additional resources, including a detailed user manual, may be available online:

- [User Manual \(PDF\)](#)
- [Instructions for Use \(IFU\) \(PDF\)](#)

