

[Manuals.plus](#) /

› [Hyper Tough](#) /

› Hyper Tough 38 Piece Stubby Wrench and Socket Set User Manual

Hyper Tough 0889526218096

Hyper Tough 38 Piece Stubby Wrench and Socket Set User Manual

Model: 0889526218096

INTRODUCTION

The Hyper Tough 38 Piece Stubby Wrench and Socket Set is designed for versatility and convenience, ideal for a wide range of tasks from automotive repairs to general household maintenance. This compact set provides essential tools for working in tight spaces, ensuring reliable performance and ease of use.

PACKAGE CONTENTS

Your Hyper Tough 38 Piece Stubby Wrench and Socket Set includes the following components, neatly organized in a durable plastic storage case:

- Ratcheting Screwdriver
- Adjustable Wrench
- Ratcheting Wrench
- Assorted Sockets
- Assorted Screwdriver Bits





Figure 1: Complete set in storage case.

This image shows the Hyper Tough 38 Piece Stubby Wrench and Socket Set neatly arranged within its transparent plastic storage case. Visible components include the ratcheting screwdriver, adjustable wrench, ratcheting wrench, and a variety of sockets and screwdriver bits, each in its designated slot for easy organization and access.

SETUP

The Hyper Tough 38 Piece Stubby Wrench and Socket Set requires no complex setup. All tools are pre-assembled and

ready for immediate use. Simply open the clear cover storage case and select the appropriate tool or bit for your task.

1. Open the latches on the storage case.
2. Carefully lift the clear cover.
3. Identify the required tool or bit from its labeled slot.
4. Remove the tool or bit for use.

OPERATING INSTRUCTIONS

Ratcheting Screwdriver

The ratcheting bit driver features a 3-position mechanism for efficient fastening and loosening.

- **Forward Ratcheting:** Set the switch to allow rotation in one direction for tightening screws.
- **Reverse Ratcheting:** Set the switch to allow rotation in the opposite direction for loosening screws.
- **Non-Ratcheting (Locked):** Set the switch to lock the driver for fixed rotation, useful for initial breaking loose or final tightening.

To use, insert the desired screwdriver bit into the driver's hex opening. Apply firm pressure and rotate the handle in the appropriate direction.



Figure 2: Ratcheting screwdriver in use.

This image illustrates the Hyper Tough ratcheting screwdriver being used to fasten a screw on a door hinge. A hand is firmly gripping the ergonomic handle of the screwdriver, demonstrating its application in a practical scenario.

Adjustable Wrench

The adjustable wrench is designed for gripping and turning nuts and bolts of various sizes. It features a maximum opening of 1 inch.

- Rotate the worm screw to adjust the jaw opening to fit the fastener snugly.

- Ensure the jaws are fully engaged with the fastener to prevent slipping and damage.
- Apply force in the direction of rotation.

Ratcheting Wrench and Sockets

The ratcheting wrench, combined with the included sockets, allows for efficient tightening and loosening of nuts and bolts without removing the wrench from the fastener after each turn.

- Select the correct size socket for your fastener.
- Attach the socket firmly onto the square drive of the ratcheting wrench.
- Place the socket over the fastener.
- Engage the reversible mechanism on the wrench to select tightening or loosening direction.
- Rotate the wrench handle to turn the fastener. The ratcheting mechanism will allow you to reset your grip without disengaging the socket from the fastener.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Hyper Tough tool set.

- **Cleaning:** After each use, wipe down tools with a clean, dry cloth to remove dirt, grease, and debris. For stubborn grime, a mild degreaser can be used, followed by thorough drying.
- **Corrosion Prevention:** The tools feature a polished-chrome finish for corrosion resistance. However, avoid prolonged exposure to moisture or corrosive substances. If tools become wet, dry them immediately.
- **Storage:** Always return tools to their designated slots in the plastic storage case. This protects them from damage, keeps them organized, and prevents loss. Store the case in a dry environment.
- **Lubrication:** Periodically apply a light coat of machine oil to the moving parts of the ratcheting mechanisms and the adjustable wrench's worm screw to ensure smooth operation.

TROUBLESHOOTING

If you encounter issues with your Hyper Tough 38 Piece Stubby Wrench and Socket Set, consider the following common solutions:

- **Tool feels stiff or sticky:** Apply a small amount of lubricant to moving parts (e.g., ratcheting mechanism, adjustable wrench screw) and work them back and forth to distribute the lubricant.
- **Socket/Bit not fitting:** Ensure you are using the correct size socket or bit for the fastener. Check for any debris inside the socket or on the fastener that might prevent a proper fit.
- **Ratcheting mechanism not engaging:** Verify the direction switch is fully engaged in either the forward or reverse position, not in the neutral (locked) position. Clean any debris from the mechanism.
- **Tools difficult to remove/insert from case:** The case is designed for secure fit. Ensure tools are aligned correctly with their slots. A slight wiggle or firm, straight pull/push may be needed.

SPECIFICATIONS

Feature	Detail
Product Name	Hyper Tough 38 Piece Stubby Wrench and Socket Set
Model Number	0889526218096

Material	Forged & heat treated steel (Corrosion resistant steel)
Finish	Polished-chrome
Adjustable Wrench Max Opening	1 inch
Ratcheting Bit Driver Positions	3 (Left, Right, Non-Ratcheting)
Item Weight	2.65 pounds
Package Dimensions	9.69 x 5.83 x 1.42 inches
Color	Red

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to inquire about replacement parts, please refer to the official Hyper Tough website or contact their customer service directly. Keep your purchase receipt as proof of purchase. While specific warranty details are not provided in this manual, Hyper Tough products typically come with a manufacturer's warranty covering defects in materials and workmanship. Always consult the official Hyper Tough resources for the most current and accurate warranty information.

© 2024 Hyper Tough. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

