

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Xbeauty](#) /

› [Xbeauty 23" Electric Fireplace Stove Instruction Manual](#)

Xbeauty 727380800043

Xbeauty 23" Electric Fireplace Stove

MODEL: 727380800043 - INSTRUCTION MANUAL

Introduction

The Xbeauty 23" Electric Fireplace Stove (Model 727380800043) offers a blend of aesthetic appeal and functional heating. Designed as a freestanding unit, it features adjustable realistic 3D flame effects and two heat settings (1000W/1500W) to provide warmth and ambiance. This manual provides essential information for safe setup, operation, and maintenance of your electric fireplace stove.

Important Safety Information

Before operating your Xbeauty Electric Fireplace Stove, please read and understand all safety instructions.

- **Overheat Protection:** The unit is equipped with a built-in overheat protection system that automatically shuts off the heater if the internal temperature becomes too high.
- **Placement:** Position the fireplace on a firm, level surface. Ensure adequate clearance from combustible materials such as curtains, furniture, bedding, and other fabrics.
- **Electrical Connection:** Plug the unit directly into a 120V AC, 15-amp (or higher) grounded outlet. Do not use extension cords or power strips.
- **Ventilation:** Do not block the air intake or exhaust vents. Maintain clear space around the unit for proper airflow.
- **Children and Pets:** Keep children and pets away from the operating heater. While the exterior remains cool, the heat outlet area can become hot.
- **Do Not Cover:** Never cover the heater or block the heat outlet. This can lead to overheating and fire hazards.
- **Maintenance:** Always unplug the unit before cleaning or performing any maintenance.

Package Contents

Upon unpacking, ensure all components are present and in good condition.

PACKAGE INCLUDING



1 Electric heater

**IMPORTANT INSTRUCTIONS
AND OPERATING MANUAL**

ELECTRIC FIREPLACE



1 User manual



4 Legs

Image: Contents of the Xbeauty Electric Fireplace Stove package, including the main heater unit, a user manual, and four separate legs for assembly.

- 1 x Electric Heater Unit
- 1 x User Manual
- 4 x Legs (for assembly)

Setup

The Xbeauty Electric Fireplace Stove is designed for easy freestanding setup.



BUTTON DESCRIPTION

1. Thermostat control knob (TEMPERATURE SETTING)

Adjust to maintain room temperature

2. Flame switch

Switch the fame effect, turn on/off the power

3. Heating setting

Please press "□" for 1000W

4. Heating setting

Please press "□" and "□" at the same time for 1500W (it can not operate without pressing "□" first)

5. Flame dimmer control

Adjust to set flame intensity



Image: The Xbeauty Electric Fireplace Stove displayed in a living room, highlighting its dimensions (16.34"W x 11.02"D x 22.83"H) and freestanding design.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Leg Assembly:** Attach the four legs to the base of the electric heater unit using the provided screws. Ensure they are securely fastened for stability.
3. **Placement:** Place the assembled unit on a stable, level surface. Ensure it is not placed directly under a wall-mounted television or near any heat-sensitive materials.
4. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet.

Operating Instructions

Your Xbeauty Electric Fireplace Stove features intuitive controls for easy operation.

Xbeauty Electric Fireplace Stove



Image: Detailed view of the control panel located behind the door of the Xbeauty Electric Fireplace Stove, showing the thermostat control knob, flame switch, heating settings (1000W/1500W), and flame dimmer control.

- **Power On/Off:** Open the front door to access the control panel. Use the main power switch (often combined with the flame switch) to turn the unit on or off.
- **Flame Effect:** The flame effect can be operated independently of the heat. Use the 'Flame switch' to activate the realistic 3D flame visuals. Adjust the flame intensity using the 'Flame dimmer control' knob.
- **Heat Settings:**
 - To activate 1000W heating, press the corresponding heating setting switch.
 - For 1500W heating, press both heating setting switches simultaneously. Note: 1500W operation requires the 1000W switch to be engaged first.
- **Thermostat Control:** Use the 'Thermostat control knob' to set your desired room temperature. The heater will cycle on and off to maintain this temperature.

Maintenance

Regular maintenance ensures the longevity and efficient operation of your electric fireplace stove.

- **Cleaning:** Always unplug the unit before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Dust Removal:** Periodically vacuum the air intake and exhaust vents to prevent dust buildup, which can impede airflow and reduce heating efficiency.
- **Glass Cleaning:** For the glass panels, use a soft cloth and a non-abrasive glass cleaner.
- **Storage:** If storing the unit for an extended period, unplug it and store it in a dry, dust-free location.

Troubleshooting

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in, power switch off, circuit breaker tripped.	Ensure unit is plugged in, power switch is on, check household circuit breaker.
No heat, but flames are on.	Heat settings not activated, thermostat set too low.	Activate appropriate heat setting switch(es), increase thermostat setting.
Flames not working.	Flame switch off, flame dimmer set to minimum.	Ensure flame switch is on, adjust flame dimmer control.
Unit shuts off unexpectedly.	Overheat protection activated.	Unplug unit, allow to cool for 10-15 minutes, check for blocked vents, then restart.

Specifications

Detailed technical specifications for the Xbeauty 23" Electric Fireplace Stove.

Feature	Detail
Brand	Xbeauty
Model Name	727380800043
Power Source	Corded Electric
Product Dimensions	11.05"D x 16.34"W x 22.83"H
Material	Glass, Metal
Finish Type	Painted/Lacquered Black
Installation Type	Freestanding
Heat Output	5100 British Thermal Units
Special Feature	Portable
Power Consumption	1500 Watts
Heating Coverage	500 square feet

Feature	Detail
Item Weight	17.6 Pounds
Warranty Type	Limited

Warranty & Support

The Xbeauty 23" Electric Fireplace Stove comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact Xbeauty customer support directly.

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Xbeauty customer service through their official website or the contact information provided in your user manual.