

CIARRA CBTIH2

CIARRA CBTIH2 Double Induction Cooktop User Manual

Model: CBTIH2 | Brand: CIARRA

1. INTRODUCTION

Thank you for choosing the CIARRA CBTIH2 Double Induction Cooktop. This manual provides essential information for the safe and efficient operation of your appliance. Please read all instructions carefully before use and retain this manual for future reference.

The CIARRA CBTIH2 is a portable double induction cooktop designed for versatile cooking. It features two cooking zones, touch controls, multiple power and temperature settings, and various safety functions.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure proper ventilation around the cooktop during operation.
- Only use induction-compatible cookware.

3. PRODUCT OVERVIEW

The CIARRA CBTIH2 Double Induction Cooktop features a sleek design with two independent cooking zones and an intuitive touch control panel.



The CIARRA CBTIH2 double induction cooktop features intuitive touch controls for easy operation. A user's hand is shown interacting with the control panel, highlighting the sleek design and user-friendly interface.

Components:

- Ceramic Glass Surface
- Left Cooking Zone
- Right Cooking Zone

- Touch Control Panel
- Digital Display
- Power Cord

4. SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove the cooktop from its packaging. Inspect for any damage.
2. **Placement:** Place the cooktop on a stable, flat, heat-resistant surface. Ensure there is adequate space around the unit for ventilation (at least 10 cm from walls or other appliances). Do not block the ventilation openings.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance (220 Volts).

5. OPERATING INSTRUCTIONS

5.1. Compatible Cookware

Induction cooktops require cookware made of ferromagnetic material. To check if your cookware is compatible, hold a magnet to the bottom of the pot or pan. If the magnet sticks, the cookware is suitable for induction cooking.



This image clarifies cookware compatibility for the induction cooktop. Compatible types include stainless steel with magnetic bottom, magnetic pots, cast iron pans, and cast iron woks. Incompatible types are enamel, copper/aluminum, ceramic, and glass.



A hand is shown using a magnet to check the compatibility of a pot with the induction cooktop, demonstrating the simple test for magnetic cookware.

5.2. Basic Operation

- 1. Power On:** Place compatible cookware with food on the desired cooking zone. Press the "On/Off" button on the touch control panel.
- 2. Select Cooking Zone:** If using both zones, select the zone you wish to adjust.
- 3. Adjust Power/Temperature:** Use the "+" and "-" buttons to adjust the power level (9 levels) or temperature (10 levels). The digital display will show the selected setting. The cooktop offers a total power of 3500W when both zones are in use.
- 4. Timer Function:** Press the timer button and use "+" and "-" to set the desired cooking time, up to 180 minutes. The cooktop will automatically shut off when the timer expires.
- 5. Child Lock:** Activate the child lock function to prevent accidental changes to settings during cooking or when the cooktop is not in use.
- 6. Power Off:** Press the "On/Off" button to turn off the cooktop. The residual heat indicator will show if the surface is still hot.



A detailed view of the CIARRA CBTIH2 control panel, showing the digital display for temperature and power settings, ranging from 60°C (200W) to 240°C (2000W).

The CIARRA CBTIH2 cooktop in use with two pans, illustrating its combined 3500W power output for simultaneous cooking on both zones.



An infographic summarizing the main features of the CIARRA CBTIH2 cooktop: Touch Control, Child Lock, Easy Cleaning, Rapid Heating, and Auto-Off function.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your cooktop.

- 1. Before Cleaning:** Always unplug the cooktop from the power outlet and allow it to cool completely.
- 2. Surface Cleaning:** Wipe the ceramic glass surface with a soft, damp cloth and a mild detergent. For stubborn stains, use a non-abrasive ceramic hob cleaner. Do not use abrasive pads, harsh chemicals, or sharp objects.
- 3. Control Panel:** Clean the touch control panel with a soft, dry cloth.
- 4. Ventilation Openings:** Ensure the ventilation openings are free from dust and debris to prevent overheating.



A hand is shown cleaning the smooth surface of the CIARRA CBTIH2 induction cooktop with a cloth and cleaning solution, emphasizing its easy-to-clean design.

7. TROUBLESHOOTING

If you encounter issues with your cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not power on.	No power supply; Cooktop not plugged in; Power outlet malfunction.	Check power cord connection; Test outlet with another appliance; Check circuit breaker.
Cooktop beeps and displays an error code.	Incompatible cookware; No cookware on zone; Overheating.	Use induction-compatible cookware; Place cookware on the zone; Allow cooktop to cool down.
Cooking zone not heating.	Cookware not centered; Cookware too small/large; Faulty cookware.	Center cookware; Use appropriate size cookware; Try different cookware.
Unusual noise during operation.	Normal fan operation; Cookware vibration.	This is often normal. Ensure cookware is flat on the surface.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the CIARRA CBTIH2 Double Induction Cooktop:

- **Model Number:** CBTIH2
- **Brand:** CIARRA
- **Color:** Black
- **Dimensions (L x W x H):** 60.5 x 37 x 5.8 cm (23.8 x 14.6 x 2.3 inches)
- **Weight:** 4.9 kg (10.8 lbs)
- **Power:** 2800 Watts (Total, up to 3500W peak)
- **Voltage:** 220 Volts
- **Heating Elements:** 2 (Induction Burners)
- **Control Type:** Touch
- **Power Levels:** 9
- **Temperature Levels:** 10
- **Automatic Shut-off Function:** Yes
- **Special Features:** Temperature levels, Automatic Pan Detection, Residual Heat Indicator, Overheat Protection, Timer (up to 180 min)
- **Country of Origin:** China



The image displays the physical dimensions of the CIARRA CBTIH2 cooktop: 605mm length, 370mm width, and 45mm height, providing essential information for placement and installation.

9. WARRANTY AND SUPPORT

The CIARRA CBTIH2 Double Induction Cooktop comes with a 2-year availability of spare parts. For warranty claims, technical support, or any questions regarding your product, please contact CIARRA customer service.

Please have your model number (CBTIH2) and purchase information ready when contacting support.