

SAKOBS SB925D-01

SAKOBS SB925D-01 60W Soundbar User Manual

Model: SB925D-01

1. INTRODUCTION

Thank you for choosing the SAKOBS SB925D-01 60W Soundbar. This soundbar is designed to enhance your audio experience for both TV and PC, delivering powerful stereo sound with deep bass and clear vocals. Featuring Bluetooth 5.0, DSP technology, and multiple input options, it provides versatile connectivity and immersive sound. Please read this manual carefully before use to ensure proper setup and operation.

2. SAFETY INFORMATION

To ensure safe and optimal performance, please observe the following safety precautions:

- Do not expose the soundbar to rain, moisture, or extreme temperatures.
- Do not open the casing. Refer all servicing to qualified personnel.
- Keep the soundbar away from heat sources, direct sunlight, and strong magnetic fields.
- Ensure proper ventilation around the unit. Do not block any ventilation openings.
- Use only the provided power adapter.
- Clean the soundbar with a soft, dry cloth. Do not use liquid cleaners or aerosols.

3. PACKAGE CONTENTS

Carefully unpack your SAKOBS SB925D-01 Soundbar and check that all the following items are included:

- SAKOBS SB925D-01 Soundbar
- Remote Control
- Power Adapter
- Optical Cable
- AUX Cable (3.5mm to 3.5mm)
- RCA Cable (3.5mm to RCA)
- Wall Mount Kit (screws and anchors)
- User Manual (this document)



Image: Soundbar dimensions and included accessories, including remote, various cables, and wall mount kit.

4. PRODUCT OVERVIEW

Front View

MATCHES YOUR COMPUTER

Compact sound system for your computer
Gives you a neat and comfortable desktop



Image: Front view of the SAKOBS SB925D-01 Soundbar, showcasing its sleek design and speaker grilles.

Rear Panel and Connections

The rear panel of the soundbar features various input ports for connecting to your devices.

MULTIPLE CONNECTIONS



Laptop



Desktop



TV



Pad



Phone



MP3



AUX



OPT



Bluetooth



Image: Rear view of the SAKOBS SB925D-01 Soundbar, highlighting the AUX and Optical input ports.



Image: Detailed view of the soundbar's rear panel, showing the AUX and S/PDIF (Optical) input connections.

Control Buttons and Remote

The soundbar can be controlled via the buttons on the unit or the included remote control.

MULTI-MODES AUDIO INPUTS



AUX / RCA



OPT



Bluetooth



Image: The SAKOBS SB925D-01 Soundbar shown with its remote control.

5. SETUP

Placement Options

The SAKOBS SB925D-01 Soundbar offers flexible placement options to suit your setup:

- **Tabletop Placement:** Place the soundbar flat on a stable surface below your TV or monitor.
- **Wall Mounting:** Use the included wall mount kit to attach the soundbar to a wall. Ensure the wall can support the weight of the soundbar.



Image: Diagram illustrating soundbar placement options: flat on a surface or wall-mounted below a TV.




Image: Visual representation of the soundbar positioned both on a TV stand and mounted on a wall.

Connecting to Devices

The soundbar supports multiple audio input modes:

- **Optical (OPT):** For high-quality digital audio from TVs, game consoles, or DVD/Blu-ray players. Use the included optical cable.
- **AUX/RCA:** For analog audio from TVs, PCs, or other devices with a 3.5mm audio output or RCA outputs. Use the included AUX or RCA cables.
- **Bluetooth:** For wireless audio streaming from smartphones, tablets, or laptops.

BUTTONS & REMOTE CONTROL



Image: Diagram showing various devices (laptop, desktop, TV, tablet, phone, MP3 player) connecting to the soundbar via AUX, Optical, and Bluetooth.



Image: Close-up of the soundbar's rear inputs, illustrating AUX/RCA, Optical, and Bluetooth connectivity options.

6. OPERATING INSTRUCTIONS

Power On/Off

Connect the power adapter to the soundbar and a power outlet. Press the power button on the soundbar or the remote control to turn the unit on or off.

Selecting Input Mode

Press the 'Input' button on the soundbar or the 'BT', 'OPT', 'AUX' buttons on the remote control to switch between input modes. An LED indicator on the soundbar will change color to indicate the current mode:

- **Blue:** Bluetooth Mode
- **White:** AUX Mode
- **Green:** Optical Mode
- **Red:** Standby Mode



Image: The soundbar's remote control and close-up views of the LED indicator showing different colors for Bluetooth, AUX, and Standby modes.

Bluetooth Pairing

1. Turn on the soundbar and switch to Bluetooth mode (Blue LED).
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "SAKOBS SB925D-01" in your device's Bluetooth list and select it to pair.
4. Once paired, the soundbar will emit a confirmation tone, and the LED will remain solid blue.



Image: A smartphone displaying its Bluetooth settings, ready to pair with the SAKOBS soundbar.

Sound Modes

The soundbar features three equalizer modes to optimize your audio experience:

- **Music Mode:** Enhances bass and treble for a rich musical experience.
- **Movie Mode:** Provides a wider soundstage and clearer dialogue for films.
- **TV Mode:** Optimizes vocal clarity for news and general TV programs.

Use the corresponding buttons on the remote control to switch between these modes.

7. MAINTENANCE

To maintain the performance and appearance of your soundbar:

- Wipe the surface with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, waxes, or solvents.
- Keep the speaker grilles free from dust and debris.

8. TROUBLESHOOTING

If you encounter any issues with your soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	Soundbar is off or in standby. Incorrect input mode selected. Volume is too low. Cables are not connected properly.	Ensure soundbar is powered on. Select the correct input mode (Bluetooth, Optical, AUX). Increase volume on soundbar and source device. Check all cable connections.

Problem	Possible Cause	Solution
Bluetooth not connecting	Soundbar not in Bluetooth pairing mode. Device Bluetooth is off. Device is too far from soundbar. Interference.	Switch soundbar to Bluetooth mode. Ensure Bluetooth is enabled on your device. Move device closer to soundbar. Avoid placing soundbar near other wireless devices.
Remote control not working	Batteries are dead or incorrectly inserted. Obstruction between remote and soundbar.	Replace batteries (AAA, not included). Ensure line of sight between remote and soundbar.
Distorted sound	Volume too high. Source audio quality is poor.	Lower the volume. Try a different audio source to check if the issue persists.

9. SPECIFICATIONS

Detailed technical specifications for the SAKOBS SB925D-01 Soundbar:

Feature	Specification
Model Number	SB925D-01
Product Dimensions (L x W x H)	41 x 10 x 7 cm (16.1 x 3.9 x 2.8 inches)
Item Weight	1 Kilogram (2.2 lbs)
Maximum Speaker Output Power	50 Watts (RMS 60W, 110 dB SPL mentioned in features)
Connectivity Technology	Bluetooth, Auxiliary, Optical
Wireless Technology	Bluetooth 5.0
Bluetooth Range	10 Meters (33 feet)
Audio Output Mode	PCM
Number of Audio Channels	2.0
Speaker Type	Soundbar
Mounting Type	Wall Mount
Material	Plastic casing, paper/polypropylene/silk components
Control Method	Remote Control
Compatible Devices	Smartphone, Tablet, Laptop, Television, Projector
Power Source	Powered by battery (likely refers to remote) / AC Adapter (for soundbar)
GTIN (UPC)	778463586750

10. WARRANTY AND SUPPORT

The SAKOBS SB925D-01 Soundbar comes with a limited warranty. For specific warranty terms and

conditions, please refer to the warranty card included in your package or contact SAKOBS customer support.

If you have any questions, require technical assistance, or need to report an issue, please contact SAKOBS customer support through the retailer's platform or the official SAKOBS website.