

[Manuals.plus](#) /

› [Duncan](#) /

› Duncan Toys Pro Z Yo-Yo Instruction Manual (Model 3606XP-6)

Duncan 3606XP-6

Duncan Toys Pro Z Yo-Yo Instruction Manual

Model: 3606XP-6

INTRODUCTION

The Duncan Pro Z Yo-Yo is designed for versatility, featuring patent-pending MOD spacers that allow it to transform between a standard looping yo-yo and a wide-body string trick yo-yo. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and enjoyment.



Image: Three Duncan Pro Z yo-yos in red, blue, and green, showcasing their design.

COMPONENTS INCLUDED

- Duncan Pro Z Yo-Yo (6 units, assorted colors)

- MOD Spacers with KonKave Bearing
- Trick Book
- Extra bolt
- Extra bearing
- Extra spacers



Image: Exploded view of Duncan Pro Z yo-yo components, including the main body, MOD spacers, and axle.

SETUP AND CONFIGURATION

1. Attaching the String

1. Unwind the yo-yo string.
2. Create a slip knot at one end of the string.
3. Loop the slip knot over the axle of the yo-yo.
4. Adjust the loop to be snug but not overly tight around the axle.

2. Adjusting String Length

1. Hold the yo-yo in your hand and let the string hang to the floor.
2. The string should reach your belly button.
3. If the string is too long, cut it to the appropriate length.
4. Tie a loop at the end of the string for your finger.

3. Using MOD Spacers for Shape Changing

The Pro Z yo-yo features convertible MOD spacers to change its shape for different play styles:

- **Standard Looping Style:** Use the narrower spacer configuration for traditional looping tricks.
- **Wide Body String Trick Style:** Replace the standard spacers with the wider MOD spacers to create a wider gap, ideal for string tricks and longer spin times.

To change spacers:

1. Carefully unscrew the yo-yo halves.
2. Remove the existing spacers and bearing.
3. Insert the desired MOD spacers and bearing onto the axle.
4. Screw the yo-yo halves back together securely, ensuring the string is properly seated.



Video: A 360-degree view of the Duncan Pulse Yo-Yo, demonstrating its design and features. While a different model, it illustrates the general construction of Duncan yo-yos.



Video: A 360-degree view of the Duncan Dragonfly Yo-Yo, providing another perspective on yo-yo design and construction.

OPERATING YOUR YO-YO

Basic Throw and Return

1. Place the loop of the string over your middle finger.
2. Wind the string tightly around the yo-yo.
3. Hold the yo-yo in your palm, then quickly snap your wrist downwards, releasing the yo-yo.
4. As the yo-yo reaches the end of the string, give a slight tug upwards with your hand to make it return.

Performing Tricks

The Duncan Pro Z is suitable for both looping and string tricks. Refer to the included 20-page trick book for detailed instructions on various maneuvers. Practice is key to mastering yo-yo tricks.



Video: A demonstration of advanced yo-yo tricks using a Duncan Roadrunner Yo-Yo, showcasing the potential for complex string maneuvers.

CARE AND MAINTENANCE

General Care

- Store your yo-yo in a clean, dry place to prevent damage.
- Avoid dropping the yo-yo on hard surfaces, as this can affect its balance and performance.
- Keep the yo-yo away from extreme temperatures.

String Replacement

Over time, yo-yo strings can fray or break. Replace the string when it shows signs of wear to maintain optimal performance and safety. The Pro Z comes with extra strings for convenience.



Video: Instructions on how to replace a yo-yo string, demonstrating the process for maintaining your yo-yo.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Duncan
Model Number	3606XP-6
Skill Level	All
Age Range (Recommended)	6 - 10 years
Product Dimensions	2.25 x 1.18 x 2.25 inches
Item Weight	1.76 ounces
Body Material	Durable Polycarbonate
Axle Type	High speed ball bearing
Response System	Starburst

© 2023 Duncan Toys. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question