

[Manuals.plus](#) /

› [DEERC](#) /

› DEERC DE42 1/18 Scale RC Off-Road Jeep User Manual

DEERC DE42

DEERC DE42 1/18 Scale RC Off-Road Jeep User Manual

Model: DE42

1. INTRODUCTION

Thank you for purchasing the DEERC DE42 1/18 Scale RC Off-Road Jeep. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new remote control car. Please read it thoroughly before use and keep it for future reference.

高性能なオフロードRCカー



バッテリー1個使用時間80分
存分に遊べよう



The DEERC DE42 RC Off-Road Jeep navigating challenging terrain, showcasing its robust design and off-road capabilities.

2. SAFETY INFORMATION

Important Safety Notice:

- Recommended age for this product is 6 years and above.
- The included lithium-ion battery has an energy density below 400Wh/L and is exempt from PSE regulations.
- Always supervise children during operation.
- Do not operate near people, pets, or obstacles to prevent accidents.
- Avoid operating in wet conditions or near water to prevent damage to electronic components.
- Ensure the battery is correctly installed and charged according to instructions.
- Remove batteries from the car and remote control when not in use for extended periods.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing:

- DEERC DE42 RC Off-Road Jeep (1 unit)
- 2.4GHz Remote Control (1 unit)
- Rechargeable Battery (1 unit)
- USB Charging Cable (1 unit)
- User Manual (This document)

4. SPECIFICATIONS

Feature	Detail
Brand	DEERC
Model Number	DE42
Scale	1:18
Power Source	Battery Powered
Operation Mode	RC (Remote Control)
Recommended Age	6 years and above
Material Type	Acrylonitrile Butadiene Styrene (ABS), Polyvinyl Chloride (PVC)
Product Dimensions	28 x 17 x 14.5 cm (Car body: 31.5 x 19.3 x 13.4 cm)
Battery Type	Lithium Polymer (LiPo)
Operation Time	Up to 80 minutes (per battery)
Control Frequency	2.4GHz

操作が簡単



2.4GHZ



1:18スケール



左折/右折



前進/後進



ヘッドライト



自動モード



収納ケース



80分

Visual representation of the DEERC DE42 RC car with key dimensions and feature icons, including 2.4GHz control, 1:18 scale, turning, forward/backward, headlights, auto mode, storage, and 80-minute playtime.

5. SETUP

5.1 Charging the Battery

1. Connect the rechargeable battery to the USB charging cable.
2. Plug the USB charging cable into a compatible USB power adapter (e.g., computer USB port, wall adapter).
3. The indicator light on the USB cable will show the charging status (refer to the cable's specific instructions for light indications).
4. Once fully charged, disconnect the battery from the charging cable.

高性能なオフロードRCカー



バッテリー1個使用時間80分
存分に遊べよう



The included high-quality rechargeable battery provides up to 80 minutes of operation time per charge.

5.2 Installing Batteries

1. **RC Car:** Open the battery compartment on the underside of the car. Connect the charged battery to the car's power connector. Securely close the battery compartment.
2. **Remote Control:** Open the battery compartment on the back of the remote control. Insert 2x AA batteries (not included), ensuring correct polarity (+/-). Close the compartment.

5.3 Pairing the Remote Control

1. Turn on the RC car.
2. Turn on the remote control.
3. The indicator light on the remote control will flash and then become solid, indicating successful pairing.
4. If pairing fails, turn off both devices and repeat the steps.

2.4GHz
RADIO SYSTEM



2.4GHZ
送信機でコントロール
>>



The 2.4GHz radio system allows multiple DEERC RC cars to be operated simultaneously without interference, perfect for family fun.

6. OPERATING INSTRUCTIONS

6.1 Basic Controls

- **Forward/Backward:** Push the left joystick forward or backward.
- **Turn Left/Right:** Push the right joystick left or right.
- **Headlights:** Press the headlight button on the remote control to turn the headlights on or off.
- **Automatic Mode:** Press the automatic mode button on the remote control for the car to perform pre-programmed movements.



The remote control features dedicated buttons for headlight control and activating the automatic driving mode.

6.2 Terrain Adaptability

The DE42 is designed for various terrains thanks to its durable PVC tires with strong grip and shock-resistant system. It can operate on:

- Soil
- Sand
- Wet Ground
- Grass
- Mountain Roads
- Rocky Surfaces
- Over small obstacles



DE42 オフロードカー さまざまな地形に対応



The DEERC DE42 is built to handle diverse environments, from sandy beaches to rocky paths, providing versatile play options.



The anti-slip tires provide superior grip and stability on various surfaces.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the car after use. Do not use water or chemical cleaners.
- **Storage:** Store the car and remote control in a cool, dry place away from direct sunlight. Remove all batteries if

storing for an extended period.

- **Battery Care:** Always fully charge the battery before use. Do not overcharge or completely discharge the battery.
- **Tire Inspection:** Regularly check tires for wear and tear.


収納ケース



ABS材料



TPR滑り止めタイヤ



衝突防止車ヘッド

Detailed views of the DEERC DE42's features, including the rear storage case, durable TPR anti-slip tires, and the robust anti-collision bumper, all designed for longevity and performance.



収納ケース

The rear of the DEERC DE42 features a functional storage case, ideal for carrying small accessories or spare parts.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not respond to remote control.	Low battery in car or remote; Not paired; Interference.	Charge car battery, replace remote batteries; Re-pair car and remote; Move to an area with less interference.
Car runs slowly or inconsistently.	Low car battery; Obstruction in wheels/gears.	Charge car battery; Check and clear any obstructions.
Car pulls to one side.	Steering trim needs adjustment.	Adjust the steering trim dial on the remote control or the trim adjustment on the car's underside until it drives straight.



The trim function allows for fine-tuning of the steering to ensure the car drives straight.

9. WARRANTY AND SUPPORT

DEERC Toys is committed to providing high-quality products and customer service. We offer a quality assurance and warranty service for this product.

If you encounter any issues or have questions regarding your DEERC DE42 RC Off-Road Jeep, please contact us through your order details page on Amazon. We will provide appropriate support to resolve your concerns.

For further assistance, please refer to the contact information provided with your purchase or visit the official DEERC store on Amazon.

- **Manufacturer:** DEERC Toys
- **Contact:** Via Amazon 'Order Details'

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question