

[Manuals.plus](#) /

› [TIZO](#) /

› TIZO Design Vertical 5x7 Lucite Picture Frame User Manual

TIZO HA158BK57

TIZO Design Vertical 5x7 Lucite Picture Frame User Manual

Model: HA158BK57

INTRODUCTION

This manual provides instructions for the TIZO Design Vertical 5x7 Lucite Picture Frame. This elegant and durable frame is designed to showcase 5" x 7" photos with its clear, 1-inch thick lucite construction and magnetic closures, ensuring your cherished memories are displayed beautifully.



Image: Front view of the TIZO 5x7 Lucite Picture Frame, showcasing its clear lucite and black base, designed for vertical display.

SAFETY INFORMATION

- Handle with care to avoid scratches or damage to the lucite surfaces.
- Keep away from direct sunlight or extreme temperatures to prevent material degradation or discoloration.
- Ensure the frame is placed on a stable, flat surface to prevent tipping and potential damage to the frame or photo.

PACKAGE CONTENTS

- 1 x TIZO Design Vertical 5x7 Lucite Picture Frame (Model HA158BK57)

SETUP

1. Unpack the picture frame carefully from its packaging, ensuring all protective films are removed.
2. Identify the front lucite panel and the back lucite panel, which includes the integrated easel stand.



Image: Back view of the TIZO Lucite Picture Frame, showing the integrated easel stand for vertical display.

3. The front panel is secured by magnetic closures at the bottom. To open, gently slide the front panel upwards to detach it from the base.

Tizo | **Luxury & Quality**

Impeccably crafted to
the highest standards



Image: The TIZO Lucite Picture Frame separated into its two main lucite panels, demonstrating the magnetic closure mechanism.

4. Insert your 5" x 7" photo between the two lucite panels, ensuring it is centered and aligned within the frame's dimensions.
5. Carefully re-align the front panel with the base and lower it until the magnetic closures secure it firmly in place.
6. Position the frame on a flat, stable surface. The easel stand on the back panel allows for vertical display.

OPERATING INSTRUCTIONS

The TIZO Lucite Picture Frame is designed for straightforward photo display and easy photo changes.

Changing Photos

1. To change a photo, gently lift the front lucite panel from the base, as described in the Setup section.
2. Remove the existing photo from between the panels.
3. Insert the new 5" x 7" photo, ensuring it is properly aligned and centered.
4. Reattach the front panel by aligning it with the base and allowing the magnets to secure it firmly.

MAINTENANCE

Cleaning the Frame

- Use a soft, lint-free microfiber cloth to gently wipe the lucite surfaces.
- For smudges or fingerprints, a small amount of mild, non-abrasive plastic cleaner specifically designed for acrylic, or a damp cloth with plain water, can be used.
- Avoid using harsh chemicals, abrasive cleaners, ammonia-based products (like window cleaner), or paper towels, as these can scratch or damage the lucite.

Storage

- If storing the frame, keep it in its original packaging or wrap it in a soft cloth to protect it from dust and scratches.
- Store in a cool, dry place away from direct sunlight and extreme temperature fluctuations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Frame appears scratched or cloudy	Improper cleaning agents or abrasive materials used.	Clean only with a soft, lint-free cloth and mild plastic cleaner or water. Avoid abrasive materials.
Photo is not held securely	Photo not aligned correctly or front panel not fully engaged.	Ensure the 5x7 photo is centered. Press the front panel firmly onto the base until the magnets engage.
Frame is unstable	Not placed on a flat surface or easel not fully extended.	Place the frame on a completely flat and stable surface. Ensure the easel stand on the back is fully extended and locked into position.

SPECIFICATIONS

- **Brand:** TIZO
- **Model:** HA158BK57
- **Product Dimensions:** 7.25"L x 5"W (designed for 5x7 inch photos)
- **Frame Material:** Lucite (Acrylic)
- **Thickness:** 1 inch
- **Mounting Type:** Easel Mount (Vertical Orientation)
- **Closure Type:** Magnetic
- **Color:** Black
- **Item Weight:** 1.76 pounds
- **UPC:** 820036023756
- **ASIN:** B08BG8D751

WARRANTY AND SUPPORT

TIZO products are crafted with quality and durability in mind. For specific warranty information or support inquiries

regarding your TIZO Design Vertical 5x7 Lucite Picture Frame, please refer to the official TIZO website or contact their customer service directly.

Official TIZO Store: [Visit the TIZO Store on Amazon](#)

Manufacturer: TIZO

© 2025 TIZO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question