

FLEXISPOT 48 x 24 Inches Electric Standing Desk

FLEXISPOT Standing Desk Instruction Manual

MODEL: 48 x 24 INCHES ELECTRIC STANDING DESK

Brand: FLEXISPOT

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your new FLEXISPOT Standing Desk. Designed for optimal ergonomic comfort, this height-adjustable electric desk is a versatile addition to any home or office environment. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation.

Safety Information

Always follow the assembly instructions carefully. Do not exceed the maximum weight limit of 154 pounds. Keep the desk away from heat sources and do not place heavy objects on the desk when it is in the raised position. Always use the desk with caution and ensure it is properly anchored to the floor to prevent tipping. Keep children and pets away from the desk when it is in use or being adjusted.

What's in the Box

- Cable Management Tray
- Desk Frame Components
- Desktop (Whole-Piece Maple)
- Control Panel

- Power Adapter and Cables
- Assembly Hardware and Tools

Setup

Follow these steps for proper assembly of your FLEXISPOT Standing Desk:

1. Unpack all components and verify against the parts list.
2. Attach the desk legs to the desktop using the provided hardware. Ensure all screws are securely tightened.
3. Install the control panel and cable management tray underneath the desktop.
4. Connect the motor and control panel cables to the power adapter.
5. Plug the power adapter into a wall outlet.



Image: Visual guide for assembling the desk components and connecting the control panel.

Video: Demonstrates the assembly process of the FlexiSpot Standing Desk, including attaching legs and connecting cables.

Operating Instructions

Your FLEXISPOT Standing Desk features an intuitive control panel for easy height adjustment.

- **Adjusting Height:** Use the up (▲) and down (▼) arrow buttons on the control panel to raise or lower the desk to your desired height.
- **Automatic Lifting Mode:** Long press the up (▲) or down (▼) button for more than 1.2 seconds to enter the automatic lifting mode, allowing the desk to move continuously without holding the button. Press any button to stop.




Image: Close-up of the desk's control panel, showing the up and down buttons for height adjustment.

Video: Shows the FlexiSpot Standing Desk in various settings, demonstrating its height adjustment capabilities and versatility.

Video: A tour of the FlexiSpot Standing Desk in daily use, highlighting its features and smooth operation.

Maintenance

To ensure the longevity and optimal performance of your standing desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Weight Limit:** Do not exceed the maximum weight capacity of 154 pounds to prevent damage to the motor and frame.

Video: Demonstrates durability tests on the FlexiSpot desktop, including scratch, weight capacity, clean, and fire resistance tests, highlighting its robust construction.

Troubleshooting

If you encounter any issues with your FLEXISPOT Standing Desk, refer to the common problems and solutions below:

- **Desk Not Moving:**
 - Check if the power cable is securely plugged into both the desk and the wall outlet.
 - Ensure all motor and control panel cables are properly connected.
 - Perform a reset: Consult the full manual or manufacturer's website for specific reset procedures, which often involve holding down certain buttons.
- **Desk is Unstable/Wobbly:**
 - Verify that all assembly screws are fully tightened.
 - Ensure the desk is placed on a flat, level surface. Adjust leveling feet if necessary.
 - Do not exceed the maximum weight capacity.
- **Unusual Noises During Operation:**
 - A slight hum from the motor is normal. If the noise is loud or grinding, check for any obstructions in the lifting mechanism.
 - Ensure the desk is not rubbing against a wall or other furniture.

Specifications

Feature	Detail
Product Dimensions	24"D x 48"W x 46.3"H
Color	White Frame + Maple Desktop
Style	Modern

Feature	Detail
Base Material	Alloy Steel
Finish Type	Lacquered
Special Feature	Adjustable
Recommended Uses For Product	Working
Item Weight	49 Pounds
Maximum Weight Recommendation	154 Pounds
Minimum Height	28 Inches
Maximum Height	46.3 Inches
Tabletop Thickness	1.18 Inches
Is Electric	Yes

DESK MEASUREMENT



Weight Capacity
up to 132lbs



<50dbs









Image: Detailed measurements of the desk, including height range and desktop dimensions.



Image: Illustrates the whole-piece desktop design, emphasizing its quality compared to split desktops.

Warranty & Support

Your FLEXISPOT Standing Desk comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official FLEXISPOT website. For customer support, troubleshooting assistance, or to inquire about replacement parts, please contact FLEXISPOT customer service through their official website or the contact information provided in your product packaging. You can also visit the [FLEXISPOT Store on Amazon](#) for additional resources.

	<p>FlexiSpot E4B/E4W Electric Standing Desk User Manual</p> <p>Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.</p>
	<p>FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>
	<p>FlexiSpot EM7L Motorized Computer Riser Installation Guide</p> <p>Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.</p>
	<p>FlexiSpot Q3G-1206-EU Electric Standing Desk User Manual</p> <p>Comprehensive user manual and installation guide for the FlexiSpot Q3G-1206-EU electric standing desk, covering specifications, assembly, operation, safety, and troubleshooting.</p>
	<p>FlexiSpot EH1-EU Electric Standing Desk Frame User Manual</p> <p>Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.</p>
	<p>FlexiSpot EG8B/EG8W Installation Guide and Limited Warranty</p> <p>This document provides a comprehensive installation guide and limited warranty information for the FlexiSpot EG8B/EG8W adjustable standing desk. It details specifications, assembly steps, keypad operation, troubleshooting, safety precautions, and warranty terms.</p>