

[manuals.plus](#) /› [Bialetti](#) /› [Bialetti New Venus 6TZ Induction Moka Pot Instruction Manual](#)**Bialetti 0007265/CN**

Bialetti New Venus 6TZ Induction Moka Pot Instruction Manual

1. INTRODUCTION

Thank you for choosing the Bialetti New Venus 6TZ Induction Moka Pot. This classic Italian coffee maker is designed to brew rich, authentic espresso-style coffee on induction stovetops, as well as gas and electric hobs. Please read this manual carefully before first use to ensure proper operation and longevity of your moka pot.

2. IMPORTANT SAFETY INSTRUCTIONS

- **Heat Warning:** The moka pot will become very hot during and after use. Always use the handle to move it and allow it to cool completely before disassembling or cleaning.
- **Pressure:** Do not overfill the water chamber above the safety valve. Ensure the upper and lower chambers are securely screwed together to prevent steam leaks and maintain proper pressure.
- **Ground Coffee:** Use medium-fine ground coffee. Do not tamp the coffee grounds.
- **Stovetop Compatibility:** This model is suitable for induction, gas, and electric stovetops. Ensure the moka pot base fully covers the heating element for optimal performance on induction hobs.
- **Cleaning:** Hand wash only. This moka pot is **not dishwasher safe**.
- **Children:** Keep out of reach of children.

3. COMPONENTS

The Bialetti New Venus Moka Pot consists of three main parts:

1. **Bottom Chamber (Water Boiler):** Holds the water. Features a safety valve.
2. **Filter Funnel:** Holds the ground coffee. Sits inside the bottom chamber.
3. **Top Chamber (Collector):** Collects the brewed coffee. Includes a lid and handle.



Image: Bialetti New Venus 6TZ Induction Moka Pot, illustrating its modular design for easy assembly and cleaning.

4. INITIAL SETUP AND FIRST USE

Before using your moka pot for the first time, it is recommended to clean it thoroughly and brew a few batches of coffee that will be discarded. This process seasons the pot and removes any manufacturing residues.

- 1. Disassemble:** Unscrew the top chamber from the bottom chamber. Remove the filter funnel.
- 2. Wash:** Wash all parts with warm water and a mild detergent. Rinse thoroughly. Do not use abrasive materials.
- 3. Assemble:** Reassemble the moka pot.
- 4. First Brews (Seasoning):** Fill the bottom chamber with water up to the safety valve. Insert the filter funnel and fill it with inexpensive ground coffee (do not tamp). Screw the top chamber on tightly. Place on the stovetop and brew as described in the "Operating Instructions" section. Discard the first 2-3 batches of coffee.

5. OPERATING INSTRUCTIONS

Follow these steps to brew delicious espresso-style coffee:

- Fill Water Chamber:** Unscrew the top chamber from the bottom chamber. Fill the bottom chamber with cold water up to the level of the safety valve. Do not exceed this level.
- Add Coffee Grounds:** Insert the filter funnel into the bottom chamber. Fill the funnel with medium-fine ground coffee. Do not tamp the coffee. Level the grounds gently without pressing them down.
- Assemble:** Screw the top chamber firmly onto the bottom chamber. Ensure it is tightly sealed to prevent steam from escaping during brewing.
- Place on Stovetop:** Place the moka pot on your stovetop. For induction hobs, ensure the base covers the heating element adequately. Use a medium heat setting.
- Brew:** As the water heats, steam pressure will force hot water up through the coffee grounds and into the top chamber. You will hear a gurgling sound as the coffee begins to flow.
- Serve:** Once the top chamber is full and the gurgling sound intensifies, remove the moka pot from the heat. Serve immediately.

6. MAINTENANCE AND CLEANING

Proper care will extend the life of your Bialetti New Venus Moka Pot.

- Cool Down:** Always allow the moka pot to cool completely before disassembling and cleaning.
- Hand Wash Only:** Wash all parts with warm water and a mild, non-abrasive detergent. Rinse thoroughly. **Do not place in a dishwasher**, as this can damage the metal and affect the coffee's flavor.
- Dry Thoroughly:** Dry all components completely before reassembling and storing to prevent mineral buildup and corrosion.
- Gasket and Filter Replacement:** Periodically check the rubber gasket and filter plate for wear. Replace them if they appear cracked, brittle, or if you notice steam escaping during brewing. Replacement parts are available from Bialetti authorized retailers.
- Safety Valve:** Ensure the safety valve is clear of any obstructions. Do not attempt to tamper with or remove the safety valve.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee does not brew or brews slowly.	<ul style="list-style-type: none">Insufficient water.Coffee grounds too fine or tamped too tightly.Heat too low.Gasket worn or loose.	<ul style="list-style-type: none">Ensure water is filled to the safety valve.Use medium-fine grounds; do not tamp.Increase heat slightly.Check and replace gasket if necessary.
Steam leaks from the side.	<ul style="list-style-type: none">Top and bottom chambers not screwed tightly.Gasket worn or improperly seated.	<ul style="list-style-type: none">Ensure chambers are screwed together firmly.Check gasket for proper seating and wear; replace if damaged.

Problem	Possible Cause	Solution
Coffee tastes burnt or bitter.	<ul style="list-style-type: none"> • Heat too high. • Coffee brewed for too long. • Pot not clean. 	<ul style="list-style-type: none"> • Reduce heat. • Remove from heat as soon as coffee fills the top chamber. • Clean thoroughly after each use.

8. PRODUCT SPECIFICATIONS

Brand	Bialetti
Model Name	Bialetti NEW VENUS 6TZ Induction
Item Model Number	0007265/CN
Coffee Maker Type	Moka Pot
Operation Mode	Manual
Coffee Input Type	Manual
Capacity	6TZ (1000 Milliliters) <i>(Note: 6TZ typically refers to 6 espresso cups, which is approximately 300ml. The provided specification of 1000 Milliliters may refer to a different measurement or be an error in the source data.)</i>
Power Source	AC (Stovetop)
Voltage	230 Volts (AC) <i>(Note: This voltage is typically for European markets. Ensure compatibility with your local power supply if using an electric hob.)</i>
Is Dishwasher Safe	No
Product Dimensions	0.39 x 0.39 x 0.39 inches <i>(Note: These dimensions appear to be incorrect and are likely placeholder data. Please refer to product packaging for accurate measurements.)</i>
Item Weight	0.353 ounces <i>(Note: This weight appears to be incorrect and is likely placeholder data. Please refer to product packaging for accurate weight.)</i>
Manufacturer	Bialetti

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the official Bialetti website or contact their customer service directly. Keep your proof of purchase for warranty claims.

Bialetti Official Website: www.bialetti.com

