

LifePlus B08BLP18LP

LifePlus Electric Fireplace Logs Heater Instruction Manual

Model: B08BLP18LP

This manual provides essential instructions for the safe and efficient operation and maintenance of your LifePlus Electric Fireplace Logs Heater.

1. IMPORTANT SAFETY INFORMATION


Please read all instructions carefully before using this electric fireplace logs heater. Failure to follow these instructions may result in fire, electric shock, or injury.

- Ensure the unit is plugged into a 120V AC grounded outlet. Do not use extension cords or power strips.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front of the heater and away from the sides and rear.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run the power cord under carpeting. Do not cover the cord with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas and where it will not be tripped over.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always unplug the heater when not in use.
- The unit is equipped with an **overheating protection** feature. If the heater overheats, it will automatically shut off. Unplug the unit, allow it to cool for 10-15 minutes, and clear any obstructions from the air vents before restarting.

2. PRODUCT OVERVIEW

The LifePlus Electric Fireplace Logs Heater is designed to provide realistic flame effects and supplemental

heating for indoor use. It features a 1500W heating element, adjustable flame brightness, and a convenient timer function, offering both ambiance and warmth.



The LifePlus Electric Fireplace Logs Heater, showcasing its realistic flame effect and included remote control.

REALISTIC PULSATING FLAME AND REALISTIC EMBER BED

4 Flame Brightness



Close-up view of the realistic pulsating flame and ember bed, featuring 4 flame brightness settings.

3. PACKAGE CONTENTS

- LifePlus Electric Fireplace Logs Heater
- Remote Control
- Instruction Manual

4. SPECIFICATIONS

Feature	Description
Brand	LifePlus
Power Source	Corded Electric
Product Dimensions	9"D x 21"W x 12"H

Material	Resin
Finish Type	Painted
Installation Type	Freestanding
Heat Output	1500 Watts
Special Feature	Adjustable Flame, Adjustable Thermostat, Flame Effect, Portable, Timer
Style	Classic
Color	Brown

5. SETUP

Follow these steps to set up your electric fireplace logs heater:

- Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
- Placement:** Place the electric fireplace logs heater on a flat, stable surface within an existing fireplace opening or a suitable open area. Ensure adequate clearance from combustible materials (at least 3 feet from the front, sides, and rear).
- Power Connection:** Plug the power cord into a standard 120V AC grounded outlet. Ensure the power cord is not pinched or routed under the unit.



The dimensions of the electric fireplace logs heater are 20.5 inches wide, 8.7 inches deep, and 12.2 inches high, with a 6.15 ft power cord.

CONVENIENT REMOTE CONTROL



The electric fireplace offers a clean alternative to traditional fireplaces, producing no gas, smell, or ashes, and requires minimal maintenance.

6. OPERATION

Your LifePlus Electric Fireplace Logs Heater can be operated using the included remote control or the manual controls located on the side panel of the unit.

6.1 Remote Control Functions

The remote control allows for convenient adjustment of all functions from a distance.



The remote control features buttons for Power, Timer, Heater, and Flame, allowing full control of the unit.

- **Power Button ()**: Press to turn the unit ON or OFF.
- **Timer Button ()**: Press to set the automatic shut-off timer. Options typically include 1H, 2H, 4H, and 8H.
- **Heater Button ()**: Press to activate the heating function. Cycle through different heat settings (e.g., 750W, 1500W) or turn the heater off.
- **Flame Button ()**: Press to adjust the brightness of the flame effect. There are typically 4 levels of flame brightness.

6.2 Side Panel Controls

The unit also features manual controls on the side panel for convenience, replicating the remote control functions.

EASY CONTROL

Allow you turn on the flame
without heating

Timer Light

Timer Button

Heater Button

Flame Button

Power Button



The side panel includes buttons for Timer, Heater, Flame, and a main Power switch for easy manual control.

6.3 Flame Effect Only

The realistic flame effect can be operated independently without activating the heating function. This allows for ambiance and visual appeal year-round, even when heat is not desired.

TURN ON THE FLAME WITHOUT HEATING



The electric fireplace can display its realistic flame effect without generating heat, perfect for creating ambiance in any season.

Your browser does not support the video tag.

This video demonstrates the operation of the LifePlus Electric Fireplace Logs Heater, including the use of both the remote control and the side panel buttons to adjust flame, heat, and timer settings.

7. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your electric fireplace logs heater.

- **Cleaning:** Always ensure the unit is unplugged from the power outlet and completely cool before performing any cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners, sprays, or harsh chemicals, as these may damage the finish.
- **Air Vents:** Periodically check the air intake and exhaust vents for dust or debris. Use a vacuum cleaner with a brush attachment to gently clean these areas to ensure proper airflow and prevent overheating.
- **Storage:** If storing the unit for an extended period, unplug it and allow it to cool. Store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

8. TROUBLESHOOTING

If you encounter any issues with your electric fireplace logs heater, refer to the following common

troubleshooting steps:

- **Unit does not turn on:**

- Ensure the power cord is securely plugged into a working 120V AC grounded outlet.
- Check if the main power switch on the unit's side panel is in the 'ON' position.
- Verify that the wall outlet is functioning by plugging in another appliance.

- **No heat output:**

- Confirm that the heater function is activated using either the remote control or the side panel buttons.
- Check if the overheating protection has been triggered. Unplug the unit, wait 10-15 minutes, and clear any obstructions from the air vents before restarting.

- **Flame effect not working:**

- Ensure the unit is powered on.
- Activate the flame function using the remote control or the side panel button.

- **Remote control not working:**

- Check and replace the batteries in the remote control if necessary.
- Ensure there are no obstructions between the remote control and the unit's sensor.



The unit includes a safety overheating protection feature, indicated by a thermometer and 'OFF' switch, which automatically activates if the temperature exceeds 230°F.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact LifePlus customer service. Refer to the product packaging or the official LifePlus website for contact details. Please have your model number (B08BLP18LP) and purchase date available when contacting support.