

- › [TVP Fit to Design Bissell](#) /
- › [TVP Fit to Design Bissell 1867 Series Steam Mop Water Filter Replacement Manual](#)

TVP Fit to Design Bissell TVP1603247

TVP Fit to Design Bissell 1867 Series Steam Mop Water Filter Replacement Manual

Brand: TVP Fit to Design Bissell | Model: TVP1603247

1. INTRODUCTION

This instruction manual provides essential information for the proper installation and maintenance of your TVP Fit to Design replacement water filter, designed for various Bissell 1867 series steam mops. This filter is comparable to Bissell part number 1603247. Regular replacement of the water filter helps maintain the performance and longevity of your steam mop by reducing mineral buildup from tap water.

2. PRODUCT OVERVIEW

The TVP Fit to Design water filter is a crucial component for your Bissell steam mop, designed to demineralize water before it is converted into steam. This process helps prevent limescale and mineral deposits from accumulating within the mop's heating elements and nozzles, ensuring consistent steam output and extending the life of your appliance.



This image displays the TVP Fit to Design replacement water filter for Bissell steam mops. It features a clear plastic casing filled with green and white filtration media, designed to reduce mineral buildup in your steam mop.

3. COMPATIBILITY

This replacement water filter is compatible with the following Bissell steam mop models:

- Bissell 21H6P
- Bissell 1867-4
- Bissell 18677
- Bissell 1867
- Bissell 18671
- Bissell 18674
- Bissell 18675
- Bissell 18676
- Bissell 18678
- Bissell 1867B
- Bissell 1867D
- Bissell 1867H
- Bissell 1867L
- Bissell 1867S
- Bissell 1867U
- Bissell 1867W

Important: Always verify your specific Bissell steam mop model number before purchasing and installing replacement parts. Do not rely solely on visual appearance.

4. SETUP AND INSTALLATION

Follow these general steps to replace the water filter in your compatible Bissell steam mop. For detailed, model-specific instructions, always refer to your original Bissell steam mop user manual.

1. **Power Off and Unplug:** Ensure your steam mop is turned off and unplugged from the electrical outlet before beginning any maintenance.
2. **Allow to Cool:** If the mop has been recently used, allow it to cool completely to prevent burns.
3. **Locate Filter:** Identify the location of the water filter on your specific Bissell steam mop model. This is typically near the water tank.
4. **Remove Old Filter:** Carefully remove the old water filter. This may involve twisting, pulling, or unlatching a cover, depending on your mop's design. Dispose of the old filter responsibly.
5. **Insert New Filter:** Take the new TVP Fit to Design replacement filter and insert it into the designated slot. Ensure it is seated firmly and correctly according to your mop's design.
6. **Secure:** If there is a cover or latch, secure it back into place.
7. **Test:** Fill the water tank with distilled or demineralized water (as recommended by Bissell), plug in the mop, and turn it on to check for proper operation and any leaks.

5. OPERATING CONSIDERATIONS

Once the new water filter is installed, your steam mop is ready for use. The filter works automatically to condition the water as it passes through to the heating element. No special operating procedures are required beyond the standard use of your Bissell steam mop.

6. MAINTENANCE

To ensure optimal performance of your steam mop and to prevent mineral buildup, it is recommended to replace the water filter regularly. The frequency of replacement depends on your water hardness and how often you use the steam mop. Typically, filters should be replaced every 3 to 6 months, or when you notice a decrease in steam production or a change in the color of the filter media.

- **Visual Inspection:** Periodically check the filter's media. If the green beads have turned completely brown or orange, it indicates the filter is exhausted and needs replacement.
- **Performance Check:** If your steam mop produces less steam than usual or leaves mineral residue, it may be time to replace the filter.

7. TROUBLESHOOTING

If you encounter issues after installing the new filter, consider the following:

- **No Steam or Low Steam:**
 - Ensure the filter is correctly seated and fully inserted.
 - Check if the water tank is properly filled and secured.
 - If the filter is old, it may be clogged; replace it.
- **Water Leaks:**

- Verify the filter is installed correctly and any associated covers or caps are tightly sealed.
- Inspect the filter for any visible damage.

- **Mineral Residue on Floor:**

- The filter may be exhausted and no longer effectively demineralizing the water. Replace the filter.
- Ensure you are using distilled or demineralized water if recommended by your steam mop's manufacturer.

If problems persist, consult your Bissell steam mop's original user manual or contact Bissell customer support.

8. SPECIFICATIONS

Attribute	Detail
Manufacturer	Top Vacuum Parts
Part Number	TVP1603247
Item Weight	4.1 ounces
Material	Plastic
Item Package Quantity	1
Number Of Pieces	1





9. WARRANTY INFORMATION

Specific warranty information for the TVP Fit to Design replacement water filter is not provided in the product details. Please refer to the manufacturer's official website or contact their customer service for any warranty-related inquiries.

10. SUPPORT

For further assistance or questions regarding the TVP Fit to Design replacement water filter, please contact the manufacturer, Top Vacuum Parts. Contact details are not provided in the product information. Please search for their official contact channels online.

Related Documents - TVP1603247

	<p>Bissell PowerFresh Steam Mop Troubleshooting: Leaking & No Power Solutions</p> <p>Resolve leaking and no power problems with your Bissell PowerFresh Steam Mop. This guide offers clear, step-by-step troubleshooting instructions for common issues.</p>
	<p>BISSELL PowerFresh™ Steam Mop User's Guide (Model 1940 Series)</p> <p>Comprehensive user's guide for the BISSELL PowerFresh™ Steam Mop (Model 1940 Series), covering safety instructions, product features, assembly, operation, maintenance, troubleshooting, warranty, and registration.</p>
	<p>BISSELL PowerFresh Slim Steam Mop User Guide</p> <p>Comprehensive user guide for the BISSELL PowerFresh Slim Steam Mop, covering assembly, operation, maintenance, and troubleshooting. Learn how to effectively use your steam mop for a deeper clean.</p>
	<p>BISSELL PowerFresh Slim Steam Mop User Guide</p> <p>A comprehensive user guide for the BISSELL PowerFresh Slim Steam Mop, covering assembly, operation, and maintenance. Includes model numbers 2233, 2234, and 2781.</p>
	<p>BISSELL Lift-Off Steam Mop 39W7 Series User's Guide</p> <p>Comprehensive user's guide for the BISSELL Lift-Off Steam Mop, 39W7 Series. Includes safety instructions, assembly, operation, maintenance, troubleshooting, warranty, and product registration information.</p>



[BISSELL Steam & Sweep 46B4 Series User's Guide](#)

User's guide for the BISSELL Steam & Sweep 46B4 Series hard floor cleaner, providing detailed instructions on safety, assembly, operation, maintenance, troubleshooting, and warranty information.