

Simple Houseware BO-45C-B

Simple Houseware 3-Tier Shoe Rack Storage Organizer
MODEL: BO-45C-B

Introduction

This manual provides instructions for the assembly, operation, and maintenance of your Simple Houseware 3-Tier Shoe Rack Storage Organizer. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.

Safety Information

- Do not exceed 9 lbs (4.1 kg) per shelf.
- Ensure stable placement to prevent tipping.
- Keep small parts away from children during assembly.
- Do not climb on the shoe rack.

Setup

The Simple Houseware 3-Tier Shoe Rack requires assembly. Follow the steps below for proper setup. A screwdriver is required (not included).

1. Unpacking and Parts Identification

Carefully remove all components from the packaging. Verify that all parts are present according to the included parts diagram.

Simple Houseware




Image: Illustrated parts diagram showing all components required for assembly.

2. Assembling the Frame

Connect the metal side frames using the provided horizontal bars. Ensure all connections are secure. The frame is designed for stability.



Adjustable Shelves

Image: Close-up view of the metal bars being connected to form the frame of the shoe rack.

3. Attaching the Fabric Shelves

Slide the washable 600 D polyester fabric shelves onto the horizontal bars. Ensure they are taut and evenly distributed across the frame. The shelves are designed to hold up to 30 lbs each.



16 Pairs Maximum

Image: A fabric shelf being carefully slid onto the metal frame, demonstrating the attachment process.

4. Adjusting Shelf Height (Optional)

The shelves are height adjustable. You can remove a panel to configure the rack into a 2-tier or 3-tier setup, accommodating different shoe types like boots or heels. This allows for personalized storage.



Image: Detail of the adjustable shelf mechanism, showing how shelves can be repositioned for varying shoe heights.

Operating

Once assembled, the shoe rack is ready for use. Place your shoes on the fabric shelves. The rack can store up to 9-16 pairs of shoes, with additional space on the bottom for more.



Image: The 3-tier shoe rack fully assembled and organized with multiple pairs of shoes, demonstrating its storage capacity.

Expandability

Multiple Simple Houseware shoe racks can be placed side-by-side to create a larger storage solution, ideal for expanding your organization system in closets, entryways, or mudrooms.



**Sturdy
Metal Construction**



**Washable
600 D Polyester Fabric**

Image: Three shoe racks connected to form a wider storage unit, showcasing the product's modular design.

Maintenance

To maintain the appearance and functionality of your shoe rack, wipe it with a dry cloth as needed. The 600 D polyester fabric shelves are washable for easy cleaning.

Troubleshooting

- **Rack feels unstable:** Ensure all screws are tightened securely. Verify that the rack is placed on a flat, level surface.
- **Shelves sagging:** Check that the weight on each shelf does not exceed 9 lbs (4.1 kg). Redistribute shoes if necessary.
- **Difficulty with assembly:** Refer to the assembly instructions and diagrams. Ensure correct parts are used for each step.

Specifications

Brand	Simple Houseware
Model Number	BO-45C-B
Dimensions	11.2"D x 26.8"W x 20.9"H
Number of Tiers	3 (adjustable)
Material	Metal frame, 600 D polyester fabric shelves
Color	Bronze
Weight Limit (per shelf)	9 lbs (4.1 kg)
Total Weight Capacity	90 lbs
Assembly Required	Yes
Special Features	Adjustable, Expandable, Stackable



Image: Diagram illustrating the dimensions (depth, width, height) of the 3-tier shoe rack.

Warranty

For information regarding product warranty, please refer to the documentation included with your purchase or contact Simple Houseware customer service.

Support

If you require further assistance or have questions about your Simple Houseware 3-Tier Shoe Rack, please contact Simple Houseware customer service. Contact details can typically be found on the product packaging or the official Simple Houseware website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08BNJ8XB2>

More documents and user manuals: <https://manuals.plus/>