Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHI VILLA B08BNQRWGZ

PHI VILLA 10'x10' Pop Up Canopy User Manual

Model: B08BNQRWGZ

Introduction

Thank you for choosing the PHI VILLA 10'x10' Pop Up Canopy. This manual provides essential information for the safe and efficient setup, operation, maintenance, and storage of your canopy. Please read all instructions carefully before assembly and retain this manual for future reference.



Image: The PHI VILLA 10'x10' Pop Up Canopy in blue, fully assembled, alongside its folded frame and wheeled carry bag.

Important Safety Information

Failure to follow these safety instructions may result in injury or damage to the product.

- Keep out of reach of children.
- Avoid setting up on a steep incline or uneven surfaces.
- Do not set up in windy, rainy, or snowy conditions.
- If there is inclement weather, take the canopy down immediately to prevent damage.
- Fully anchor the canopy to the ground using stakes and ropes to ensure stability and avoid damage.
- The canopy is designed for temporary use only and should not be left unattended for extended periods.
- Do not use open flames or heating devices inside or near the canopy.

Package Contents

Please verify that all components are present before beginning assembly:

- 1 x Pop Up Canopy Frame (Pre-assembled)
- 1 x Canopy Top Fabric (Blue)
- 1 x Wheeled Carry Bag
- 4 x Ground Stakes
- 4 x Guy Ropes



Image: The main components of the canopy, including the folded frame, canopy top, and wheeled carry bag, as they appear when packaged.

Setup Instructions

It is recommended that two people assist with the setup process for ease and safety.

1. **Step 1: Open the Canopy Frame.** Place the folded frame in the center of your desired setup area. With a person at each end, slowly pull the frame outwards, partially extending it.




Image: Illustration of the canopy frame in its folded state and the initial step of pulling it open.

2. **Step 2: Attach the Canopy Top.** Drape the canopy fabric over the partially opened frame. Align the corners of the fabric with the corners of the frame. Secure the fabric to the frame using the attached Velcro straps. Ensure the vented top is correctly oriented.
3. **Step 3: Fully Extend the Frame.** From each corner, push up the steel frame until the sliding hub locks into place with an audible click. Ensure all four corners are fully extended and locked.
4. **Step 4: Adjust Height.** Press the red adjustment button on each leg and extend the legs to your desired height. There are three height positions available. Ensure all legs are set to the same height.



Image: Detailed view of the red adjustable 3-height position button and the anchoring spike at the base of a leg.

5. **Step 5: Secure the Canopy.** Use the provided ground stakes and guy ropes to firmly anchor each leg and corner of the canopy to the ground. This is crucial for stability, especially in light wind conditions.

Operating Instructions

Height Adjustment

The canopy features a 3-height position adjustment system. To adjust the height, locate the red button on each leg. Press the button and slide the inner leg up or down to the desired position. Ensure the button clicks securely into one of the three holes for stability. Always adjust all four legs evenly.



Image: Diagram illustrating the dimensions of the 10'x10' canopy and its three adjustable height positions.

Vented Top for Airflow

The canopy is designed with a vented top to improve air circulation and provide increased headroom. This feature helps to reduce wind resistance and heat buildup under the canopy.



Image: A close-up view of the canopy's vented top, designed to facilitate better air circulation and provide increased headroom.

Maintenance

Cleaning

- Clean the canopy fabric with mild soap and water. Do not use harsh detergents or abrasive cleaners.
- Rinse thoroughly and allow the fabric to air dry completely before folding and storing.
- Wipe down the frame with a damp cloth to remove dirt and debris.

Storage

- Ensure the canopy fabric and frame are completely dry before storage to prevent mold, mildew, and rust.
- Fold the canopy fabric neatly and place it back into the wheeled carry bag.
- Collapse the frame according to the reverse of the setup instructions and place it into the carry bag.

- Store the canopy in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: A person carrying the PHI VILLA canopy in its wheeled storage bag, demonstrating its portability.

Troubleshooting

- **Difficulty Opening/Closing Frame:** Ensure all locking mechanisms are disengaged when closing. When opening, ensure the frame is on a flat surface and pull evenly from opposite sides. Do not force the frame.
- **Water Pooling on Canopy Top:** This can occur during heavy rain if the canopy is not properly tensioned or if the legs are not fully extended. Ensure the canopy fabric is taut and all legs are at their maximum stable height. **Important:** The canopy is not designed for heavy rain. Take down immediately during inclement weather to prevent structural damage.
- **Canopy Instability:** Ensure all legs are fully extended and locked into position. Verify that all ground stakes and guy ropes are securely fastened to the ground. Do not use in strong winds.

- **Damaged Fabric:** Small tears can often be repaired with a patch kit designed for outdoor fabrics. For significant damage, contact customer support for replacement options.

Specifications

Feature	Detail
Brand	PHI VILLA
Model Number	B08BNQRWGZ
Material	Alloy Steel (Frame), Fabric (Canopy Top)
Color	Blue
Item Weight	26 Pounds
Product Dimensions	120"L x 120"W x 102"H (10'L x 10'W x 8.5'H)
UV Protection	True (UPF 50+, UVA 99%)
Water Resistance Level	Water Resistant
Assembly Required	No (Pop-up design)
Recommended Uses	Beach, Camping, Outdoor Activities, Party, Wedding

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact PHI VILLA customer service. Refer to your purchase documentation or the PHI VILLA official website for contact details.
Please have your model number (B08BNQRWGZ) and date of purchase available when contacting support.

© 2025 PHI VILLA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08BNQRWGZ

More documents and user manuals: **https://manuals.plus/**