

[Manuals.plus](#) /

› [Ideal Standard](#) /

› Ideal Standard A7192AA Cerafine O Built-in Shower Mixer Installation and User Manual

Ideal Standard A7192AA

Ideal Standard A7192AA Cerafine O Built-in Shower Mixer

Installation and User Manual

1. PRODUCT OVERVIEW

This manual provides detailed instructions for the installation, operation, and maintenance of your Ideal Standard A7192AA Cerafine O built-in single-lever shower mixer. This product is designed for use in bathroom shower installations, offering precise control over water flow and temperature.



Image 1: Ideal Standard A7192AA Cerafine O Built-in Shower Mixer. This image displays the chrome-finished single-lever mixer, designed for concealed installation within a shower system.

The A7192AA model features a durable chrome finish and a 47 mm ceramic cartridge with an EKO system, ensuring reliable performance and water efficiency. Please ensure all shower components are acquired separately as they are not included with this mixer.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage, personal injury, or product malfunction.

- Installation should only be performed by a qualified professional plumber in accordance with local plumbing and building codes.

- Ensure the main water supply is turned off before beginning any installation or maintenance work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Do not use abrasive cleaners or harsh chemicals on the chrome finish, as this may cause damage.
- Verify all connections are secure and leak-free before restoring water supply.

3. PACKAGE CONTENTS

Carefully unpack the product and verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with installation and contact your supplier.

- 1 x Ideal Standard A7192AA Single-lever Shower Mixer
- 1 x Concealed Body for installation

Note: Shower head, hose, and other shower components are not included and must be purchased separately.

4. INSTALLATION INSTRUCTIONS

This section outlines the general steps for installing the Ideal Standard A7192AA built-in shower mixer. Refer to the detailed technical drawings and consult a professional plumber for precise installation.




Image 2: Ideal Standard A7192AA Shower Mixer. This image shows the complete mixer unit, including the handle and faceplate, ready for installation.

4.1 Pre-Installation

1. Turn off the main water supply to the installation area.
2. Ensure the wall cavity is prepared according to the dimensions required for the concealed body.
3. Confirm that the hot and cold water supply lines (1/2" connections) are accessible and correctly positioned.

4.2 Concealed Body Installation

1. Mount the concealed body securely within the wall cavity, ensuring it is level and at the correct depth relative to the finished wall surface.
2. Connect the hot and cold water supply lines to the designated inlets on the concealed body. The connections are 1/2".
3. Connect the mixed water outlet from the concealed body to the shower outlet pipe.
4. Perform a leak test by temporarily restoring water supply to the concealed body before closing the wall. Address any leaks immediately.

4.3 Final Assembly

1. Once the wall is finished, install the decorative faceplate and handle onto the concealed body according to the manufacturer's instructions.
2. Secure all visible components firmly.
3. Restore the main water supply and check for proper operation and any leaks.

5. OPERATION

The Ideal Standard A7192AA is a single-lever mixer, providing intuitive control over water flow and temperature.

- **Water Flow Control:** Lift the lever handle to increase water flow. Push it down to decrease or stop the flow.
- **Temperature Control:** Rotate the lever handle to the left for hot water and to the right for cold water. The EKO system cartridge helps in managing water temperature and flow efficiently.




Image 3: Exploded view of a ceramic cartridge, illustrating the internal components responsible for water flow and temperature control, featuring FirmaFlow Technology.

6. CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and aesthetic appeal of your Ideal Standard shower mixer.

- **Cleaning:** Clean the chrome surfaces regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome finishes. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Avoid:** Do not use abrasive sponges, scouring pads, or cleaners containing alcohol, ammonia, bleach, or phosphoric acid, as these can damage the chrome finish.
- **Cartridge Maintenance:** If water flow or temperature control becomes inconsistent, the ceramic cartridge may

require cleaning or replacement. This should be performed by a qualified technician.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your shower mixer.

Problem	Possible Cause	Solution
Low water flow	Clogged aerator or shower head (if connected); partially closed stopcock; debris in cartridge.	Clean or replace aerator/shower head. Ensure stopcocks are fully open. Consult a plumber to inspect/clean the cartridge.
Inconsistent water temperature	Pressure imbalance between hot and cold water; faulty cartridge.	Check water pressure. If issue persists, the cartridge may need replacement by a professional.
Leaks from handle or faceplate	Loose connections; worn seals or O-rings; damaged cartridge.	Tighten connections. Inspect and replace seals/O-rings. If the cartridge is damaged, it requires replacement by a professional.

For issues not listed here or if solutions do not resolve the problem, please contact a qualified plumber or Ideal Standard customer support.

8. TECHNICAL SPECIFICATIONS

Specification	Detail
Model Number	A7192AA
Brand	Ideal Standard
Product Type Name	Built-in Bathtub/Shower Faucet
Color	Chrome
Finish Type	Chrome
Material	Metal, Acrylonitrile Butadiene Styrene
Handle Material	Metal
Number of Handles	1
Handle Type	Lever
Installation Type	Wall Mount, Single Hole
Special Feature	Tarnish Resistant
Included Components	1 mixer, 1 concealed body
Cartridge	47 mm with EKO system
Product Dimensions (L x W x H)	16.3 x 16.3 x 4.9 cm

Specification	Detail
Item Weight	1.13 Kilograms
Country of Origin	Bulgaria

9. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or spare parts, please refer to the official Ideal Standard website or contact their customer service department directly. Keep your proof of purchase for warranty claims.

Ideal Standard is committed to providing high-quality products and support. For further assistance, please visit www.idealstandard.com.

© 2023 Ideal Standard. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question