Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

shernbao B08BS41BF5

Shernbao Dog and Cat Nail Grinder Instruction Manual

Model: B08BS41BF5

1. Introduction

Thank you for choosing the Shernbao Dog and Cat Nail Grinder. This device is designed to provide a safe, efficient, and comfortable nail grooming experience for your pets. Featuring a high-speed motor, diamond grinding bit, and dual-speed settings, it is suitable for various pet sizes and nail hardness. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

2. Safety Information

- Always keep the device out of reach of children and pets when not in use.
- Do not immerse the device in water or any other liquid.
- Ensure the device is fully charged before use to maintain optimal performance.
- Avoid grinding the quick (the sensitive part of the nail containing blood vessels and nerves) to prevent pain and bleeding. If unsure, grind small amounts at a time.
- Do not use the device on broken, infected, or otherwise unhealthy nails. Consult a veterinarian if your pet has nail health issues.
- If the device becomes hot during prolonged use, turn it off and allow it to cool down.
- Use only the provided charging cable and adapter.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

3. Product Components

The Shernbao Nail Grinder features a robust design with user-friendly components:

- **Diamond Grinding Bit:** A durable, advanced diamond roller for effective and safe nail shaping.
- **High-Speed Motor:** Provides powerful and consistent grinding performance.
- **Porous Protective Sleeve:** Helps contain nail dust and offers different grinding ports.
- **Dual-Speed Settings:** Allows selection between 6500 RPM and 7500 RPM for varying nail hardness.

- **LCD Power Display:** Indicates battery status for convenient monitoring.
- **Non-Slip Ergonomic Grip:** Made from environmentally friendly TRP rubber for comfortable and secure handling.
- **USB Charging Port:** For quick and convenient recharging.



Figure 3.1: Internal components including the diamond grinding bit and high-speed motor.



Figure 3.2: Key features of the nail grinder, including the protective sleeve and controls.

4. Setup

4.1 Initial Charging

Before first use, fully charge the nail grinder. The device features fast charging technology and a high-capacity battery.

1. Connect the USB charging cable to the grinder's charging port.
2. Plug the other end of the USB cable into a power adapter, computer/PC, car charger, or power bank.
3. The LCD display will show the charging status. A full charge takes approximately 1.5 hours and provides 4-5 hours of continuous operation.



Figure 4.1: Charging options and battery indicators.

4.2 Preparing for Use

Ensure your pet is calm and comfortable before starting the grooming process. Introduce the grinder slowly to your pet, allowing them to get used to its sound and vibration.

5. Operating Instructions

5.1 Selecting the Grinding Port

The protective sleeve features three different grinding ports to accommodate various pet sizes:

- **Port 1:** For small-sized pets.
- **Port 2:** For medium-sized pets.
- **Port 3:** For large-sized pets and fast grinding.

Choose the appropriate port based on your pet's nail size.



Figure 5.1: Grinding ports for different pet sizes.

5.2 Powering On and Speed Selection

1. Press the power button to turn on the grinder.
2. The device offers two speed settings: 6500 RPM and 7500 RPM. Press the speed selection button to toggle between the two speeds.
3. Select the appropriate speed based on your pet's nail hardness and your comfort level. The higher speed (7500 RPM) is suitable for harder nails or faster grinding, while the lower speed (6500 RPM) is ideal for softer nails or more precise work.

5.3 Grinding Technique

1. Gently hold your pet's paw and isolate the nail you wish to grind.
2. Carefully insert the nail into the chosen grinding port.
3. Apply light pressure and grind the nail for only a few seconds at a time. This prevents overheating and allows you to check your progress to avoid the quick.

4. Repeat the process for each nail, gradually shaping it to the desired length.
5. After grinding, ensure the nail edges are smooth.

The grinder operates with low noise (below 46 dB) and low vibration, which helps keep pets calm during grooming.



Figure 5.2: Low noise operation for a calm grooming experience.

6. Maintenance

6.1 Cleaning the Grinding Head

Regular cleaning of the grinding head is essential for optimal performance and hygiene.

1. Turn off the device before cleaning.
2. Gently remove the protective sleeve.
3. Use a soft brush or cloth to remove any nail dust or debris from the diamond grinding bit and the inside of the protective sleeve.
4. Do not use water or harsh chemicals to clean the grinding bit.
5. Reattach the protective sleeve securely after cleaning.

6.2 Storage

Store the nail grinder in a cool, dry place, away from direct sunlight and moisture. Ensure it is fully charged before storing for extended periods to preserve battery life.

7. Troubleshooting

Problem	Possible Cause	Solution
Grinder does not turn on.	Battery is depleted.	Charge the device fully (refer to Section 4.1).
Grinding performance is weak or slow.	Low battery. Grinding bit is clogged with dust. Incorrect speed setting.	Charge the device. Clean the grinding bit (refer to Section 6.1). Select a higher speed setting.
Device gets hot during use.	Prolonged continuous use. Excessive pressure applied.	Allow the device to cool down. Apply lighter pressure and grind in short intervals.
Pet is scared of the grinder.	Not accustomed to the sound/vibration.	Introduce the grinder gradually. Start with short sessions, offering treats and praise. Allow your pet to sniff and investigate the device while it's off, then on.

8. Specifications

- **Brand:** Shernbao
- **Model:** B08BS41BF5
- **Dimensions (Packaging):** 16.69 x 7.8 x 4.7 cm
- **Weight (Packaging):** 231 g
- **Speed Settings:** 6500 RPM, 7500 RPM
- **Charging Time:** Approximately 1.5 hours
- **Operating Time:** 4-5 hours (continuous)
- **Noise Level:** Below 46 dB
- **Grinding Head:** Diamond roller

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact your retailer. Keep your purchase receipt as proof of purchase. If you encounter any issues not covered in this manual, please reach out to Shernbao customer service for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08BS41BF5

More documents and user manuals: **https://manuals.plus/**