



[Manuals.plus](#) /

> [DURAMAX](#) /

> DURAMAX Storemax Plus 7x7 Vinyl Garden Storage Shed Instruction Manual

DURAMAX 30325

DURAMAX Storemax Plus 7x7 Vinyl Garden Storage Shed Instruction Manual

Model: 30325

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your DURAMAX Storemax Plus 7x7 Vinyl Garden Storage Shed. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and safe operation. Retain this manual for future reference.

The DURAMAX Storemax Plus shed is designed to provide a durable, low-maintenance storage solution for outdoor items. Constructed from tough vinyl with a reinforced metal structure, it offers protection against various weather conditions.

2. SAFETY INFORMATION

Caution:

Proper assembly, handling, and maintenance are essential to ensure the structural integrity and longevity of this storage shed. Always follow the manufacturer's instructions for safe installation and use. Handle heavy components with care during assembly. Ensure the shed is placed on a level and stable foundation.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. Refer to the detailed parts list provided in your separate assembly guide for specific component identification.

- Vinyl wall panels and roof sections
- Reinforced metal frame components
- Double doors with integrated windows

- Door handles with padlock eyes
- Molded floor kit
- Fasteners and hardware

4. SETUP AND ASSEMBLY

Assembly of the DURAMAX Storemax Plus shed requires careful attention to detail and typically involves two individuals. A separate, detailed assembly guide with step-by-step diagrams is included with your product. Please follow those instructions precisely.

4.1 Site Preparation

Select a level and stable site for your shed. A concrete slab or a properly prepared gravel foundation is recommended to ensure stability and drainage. Ensure adequate clearance around the shed for assembly and future access.

4.2 Assembly Process

1. Unpack all components and verify against the parts list.
2. Assemble the molded floor kit on your prepared foundation.
3. Erect the wall panels, securing them to the floor and to each other according to the assembly guide.
4. Install the reinforced metal roof structure.
5. Attach the roof panels.
6. Install the double doors, ensuring they open and close smoothly.
7. Attach door handles and any remaining hardware.

Note: The shed's reinforced metal structure is designed to handle snow loads up to 20 lb/sqft. Proper assembly is crucial for this structural integrity.



Figure 1: Dimensional drawing of the Storemax Plus 7x7 shed, showing external dimensions including width, depth, and height.



Figure 2: Front view of the assembled shed, illustrating the double doors and overall structure.

5. OPERATING INSTRUCTIONS

5.1 Door Operation

The shed features wide double doors measuring 53 inches wide by 71.5 inches tall, designed for easy access and storage of large items. To open, grasp the handles and pull outwards. To close, push the doors firmly until they latch.



Figure 3: Interior view with doors open, demonstrating the wide access.

5.2 Security

The door handles include integrated padlock eyes for securing your belongings. A padlock (not included) can be used to lock the shed doors, providing enhanced security for stored items.



Figure 4: Detail of the door handle with padlock eye.

6. MAINTENANCE

The DURAMAX Storemax Plus vinyl shed is designed for minimal maintenance. Its vinyl construction ensures it will not rust, dent, rot, mildew, or fade under normal conditions. It does not require painting or treating.

6.1 Cleaning

To clean the shed, simply use water and a mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the vinyl surface.

6.2 Seasonal Checks

Periodically inspect the shed for any loose fasteners or signs of wear, especially after severe weather. Tighten any loose screws and ensure doors operate correctly.



Figure 5: Shed in a winter setting, highlighting its all-weather design.

7. TROUBLESHOOTING

This section addresses common issues that may arise during the use of your storage shed. For problems not listed here, please contact customer support.

7.1 Doors Do Not Close Properly

- Check if the shed is on a level surface. Uneven ground can cause the frame to twist, affecting door alignment.
- Inspect hinges for damage or loose screws. Tighten as necessary.
- Ensure no obstructions are preventing the doors from closing fully.

7.2 Water Leakage

- Verify that all roof panels and wall panels are securely fastened and sealed according to the assembly instructions.
- Check for any cracks or damage to the vinyl panels.
- Ensure the foundation provides adequate drainage away from the shed base.

8. SPECIFICATIONS

Feature	Detail
Brand	DURAMAX
Model Number	30325
Material	Polyvinyl Chloride (Vinyl) with Galvanized Steel Frame
Color	Dark Grey & Adobe
External Base Dimensions (W x D x H)	82.3 In. W x 81 In. D x 92.3 In. H (approx. 7 ft W x 7 ft D x 7.7 ft H)
Internal Dimensions (W x D)	76.8 In. W x 76.8 In. D (approx. 6.4 ft W x 6.4 ft D)
Side Panel Height	73 In. Tall (approx. 6.1 ft)
Door Style	Double Doors
Door Opening (W x H)	53 In. W x 71.5 In. H
Snow Load Capacity	20 lb/sqft
Assembly Required	Yes
Item Weight	94 Kilograms (207 pounds)
UPC	638801303251



Figure 6: Example of interior storage capacity.

9. WARRANTY AND SUPPORT

For warranty information or technical assistance, please refer to the warranty card included with your product or contact DURAMAX customer support directly. Contact details can typically be found on the manufacturer's website or on your purchase documentation.

For general inquiries or support, you may also refer to the seller, Durasheds, for assistance.