

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ArtCreativity](#) /
- › [ArtCreativity Fortune Telling Magical Ball Instruction Manual](#)

### ArtCreativity AC-1134

# ArtCreativity Fortune Telling Magical Ball Instruction Manual

Model: AC-1134

## 1. INTRODUCTION

The ArtCreativity Fortune Telling Magical Ball is a novelty toy designed to provide entertaining answers to 'yes' or 'no' questions. This manual provides instructions for its proper use and care to ensure an enjoyable experience.



Image: A couple interacting with the Fortune Telling Magical Ball.

## 2. PRODUCT OVERVIEW

This magical orb is a classic question-and-answer game. It features a durable plastic casing and an internal

mechanism that reveals one of several pre-programmed answers when shaken. The ball measures approximately 3.75 inches in diameter.



Image: The Fortune Telling Magical Ball showing its approximate 3.75-inch diameter.

### 3. SETUP

---

The ArtCreativity Fortune Telling Magical Ball requires no assembly or batteries. Simply remove the ball from its packaging, and it is ready for immediate use.

### 4. OPERATING INSTRUCTIONS

---

Follow these steps to use your Fortune Telling Magical Ball:

1. **Formulate a Question:** Think of a clear 'yes' or 'no' question.
2. **Shake the Ball:** Hold the ball with the answer window facing down. Gently shake the ball to allow the internal die to float and settle.
3. **Reveal the Answer:** Turn the ball over so the answer window faces upwards. An answer will appear

in the window.



Image: The Fortune Telling Magical Ball displaying an answer.

Examples of answers you might receive include:

- YES
- NO
- YOU CAN COUNT ON IT
- DON'T BET ON IT
- ANSWER UNCLEAR ASK ME LATER
- PROSPECT GOOD



## 5. MAINTENANCE

---

To maintain the condition of your Fortune Telling Magical Ball:

- **Cleaning:** Wipe the exterior of the ball with a soft, damp cloth. Do not use abrasive cleaners or submerge the ball in water.
- **Storage:** Store the ball in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

---

If you encounter an issue with your Fortune Telling Magical Ball:

- **Unclear Answer:** If the answer in the window is not fully visible or appears distorted, gently shake the ball again and turn it slowly to allow the internal die to settle correctly.
- **No Answer Appears:** Ensure the ball is shaken sufficiently to dislodge the internal die, then turn it over to reveal the answer.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	AC-1134
Brand	ArtCreativity
Package Dimensions	4.09 x 3.94 x 2.91 inches
Item Weight	7.4 ounces
Recommended Age	3 years and up

## 8. SAFETY INFORMATION

---

- This product is a novelty item and is not intended for actual fortune telling.
- Recommended for ages 3 and up. Adult supervision is advised for younger children.
- Keep out of reach of very young children to prevent choking hazards from small parts if the item were to break.
- Do not attempt to open or modify the ball, as this may damage the product and void any potential warranty.

## 9. WARRANTY AND SUPPORT

---

Specific warranty information is not explicitly provided with this manual. For support, warranty inquiries, or further assistance, please contact ArtCreativity directly through their official website or the retailer where the product was purchased.

